

BladeCenter Management Module  
BladeCenter T Management Module



# Command-Line Interface Reference Guide



BladeCenter Management Module  
BladeCenter T Management Module



# Command-Line Interface Reference Guide

**Note:** Before using this information and the product it supports, read the general information in “Getting help and technical assistance,” on page 145 and “Notices” on page 147.

**Fifteenth Edition (November 2008)**

**© Copyright IBM Corporation 2008.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

---

# Contents

## Chapter 1. Introduction . . . . . 1

Before you begin . . . . .	1
Accessibility features for the BladeCenter management module . . . . .	2

## Chapter 2. Using the command-line interface . . . . . 3

Command-line interface guidelines . . . . .	3
Selecting the command target. . . . .	4
Commands and user authority . . . . .	6
Cabling the management module . . . . .	8
Networked connection . . . . .	9
Direct connection . . . . .	9
Starting the command-line interface . . . . .	9
Telnet connection . . . . .	10
Secure Shell (SSH) connection . . . . .	11
BladeCenter unit configuration . . . . .	12
Configuring the management module . . . . .	12
Starting an SOL session . . . . .	14
Ending an SOL session . . . . .	14

## Chapter 3. Command reference . . . . . 15

Alphabetic command list . . . . .	15
Command list by function . . . . .	16
Command syntax . . . . .	17
alarm command (BladeCenter T only) . . . . .	18
alertentries command . . . . .	23
boot command . . . . .	29
clear command . . . . .	30
clearlog command . . . . .	31
clock command . . . . .	32
config command. . . . .	36
console command . . . . .	39
dhcpcfg command. . . . .	40
displaylog command . . . . .	41
dns command . . . . .	42
env (environment) command . . . . .	44
exit command . . . . .	48
fuelg command . . . . .	49
health command. . . . .	52
help command . . . . .	55
history command . . . . .	57
identify (location LED) command . . . . .	58
ifconfig command . . . . .	59
info (configuration information) command . . . . .	65
kvm (keyboard, video, mouse) command . . . . .	67
list (system physical configuration) command . . . . .	69
mt (media tray) command . . . . .	70
power command . . . . .	72
reset command . . . . .	76
shutdown command . . . . .	79
slp command. . . . .	80
smtp command . . . . .	81
snmp command . . . . .	82
sol (serial over LAN) command . . . . .	91

tcpcmdmode command . . . . .	95
telnetcfg (Telnet configuration) command . . . . .	97
update (update firmware) command . . . . .	98
uplink (management module failover) command . . . . .	101
users command . . . . .	103

## Chapter 4. Error messages . . . . . 113

Common errors. . . . .	114
alarm command errors . . . . .	116
alertentries command errors . . . . .	117
boot command errors. . . . .	118
clear command errors . . . . .	118
clearlog command errors . . . . .	118
clock command errors . . . . .	119
config command errors . . . . .	120
console command errors. . . . .	120
dhcpcfg command errors . . . . .	121
displaylog command errors. . . . .	121
dns command errors . . . . .	121
env command errors . . . . .	122
exit command errors . . . . .	122
fuelg command errors . . . . .	122
health command errors . . . . .	125
help command errors. . . . .	126
history command errors . . . . .	126
identify command errors . . . . .	126
ifconfig command errors . . . . .	127
info command errors . . . . .	130
kvm command errors. . . . .	131
list command errors . . . . .	131
mt command errors . . . . .	131
power command errors . . . . .	132
reset command errors . . . . .	132
shutdown command errors. . . . .	133
slp command errors . . . . .	133
smtp command errors . . . . .	133
snmp command errors . . . . .	134
sol command errors . . . . .	135
tcpcmdmode command errors . . . . .	136
telnetcfg command errors . . . . .	137
update command errors . . . . .	137
uplink command errors . . . . .	140
users command errors . . . . .	140

## Appendix. Getting help and technical assistance. . . . . 145

Before you call . . . . .	145
Using the documentation . . . . .	145
Getting help and information from the World Wide Web . . . . .	146
Software service and support . . . . .	146
Hardware service and support . . . . .	146
IBM Taiwan product service . . . . .	146

**Notices . . . . . 147**  
Trademarks . . . . . 147  
Important notes . . . . . 148

**Index . . . . . 151**

---

## Chapter 1. Introduction

This topic provides a short introduction to the BladeCenter management module command-line interface. Information about the command-line interface for the advanced management module is in a separate document.

The IBM® BladeCenter management-module command-line interface (CLI) provides direct access to BladeCenter management functions as an alternative to using the Web-based user interface. Using the command-line interface, you can issue commands to control the power and configuration of the management module and other components that are in a BladeCenter unit.

All IBM BladeCenter units are referred to throughout this document as the BladeCenter unit. All management modules are referred to throughout this document as the management module. Unless otherwise noted, all commands can be run on all management-module and BladeCenter unit types.

The command-line interface also provides access to the text-console command prompt on each blade server through a serial over LAN (SOL) connection. See the *IBM BladeCenter Serial Over LAN Setup Guide* for information about SOL and setup instructions.

You access the management-module CLI by establishing a Telnet connection to the IP address of the management module or through a Secure Shell (SSH) connection. You can initiate connections from the client system by using standard remote communication software; no special programs are required. Users are authenticated by the management module before they can issue commands. You enter commands one at a time; however, you can use command scripting to enter multiple commands. The interface does not support keyboard shortcuts, except for the special key sequence, Esc (, that terminates an SOL session.

The most recent versions of all BladeCenter documentation are available from <http://www.ibm.com/systems/support/>.

---

### Before you begin

The following hardware and software is required for the command-line interface:

#### Hardware:

No special hardware is required to use the management-module command-line interface.

To use the SOL feature, an Ethernet I/O module that supports SOL must be installed in I/O-module bay 1. You can use the console command to control a blade server through SOL only on blade server types that support SOL functionality and have an integrated service processor firmware level of version 1.00 or later. See the *IBM BladeCenter Serial Over LAN Setup Guide* for information.

#### Firmware:

Make sure that you are using the latest versions of device drivers, firmware, and BIOS code for your blade server, management module, and other BladeCenter components. Go to <http://www.ibm.com/systems/>

support/ for the latest information about upgrading the device drivers, firmware, and BIOS code for BladeCenter components. The latest instructions are in the documentation that comes with the updates.

The management-module CLI is supported by BladeCenter management-module firmware level version 1.08 or later. All versions of BladeCenter T management-module firmware and advanced management module firmware support the command-line interface. The SOL feature has additional firmware requirements. See the *IBM BladeCenter Serial Over LAN Setup Guide* for information.

---

## Accessibility features for the BladeCenter management module

Accessibility features help users who have a disability, such as restricted mobility or limited vision, to use information technology products successfully.

### Accessibility features

Accessibility for the BladeCenter management module interface is provided through the command-line interface. The remote control video feed is not accessible to a screen reader.

The BladeCenter Information Center is accessibility-enabled. The accessibility features of the information center include:

- Keyboard-only operation
- Interfaces that are commonly used by screen readers. (The Java access bridge must be installed to make Java applets available to the JAWS screen reader.)
- The attachment of alternative input and output devices

### Keyboard navigation

This product uses standard Microsoft® Windows® navigation keys.

### Related accessibility information

You can view the publications for IBM BladeCenter in Adobe® Portable Document Format (PDF) using the Adobe Acrobat® Reader. The PDFs are provided on a CD that is packaged with the product, or you can access them through the IBM BladeCenter Information Center.

### IBM and accessibility

See the IBM Human Ability and Accessibility Center for more information about the commitment that IBM has to accessibility.



---

## Chapter 2. Using the command-line interface

This topic tells you how to use the management module command-line interface.

The IBM management-module command-line interface (CLI) provides a convenient method for entering commands that manage and monitor BladeCenter components. This chapter contains the following information about using the command-line interface:

- “Command-line interface guidelines”
- “Selecting the command target” on page 4
- “Commands and user authority” on page 6
- “Cabling the management module” on page 8
- “Starting the command-line interface” on page 9
- “BladeCenter unit configuration” on page 12
- “Configuring the management module” on page 12
- “Starting an SOL session” on page 14
- “Ending an SOL session” on page 14

See Chapter 3, “Command reference,” on page 15 for detailed information about commands that are used to monitor and control BladeCenter components. Command-line interface error messages are in Chapter 4, “Error messages,” on page 113. See the *IBM BladeCenter Serial Over LAN Setup Guide* for SOL setup instructions and the documentation for your operating system for information about commands that you can enter through an SOL connection.

---

### Command-line interface guidelines

This topic gives general guidelines for using the BladeCenter command-line interface.

All commands have the following basic structure:

command -option parameter

Some commands do not require options and some command options do not require parameters. You can add multiple options to a command on one line to avoid repeating the same command. Options that display a value and options that set a value must not be used together in the same command. The following examples illustrate valid command option syntax:

- command
- command -option\_set
- command -option\_set parameter
- command -option1\_set parameter -option2\_set parameter

The information for each option is returned in the order in which it was entered and is displayed on separate lines.

Observe the following general guidelines when you use the command-line interface:

- Case sensitivity  
All commands, command options, and predefined command option parameters are case sensitive.  
  
**Note:** If you receive a Command not found error, make sure that you are typing the command in the correct case. For a list of valid commands, type help or ?.
- Data types  
The ip\_address data type uses a predefined formatted string of xxx.xxx.xxx.xxx, where xxx is a number from 0 to 255.
- Delimiters
  - Options are delimited with a minus sign.
  - In a command that requires parameters, a single space is expected between an option and its parameter. Any additional spaces are ignored.
- Output format
  - Failed commands generate failure messages.
  - Successful commands are indicated by the message OK or by the display of command results.
- Strings
  - Strings that contain spaces must be enclosed in quotation marks, for example, snmp -cn "John B. Doe".
  - String parameters can be mixed case.
- The help command lists all commands and a brief description of each command. You can also issue the help command by typing ?. Adding the -h parameter to any command displays its syntax.
- You can use the Up Arrow and Down Arrow keys in the command-line interface to access the last eight commands that you entered.


---

## Selecting the command target

This topic describes command targets and the persistent command environment.

You can use the command-line interface to target commands to the management module or to other devices in the BladeCenter unit. The command-line prompt indicates the persistent command environment: the environment in which commands are entered unless they are otherwise redirected. When a command-line interface session is started, the persistent command environment is system; this indicates that commands are being directed to the BladeCenter unit.

Command targets are specified hierarchically, as shown in the following illustration. This illustration shows command targets for all management module and BladeCenter unit types.



You can change the persistent command environment for the remainder of a command-line interface session by using the `env` command (see “`env (environment) command`” on page 44). When you list the target as a command attribute by using the `-T` option, you change the target environment for the command that you are entering, temporarily overriding the persistent command environment. You can specify target environments by using the full path name or by using a partial path name that is based on the persistent command environment. Full path names always begin with “system”. The levels in a path name are divided using a colon (:).

For example:

- Use the `-T system:mm[1]` option to redirect a command to the management module in bay 1.
- Use the `-T system:switch[1]` option to redirect a command to the I/O (switch) module in I/O (switch) module bay 1.
- Use the `-T sp` option to redirect a command to the integrated service processor in the blade server in blade server bay 3, when the persistent command environment is set to the blade server in blade server bay 3.

Most management-module commands must be directed to the primary management module. If only one management module is installed in the BladeCenter unit, it always acts as the primary management module. Either management module can function as the primary management module; however, only one management module can be primary at one time. You can determine which management module is acting as the primary management module by using the `list` command (see “`list (system physical configuration) command`” on page 69).

## Commands and user authority

This topic lists command-line interface commands and the user authority levels needed to run them.

Some commands in the command-line interface can be executed only by users who are assigned a required level of authority. Users with Supervisor command authority can execute all commands. Commands that display information do not require any special command authority; however, users can be assigned restricted read-only access, as follows:

- Users with Operator command authority can execute all commands that display information.
- Users with Chassis Operator custom command authority can execute commands that display information about the common BladeCenter unit components.
- Users with Blade Operator custom command authority can execute commands that display information about the blade servers.
- Users with Switch Operator custom command authority can execute commands that display information about the I/O modules.

Table 1 shows the command-line interface commands and their required authority levels. To use the table, observe the following guidelines:

- The commands in this table apply only to the command variants that set values or cause an action: display variants of the commands do not require any special command authority.
- If a command requires only one command authority at a time, each of the applicable command authorities is indicated by a dot (•). If a command requires a combination of two or more command authorities, the applicable command authorities are indicated by  $\diamond$  or  $\ddagger$ . For example, the `boot -c` command is available to a user with the Supervisor command authority and to a user with both the Blade Administration and Blade Remote Presence command authorities.

**Important:** Command authority definitions might change between firmware versions. Make sure that the command authority level for each user is correct after you update the management-module firmware.

**Note:** LDAP authority levels are not supported by the management-module Web interface.

Table 1. Command authority relationships

Command	Authority									
	Supervisor	Chassis Account Management	Chassis Log Management	Chassis Administration	Chassis Configuration	Blade Administration	Blade Configuration	Blade Remote Presence	I/O Module Administration	I/O Module Configuration
alarm -c, -r, -s	•				•		•			•
alarm -q -g	•					•		•		

Table 1. Command authority relationships (continued)

Command	Authority									
	Supervisor	Chassis Account Management	Chassis Log Management	Chassis Administration	Chassis Configuration	Blade Administration	Blade Configuration	Blade Remote Presence	I/O Module Administration	I/O Module Configuration
alertentries	•				•					
boot (blade server target)	•					•				
boot -c	•					◇		◇		
boot -p	•					•				
clear	•			◇	◇				‡	‡
clearlog	•		•							
clock	•				•					
config (blade server)	•						•			
config (management module)	•				•					
console	•							•		
dns	•				•					
fuelg	•				•					
identify	•				•		•			
ifconfig (blade server target)	•						•			
ifconfig (blade server ISMP, system targets)	•				•					
kvm -local	•				•					
mt -b	•							•		
mt -local, -remote	•				•					
power -on, -off, -softoff, -cycle	•					•				
power -on -c, -cycle -c	•					◇		◇		
reset (blade server or ISMP targets)	•					•				
reset (I/O module target)	•								•	
reset (management module target)	•			•						
reset -c, -clr, -dg, -ddg, -sft (blade server target)	•					◇		◇		
reset -exd, -full, -std (I/O module target)	•								•	

Table 1. Command authority relationships (continued)

Command	Authority									
	Supervisor	Chassis Account Management	Chassis Log Management	Chassis Administration	Chassis Configuration	Blade Administration	Blade Configuration	Blade Remote Presence	I/O Module Administration	I/O Module Configuration
reset -f (management module target)	•			•						
shutdown	•					•				
slp	•				•					
sntp	•				•					
snmp	•				•					
sol	•				•		•			
tcpcmdmode	•				•					
telnetcfg	•				•					
update (see Note 2)	•			•		•			•	
uplink	•				•					
users	•	•								

**Note:**

1. Firmware operations for the Server Connectivity Module for IBM BladeCenter require Chassis Administration authority.

## Cabling the management module

This topic describes how to cable the management module.

You must connect a client system to the management module to configure and manage operation of the BladeCenter unit. All management modules support a remote management and console (Ethernet) connection.

You can manage the BladeCenter unit by using by using the command-line interface that you access through Telnet. You can also use the graphical user interface that is provided by the management-module Web interface to manage the BladeCenter unit and blade servers that support KVM. To make management connections to blade servers that do not support KVM, use an SOL session through the management-module command-line interface.

To access the management-module command-line interface, you need the following equipment and information:

- A system with Ethernet capability. To facilitate connections at multiple locations, you can use a notebook computer.
- The management-module MAC address (listed on the label on the management module).
- For networked connection to the management module, you need a standard Ethernet cable and a local Ethernet network port (facility connection).
- For direct connection of a system to the management-module remote management and console (Ethernet) connector, you need an Ethernet crossover cable.

For information about accessing the management-module Web interface, see the *BladeCenter Management Module User's Guide*.

The following topics describe how to cable to the management module to perform initial configuration of the BladeCenter unit. See the *Installation Guide* for your management module for specific cabling instructions.

## Networked connection

This topic describes how to connect the management module to a network.

Connect one end of a Category 5 or higher Ethernet cable to the remote management and console (Ethernet) connector of the management module. Connect the other end of the Ethernet cable to the facility network.

## Direct connection

This topic tells you how to connect a client computer directly to the management module.

Connect one end of a Category 5 or higher Ethernet crossover cable to the remote management and console (Ethernet) connector of the management module. Connect the other end of the cable to the Ethernet connector on the client system.

---

## Starting the command-line interface

Access the management-module command-line interface from a client system by establishing a Telnet connection to the IP address of the management module or by establishing a Secure Shell (SSH) connection.

You can establish up to 20 separate Telnet or SSH sessions to the BladeCenter management module, giving you the ability to have 20 command-line interface sessions active at the same time.

Although a remote network administrator can access the management-module command-line interface through Telnet, this method does not provide a secure connection. As a secure alternative to using Telnet to access the command-line interface, use a serial or SSH connection. SSH ensures that all data that is sent over the network is encrypted and secure.

The following SSH clients are available. Although some SSH clients have been tested, support or nonsupport of any particular SSH client is not implied.

- The SSH clients that are distributed with operating systems such as Linux, AIX®, and UNIX (see your operating-system documentation for information). The SSH client of Red Hat Linux 8.0 Professional was used to test the command-line interface.
- The SSH client of cygwin (see <http://www.cygwin.com> for information)
- Putty (see <http://www.chiark.greenend.org.uk/~sgtatham/putty> for information)

The following table shows the types of encryption algorithms that are supported, depending on the client software version that is being used.

Algorithm	SSH version 1.5 clients	SSH version 2.0 clients
Public key exchange	SSH 1-key exchange algorithm	Diffie-Hellman-group 1-sha-1
Host key type	RSA - 1024-bit	DSA - 1024-bit
Bulk cipher algorithms	3-des	3-des-cbc or blowfish-cbc
MAC algorithms	32-bit crc	Hmac-sha1

The following topics describe how to connect your system to the management module to perform initial configuration of the BladeCenter unit. The management module has the following default settings:

- IP address: 192.168.70.125 (primary management module)
- IP address: 192.168.70.124 (standby management module)
- Subnet: 255.255.255.0
- User ID: USERID (all capital letters)
- Password: PASSWORD (note the number zero, not the letter O, in PASSWORD)

The system that you are connecting to the management module must be configured to operate on the same subnet as the BladeCenter management module. If the IP address of the management module is outside of your local domain, you must change the Internet protocol properties on the system that you are connecting.

## Telnet connection

This topic tells you how to establish a Telnet session with the management module.

To log on to the management module by using Telnet, complete the following steps:

1. From a command-line prompt on the network-management workstation, type `telnet 192.168.70.125`, and press Enter. The IP address 192.168.70.125 is the default IP address of the management module; if a new IP address has been assigned to the management module, use that one instead.
2. At the login prompt, type the management-module user ID. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module Web access. The default management-module user name is USERID, and the default password is PASSWORD (note the number zero, not the letter O, in PASSWORD).



The CLI command prompt is displayed. You can now enter commands for the management module.

## Secure Shell (SSH) connection

This topic tell you how to establish a Secure Shell (SSH) connection with the management module.

To log on to the management module using SSH, complete the following steps:

1. Make sure that the SSH service on the network-management workstation is enabled. See your operating-system documentation for instructions.
2. Make sure that the SSH server on the BladeCenter management module is enabled. See the *BladeCenter Management Module User's Guide* for instructions.
3. Start an SSH session to the management module, using the SSH client of your choice. For example, if you are using the cygwin client, from a command prompt on the network-management workstation, type `ssh 192.168.70.125`, and press Enter. The IP address 192.168.70.125 is the default IP address of the management module; if a new IP address has been assigned to the management module, use that one instead.
4. Type the management-module user ID when you are prompted. At the password prompt, type the management-module password. The user ID and password are case sensitive and are the same as those that are used for management-module Web access. The default management-module user name is `USERID`, and the default password is `PASSW0RD` (note the number zero, not the letter O, in `PASSW0RD`).

The CLI command prompt is displayed. You can now enter commands for the management module.

## Using the Secure Shell server

This topic tells you how to use the management module Secure Shell server.

The following SSH clients are available. Although some SSH clients have been tested, support or nonsupport of any particular SSH client is not implied.

- The SSH clients that are distributed with operating systems such as Linux, AIX®, and UNIX® (see your operating-system documentation for information).
- The SSH client of cygwin (see <http://www.cygwin.com> for information).

If you are using the Secure Shell client that is based on OpenSSH, such as the client that is included in Red Hat Linux version 7.3, to start an interactive command-line Secure Shell session to a management module with network address 192.168.70.2, type a command similar to the following example:

```
ssh -x -l USERID 192.168.70.2
```

where `-x` indicates no X Window System forwarding and `-l` indicates that the session is to use the login ID `USERID`.

---

## BladeCenter unit configuration

You must configure the BladeCenter unit for command-line interface operation.

The BladeCenter unit automatically detects the modules and blade servers that are installed and stores the vital product data (VPD). When the BladeCenter unit is started, the management module automatically configures the remote management port of the management module, so that you can configure and manage BladeCenter components. You configure and manage BladeCenter components remotely by using the management-module command-line interface (CLI) or the management-module Web interface.

To communicate with network resources and with the I/O modules in the BladeCenter unit, you must configure IP addresses for the management module and I/O modules. You can configure management-module IP addresses by using the Web interface or command-line interface. You can configure the I/O modules through the management-module Web interface or through an external I/O-module port that is enabled through the management module, using a Telnet interface, or a Web browser. See the documentation that comes with each I/O module for information and instructions.

To communicate with the blade servers for functions such as deploying an operating system or application program over a network, you must also configure at least one external (in-band) port on an Ethernet switch module in I/O-module bay 1 or 2.

**Note:** If a pass-thru module is installed in I/O-module bay 1 or 2 (instead of an Ethernet I/O module), you must configure the network switch that the pass-thru module is connected to; see the documentation that comes with the network switch for instructions.

---

## Configuring the management module

You must configure the management module for command-line interface operation.

You configure only the primary (active) management module. The standby management module, if present, receives the configuration and status information automatically from the primary management module when necessary. The configuration information in this topic applies to the primary management module, which might be the only management module in the BladeCenter unit.

If the management module that you installed is a replacement for the only management module in the BladeCenter unit and you saved the configuration file before you replaced the management module, you can apply the saved configuration file to the replacement management module. Management modules must have their configurations restored through the management-module Web interface (see the *BladeCenter Management Module User's Guide* for information).

For the primary management module to communicate, you must configure the IP addresses for the following internal and external ports:

- The external Ethernet (remote management) port (eth0) of the management module. The initial automatic management module configuration enables a remote console to connect to the management module to configure the port completely and to configure the rest of the BladeCenter unit.
- The internal Ethernet port (eth1) on the management module for communication with the I/O modules.

After you connect the primary management module to the network, the Ethernet port connection is configured in one of the following ways. Either of these actions enables the Ethernet connection on the primary management module.

- If you have an accessible, active, and configured dynamic host configuration protocol (DHCP) server on the network, the IP address, gateway address, subnet mask, and DNS server IP address are set automatically. The host name is set to the management-module MAC address by default, and the domain server cannot change it.
- If the DHCP server does not respond within 2 minutes after the port is connected, the management module uses the factory-defined static IP address and default subnet address.

**Note:** If the management-module DHCP setting is set to try the DHCP server and then use the static IP address, the management module uses the static IP address when the DHCP server is not available during management-module startup. When this occurs, the IP address might not be reachable if multiple management modules were started with the same static IP address.

**Important:** You cannot connect your system to the management module by using the factory-defined static IP address and default subnet address until at least 3 minutes after management-module startup.

**Note:** If the IP configuration is assigned by the DHCP server, you can use the MAC address of the management-module network interface to find out what IP address is assigned.

To configure the management-module internal and external Ethernet ports, complete the following steps:

1. Connect your system to the management-module command-line interface (see “Starting the command-line interface” on page 9 for more information).
2. Configure the internal Ethernet interface (eth1), using the **ifconfig** command (see “ifconfig command” on page 59 for instructions).

**Notes:**

- The internal Ethernet management port on each I/O module provides for communication with the management module. You configure this port by configuring the IP address for the I/O module (see the *BladeCenter Management Module User's Guide* and the *User's Guide* for your I/O module type for information and instructions). Some types of I/O modules, such as the pass-thru module, have no management port. See the documentation that comes with each I/O module to determine what else you must configure in the I/O module.
- For I/O-module communication with a remote management station, such as an IBM® Director management server, through the management-module external

Ethernet port, the I/O-module internal network interface and the management-module internal and external interfaces must be on the same subnet.

- To communicate with the blade servers for functions such as deploying an operating system or application program, you also must configure at least one external (in-band) port on an Ethernet I/O module.

---

## Starting an SOL session

After you start a Telnet or SSH session to the BladeCenter management module, you can start an SOL session to any individual blade server that supports SOL.

**Note:** Serial over LAN (SOL) must be enabled for both the BladeCenter unit and the blade server before you can start an SOL session with the blade server. See “sol (serial over LAN) command” on page 91 and the *BladeCenter Serial over LAN Setup Guide* for information about setting up and enabling SOL.

Because you can start up to 20 separate Web interface, Telnet, or SSH sessions to the BladeCenter management module, simultaneous SOL sessions can be active for each blade server installed in the BladeCenter unit.

Start an SOL session by using the `console` command, from the command line, indicating the target blade server. For example, to start an SOL connection to the blade server in blade bay 6, type

```
console -T system:blade[6]
```

**Note:** A blade server assembly that occupies more than one blade server bay is identified by the lowest bay number that it occupies.

After an SOL session is started, all commands are sent to the blade server that is specified by the `console` command until the SOL session is ended, regardless of the persistent command target that was in effect before the SOL session.

See “sol (serial over LAN) command” on page 91 and the *IBM BladeCenter Serial over LAN Setup Guide* for information about configuring a blade server for SOL. See your operating-system documentation for information about SOL commands that you can enter by using the command-line interface.

---

## Ending an SOL session

To end an SOL session, press Esc followed by an opening parenthesis.

When the SOL session ends, the command-line interface returns to the persistent command target that was in effect before the SOL session. If you want to end the Telnet or SSH command-line session, type `exit`.

**Note:** Exiting an SOL session does not stop the flow of serial data.

---

## Chapter 3. Command reference

This topic contains command function, usage information, and examples.

Commands in “Command syntax” on page 17 are listed in alphabetic order. The commands are also listed in the following two topics:

- “Alphabetic command list”
- “Command list by function” on page 16

Adding a `-h`, `-help`, or `?` option to a command displays syntax help for that command. For example, to display help for the `env` command, type one of the following commands:

- `env -h`
- `env -help`
- `env ?`

You can target a command to a device other than the one that is set as the default by adding a `-T` option to a command. See “Selecting the command target” on page 4 for information.

---

### Alphabetic command list

In alphabetic order, the commands are as follows:

- “alarm command (BladeCenter T only)” on page 18
- “alertentries command” on page 23
- “boot command” on page 29
- “clear command” on page 30
- “clearlog command” on page 31
- “clock command” on page 32
- “config command” on page 36
- “console command” on page 39
- “dhcpinfo command” on page 40
- “displaylog command” on page 41
- “dns command” on page 42
- “env (environment) command” on page 44
- “exit command” on page 48
- “fuelg command” on page 49
- “health command” on page 52
- “help command” on page 55
- “history command” on page 57
- “identify (location LED) command” on page 58
- “ifconfig command” on page 59
- “info (configuration information) command” on page 65
- “kvm (keyboard, video, mouse) command” on page 67
- “list (system physical configuration) command” on page 69
- “mt (media tray) command” on page 70
- “power command” on page 72
- “reset command” on page 76
- “shutdown command” on page 79
- “slp command” on page 80
- “smtp command” on page 81
- “snmp command” on page 82

- “sol (serial over LAN) command” on page 91
- “tcpcmdmode command” on page 95
- “telnetcfg (Telnet configuration) command” on page 97
- “update (update firmware) command” on page 98
- “uplink (management module failover) command” on page 101
- “users command” on page 103

---

## Command list by function

By function, the commands are as follows:

- **Built-in commands**

Use these commands to perform top-level functions within the command-line interface:

- “env (environment) command” on page 44
- “help command” on page 55
- “history command” on page 57
- “list (system physical configuration) command” on page 69

- **Common commands**

Use these commands to monitor and control operation of BladeCenter components:

- “health command” on page 52
- “info (configuration information) command” on page 65

- **Configuration commands**

Use these commands to view and configure network settings, Ethernet interfaces, and other functions:

- “alertentries command” on page 23
- “clock command” on page 32
- “config command” on page 36
- “dhcpinfo command” on page 40
- “dns command” on page 42
- “health command” on page 52
- “ifconfig command” on page 59
- “info (configuration information) command” on page 65
- “kvm (keyboard, video, mouse) command” on page 67
- “mt (media tray) command” on page 70
- “slp command” on page 80
- “smtp command” on page 81
- “snmp command” on page 82
- “sol (serial over LAN) command” on page 91
- “tcpcmdmode command” on page 95
- “telnetcfg (Telnet configuration) command” on page 97
- “uplink (management module failover) command” on page 101
- “users command” on page 103

- **Event log commands**  
Use these commands to view and clear primary management-module event log entries:
  - “clearlog command” on page 31
  - “displaylog command” on page 41
- **LED commands**  
Use these commands to monitor and control operation of BladeCenter unit LEDs:
  - “identify (location LED) command” on page 58
- **Memory commands**  
Use these commands to reset the management-module configuration and perform firmware updates:
  - “clear command” on page 30
  - “update (update firmware) command” on page 98
- **Power-control commands**  
Use these commands to control operation of the BladeCenter unit, blade servers, and I/O (switch) modules:
  - “boot command” on page 29
  - “power command” on page 72
  - “reset command” on page 76
  - “shutdown command” on page 79
- **Power-management commands**  
Use these commands to monitor power consumption of the BladeCenter unit and installed components:
  - “fuelg command” on page 49
- **Session commands**  
Use these commands to start an SOL connection to the command console of a specific blade server or to end a command console session:
  - “console command” on page 39
  - “exit command” on page 48
- **Systems-management commands (BladeCenter T only)**  
Use these commands to manage alarms for monitored parameters of the BladeCenter T unit:
  - “alarm command (BladeCenter T only)” on page 18

---

## Command syntax

Each of the following topics describes a command-line interface command and its syntax. Each command description also includes an example of command use.

## alarm command (BladeCenter T only)

This command displays alarm information, acknowledges alarms, and clears alarms for the specified command target.

Table 2. alarm command

Function	What it does	Command	Valid targets
<b>Display all alarms</b>	<p>Display all alerts generated by the target component. When directed to the BladeCenter unit, the command returns a summary of alarms for all BladeCenter components. When directed to a component installed in the BladeCenter unit, the command returns a detailed alarm listing for that component.</p> <p>Detailed alarm listings include an alarm key that can be used to acknowledge or clear an alarm.</p>	alarm	<ul style="list-style-type: none"> <li>-T system</li> <li>-T system:mm[x]</li> <li>-T system:blade[x]</li> <li>-T system:switch[x]</li> <li>-T system:power[x]</li> <li>-T system:blower[x]</li> </ul> <p>where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.</p>
<b>Display power alarms</b>	<p>Display all power related alerts generated by the target component. When directed to the BladeCenter unit, the command returns a summary of alarms for all BladeCenter components. When directed to a component installed in the BladeCenter unit, the command returns a detailed alarm listing for that component.</p> <p>Detailed alarm listings include an alarm key that can be used to acknowledge or clear an alarm. <b>Note:</b> The -p option can be combined with the -q option to query power related alarms.</p>	alarm -p	<ul style="list-style-type: none"> <li>-T system</li> <li>-T system:mm[x]</li> <li>-T system:blade[x]</li> <li>-T system:switch[x]</li> <li>-T system:power[x]</li> <li>-T system:blower[x]</li> </ul> <p>where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.</p>
<b>Display alarm information (specified by alarm generator ID)</b>	<p>Display information for alarm specified by the generator ID.</p>	<p>alarm -q -g <i>value</i></p> <p>where <i>value</i> is the generator ID.</p>	<ul style="list-style-type: none"> <li>-T system:mm[x]</li> <li>-T system:blade[x]</li> <li>-T system:switch[x]</li> <li>-T system:power[x]</li> <li>-T system:blower[x]</li> </ul> <p>where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.</p>



Table 2. alarm command (continued)

Function	What it does	Command	Valid targets
<b>Display alarm information (specified by alarm ID)</b>	Display information for alarm specified by the alarm ID.	alarm -q -a <i>value</i>  where <i>value</i> is the alarm ID.	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.
<b>Display detailed alarm information (specified by generator information)</b>	Display detailed information for alarm specified by the alarm generator information. Information returned includes the alarm description that is shown by the management-module Web interface and other information such as the alarm severity, power source, software indicator, and an alarm key.	alarm -q -o <i>value</i>  where <i>value</i> is the generator information.	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.
<b>Display alarm information (specified by complete alarm key)</b>	Display information for alarm specified by the complete alarm key.	alarm -q -k <i>m:g:o:a</i>  where <i>m:g:o:a</i> is the complete alarm key: <ul style="list-style-type: none"> <li>• <i>m</i> is the module ID</li> <li>• <i>g</i> is the generator ID</li> <li>• <i>o</i> is the generator information</li> <li>• <i>a</i> is the alarm ID</li> </ul>	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.
<b>Acknowledge alarm (specified by alarm generator ID)</b>	Acknowledge the alarm specified by the generator ID.	alarm -r -g <i>value</i>  where <i>value</i> is the generator ID.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.

Table 2. alarm command (continued)

Function	What it does	Command	Valid targets
<b>Acknowledge alarm (specified by generator information)</b>	Acknowledge the alarm specified by the generator information.	alarm -r -o <i>value</i>  where <i>value</i> is the generator information.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.
<b>Acknowledge alarm (specified by alarm ID)</b>	Acknowledge the alarm specified by the alarm ID.	alarm -r -a <i>value</i>  where <i>value</i> is the alarm ID.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.
<b>Acknowledge alarm (specified by complete alarm key)</b>	Acknowledge the alarm specified by the complete alarm key.	alarm -r -k <i>m:g:o:a</i>  where <i>m:g:o:a</i> is the complete alarm key: <ul style="list-style-type: none"> <li>• <i>m</i> is the module ID</li> <li>• <i>g</i> is the generator ID</li> <li>• <i>o</i> is the generator information</li> <li>• <i>a</i> is the alarm ID</li> </ul> Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.
<b>Clear alarm (specified by alarm generator ID)</b>	Clear the alarm specified by the generator ID.	alarm -c -g <i>value</i>  where <i>value</i> is the generator ID.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.

Table 2. alarm command (continued)

Function	What it does	Command	Valid targets
<b>Clear alarm (specified by generator information)</b>	Clear the alarm specified by the generator information.	alarm -c -o <i>value</i>  where <i>value</i> is the generator information.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.
<b>Clear alarm (specified by alarm ID)</b>	Clear the alarm specified by the alarm ID.	alarm -c -a <i>value</i>  where <i>value</i> is the alarm ID.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.
<b>Clear alarm (specified by complete alarm key)</b>	Clear the alarm specified by the complete alarm key.	alarm -c -k <i>m:g:o:a</i>  where <i>m:g:o:a</i> is the complete alarm key: <ul style="list-style-type: none"> <li>• <i>m</i> is the module ID</li> <li>• <i>g</i> is the generator ID</li> <li>• <i>o</i> is the generator information</li> <li>• <i>a</i> is the alarm ID</li> </ul> Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.
<b>Set alarm</b>	Set an alarm for the specified target, including severity level and description.	alarm -s -l <i>level desc</i>  where <ul style="list-style-type: none"> <li>• <i>level</i> is the severity level: <ul style="list-style-type: none"> <li>– CRT (critical)</li> <li>– MJR (major)</li> <li>– MNR (minor)</li> </ul> </li> <li>• <i>desc</i> is a short text description of the alarm</li> </ul> Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] -T system:blade[x] -T system:switch[x] -T system:power[x] -T system:blower[x]  where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.

**Example:** To display the alarm status for the BladeCenter T unit, while the BladeCenter T unit is set as the persistent command environment, at the system> prompt, type

```
alarm -q
```

To display the power alarm status for the BladeCenter T unit, while the BladeCenter T unit is set as the persistent command environment, at the system> prompt, type

```
alarm -p
```

To display detailed power alarm status for the power module in power bay 2, while the BladeCenter T unit is set as the persistent command environment, at the system> prompt, type

```
alarm -T system:power[2] -q
```

The following example shows the information that is returned from a series of alarm commands.

```
system> alarm -q
Alarms Summary List
Module          ACK  Severity  Power  Software
=====
mm[1]           No   Major    No     No
power[2]       No   Critical  Yes    No

system> alarm -q -p
Alarms Summary List
Module          ACK  Severity  Power  Software
=====
power[2]       No   Critical  Yes    No

system> alarm -q -T mm[1]
Alarms Detailed List
ACK Severity PWR SW  Descript                                     Key
=====
No Major   No No (05/21/08, 13:46:11) Insufficient chassis power 255:81:1:2:3
No Minor  No No (05/21/08, 13:45:26) Event log full                255:81:1:1:1

system>
```

## alertentries command

This command manages the recipients of alerts generated by the primary management module.

Table 3. *alertentries* command

Function	What it does	Command	Valid targets
<b>Display alert properties for all recipients</b>	Displays alert properties for all management-module alert recipients. Returned values for each alert recipient are: <ul style="list-style-type: none"> <li>• recipient name</li> <li>• notification method (E-Mail over LAN/Director comp./SNMP over LAN)</li> <li>• type of alerts received (Receives critical alerts only/Receives all alerts/Disabled)</li> </ul>	alertentries	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Display alert properties for alert recipients</b>	Displays alert properties for the specified management-module alert recipient profile. Returned values are: <ul style="list-style-type: none"> <li>• -status <i>alert_recipient_status</i> (on/off)</li> <li>• -n <i>alert_recipient_name</i></li> <li>• -f <i>alert_type</i> (critical/none)</li> <li>• -t <i>notification_method</i> (email/director/snmp)</li> <li>• -e <i>email_address</i> (used for e-mail notifications)</li> <li>• -i <i>static_IP_addr/hostname</i> (used for IBM Director notifications)</li> </ul>	alertentries <i>-recip_number</i>  where <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Delete alert recipient</b>	Delete the specified alert recipient.	alertentries <i>-recip_number -del</i>  where <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list. It is possible to delete an empty alert recipient.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 3. alertentries command (continued)

Function	What it does	Command	Valid targets
<p><b>Create alert recipient</b></p>	<p>Create the specified alert recipient.</p> <p>All fields must be specified when creating an alert recipient.</p>	<pre> alertentries -<i>recip_number</i> -n <i>recip_name</i> -status <i>alert_status</i> -f <i>filter_type</i> -t <i>notification_method</i> -e <i>email_addr</i> -i <i>ip_addr/hostname</i> </pre> <p>where:</p> <ul style="list-style-type: none"> <li>• <i>recip_number</i> is a number from 1 to 12 that corresponds to an unused recipient number in the "Display alert properties for all recipients" list.</li> <li>• <i>recip_name</i> is a alphanumeric string up to 31 characters in length containing any character, including spaces, except for angle brackets ( &lt; and &gt; ). If the string includes spaces it must be enclosed in double-quotes.</li> <li>• <i>alert_status</i> is on or off for receipt of alerts.</li> <li>• <i>filter_type</i> filters the alert types received: critical (receive critical alerts only) or none (receive all alerts).</li> <li>• <i>notification_method</i> is e-mail, director (IBM Director) or snmp. <ul style="list-style-type: none"> <li>– For e-mail, you must specify an e-mail address (-e argument).</li> <li>– For director you must specify an IP address (-i argument).</li> <li>– If snmp is selected, the -e and -i arguments are not needed.</li> </ul> </li> <li>• <i>email_addr</i> is a valid e-mail address string up to 63 characters in length.</li> </ul> <p>(continued on next page)</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 3. alertentries command (continued)

Function	What it does	Command	Valid targets
<b>Create alert recipient</b> (continued)		<ul style="list-style-type: none"> <li><i>ip_addr/hostname</i> is a valid static IP address or an alphanumeric hostname string for the recipient that is up to 49 characters in length that can include periods ( . ), hyphens ( - ), and underscores ( _ ).</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	
<b>Set alert recipient name</b>	Sets a name for the specified alert recipient.	<p>alertentries -<i>recip_number</i> -n <i>recip_name</i></p> <p>where:</p> <ul style="list-style-type: none"> <li><i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list.</li> <li><i>recip_name</i> is a alphanumeric string up to 31 characters in length that can include any character, including spaces, except for angle brackets ( &lt; and &gt; ). If the name includes spaces, it must be enclosed in double-quotes.</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>Set alert recipient status</b>	Sets status for the specified alert recipient. The status determines if a recipient will receive alarm notifications.	<p>alertentries -<i>recip_number</i> -status <i>alert_status</i></p> <p>where:</p> <ul style="list-style-type: none"> <li><i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list.</li> <li><i>alert_status</i> is on or off.</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 3. alertentries command (continued)

Function	What it does	Command	Valid targets
<b>Set alert types received</b>	Filters the types of alert that are received by the specified alert recipient.	<p>alertentries -<i>recip_number</i> -f <i>filter_type</i></p> <p>where:</p> <ul style="list-style-type: none"> <li>• <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list.</li> <li>• <i>alert_type</i> filters the alert types received: critical (receive critical alerts only) or none (receive all alerts).</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>Set alert notification method</b>	Sets the alert notification method for the specified alert recipient.	<p>alertentries -<i>recip_number</i> -t <i>notification_method</i></p> <p>where:</p> <ul style="list-style-type: none"> <li>• <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list.</li> <li>• <i>notification_method</i> is <ul style="list-style-type: none"> <li>- email</li> <li>- director (IBM Director)</li> <li>- snmp</li> </ul> </li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>



Table 3. alertentries command (continued)

Function	What it does	Command	Valid targets
<b>Set alert recipient e-mail address</b>	<p>Sets the e-mail address for the specified alert recipient. This e-mail address is used to send alerts to the recipient via e-mail.</p> <p>The e-mail address can be set only if the alert notification method (-t option) is set to email. The -t and -e options can be combined within the same command.</p>	<p>alertentries -<i>recip_number</i> -e <i>email_addr</i></p> <p>where:</p> <ul style="list-style-type: none"> <li>• <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list.</li> <li>• <i>email_addr</i> is a valid e-mail address string up to 63 characters in length.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>Set alert recipient IP address or hostname</b>	<p>Sets the IP address or hostname used to send alert notifications to the specified alert recipient using IBM Director.</p> <p>The IP address or hostname used to send alert notifications can be set only if the alert notification method (-t option) is set to director (IBM Director). The -t and -i options can be combined within the same command.</p>	<p>alertentries -<i>recip_number</i> -i <i>ip_addr/hostname</i></p> <p>where:</p> <ul style="list-style-type: none"> <li>• <i>recip_number</i> is a number from 1 to 12 that corresponds to the recipient number assigned in the "Display alert properties for all recipients" list.</li> <li>• <i>ip_addr/hostname</i> is a valid static IP address or an alphanumeric hostname string up to 49 characters in length that can include periods ( . ), hyphens ( - ), and underscores ( _ ).</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

**Example:** To view the configuration for alert recipient 1, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
alertentries -1
```

To configure alert recipient 2 to receive only critical alert notifications by e-mail, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
alertentries -2 -n test2 -status on -f critical -t email -e test2@us.ibm.com
```

To configure alert recipient 3 to receive all alert notifications through IBM Director, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
alertentries -3 -n test3 -status on -f none -t director -i 192.168.70.140
```

To configure alert recipient 4 to receive all alert notifications through SNMP, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
alertentries -4 -n test4 -status on -f none -t snmp
```

The following example shows the information that is returned from these commands:

```
system:mm[1]> alertentries -1
-status on
-n test1
-f critical
-t email
-e test1@us.ibm.com
system:mm[1]> alertentries -2 -n test2 -status on -f critical -t email
-e test2@us.ibm.com
OK
system:mm[1]> alertentries -3 -n test3 -status on -f none -t director
-i 192.168.70.140
OK
system:mm[1]> alertentries -4 -n test4 -status on -f none -t snmp
OK
system:mm[1]>
```

## boot command

This command resets blade servers with several different restart options.

Table 4. *boot command*

Function	What it does	Command	Valid targets
<b>Reset blade server</b>	Performs an immediate reset and restart of the specified blade server.  This command will start a blade server that is turned off.	boot  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where x is the blade server bay number.
<b>Reset blade server to command console</b>	Resets the specified blade server, causing it to open a command console with an SOL session when it restarts.  This command will start a blade server that is turned off.	boot -c  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where x is the blade server bay number.
<b>Power cycle</b>	Cycles power for the specified blade server. If the blade server is off, it will turn on. If the blade server is on, it will turn off and then turn on.	boot -p powercycle  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where x is the blade server bay number.
<b>Reset blade server</b>	Performs an immediate reset and restart of the specified blade server.  This command will start a blade server that is turned off.	boot -p reset  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where x is the blade server bay number.

**Example:** To boot the blade server in blade bay 3, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type  
boot -T system:blade[3]

The following example shows the information that is returned:

```
system:mm[1]> boot -T system:blade[3]
OK
system:mm[1]>
```

## clear command

This command restores the primary management module configuration or an I/O (switch) module configuration to the default settings.

The clear command must always include the `-config` option.

Table 5. *clear command*

Function	What it does	Command	Valid targets
<b>Restore default configuration of primary management module</b>	<p>Restores the default configuration of the primary management module; then, resets the management module.</p> <p>No results are returned from this command because it resets the management module.</p> <p>When you restore the management-module configuration, the Ethernet configuration method is set to a value of <code>dthens</code>. After the management module resets, this causes the management module to try dhcp configuration and then default to the static IP configuration, which might cause the management module to remain offline for longer than normal. See “<code>ifconfig</code> command” on page 59 for information.</p>	<p><code>clear -config</code></p> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p><code>-T system:mm[x]</code></p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>Restore default configuration of I/O module</b>	<p>Restores the configuration of the specified I/O module to the default settings.</p>	<p><code>clear -config</code></p> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p><code>-T system:switch[x]</code></p> <p>where <i>x</i> is the I/O-module bay number.</p>

**Example:** To restore the primary management-module configuration to default settings, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
clear -config
```

No results are returned from this command. After the management module resets, you will need to start a new command-line session.

## clearlog command

This command clears the management-module audit event log, the system event log, or both.

Table 6. *clearlog* (clear management-module event log) command

Function	What it does	Command	Valid targets
<b>Clear management-module event log</b>	Clears the management-module event log and displays a message confirming that the specified event log was cleared.	clearlog  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.

**Example:** To clear the management-module audit log, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type clearlog

The following example shows the information that is returned:

```
system:mm[1]> clearlog
OK
system:mm[1]>
```

## clock command

This command configures and displays the management-module clock settings.

Table 7. *clock* command

Function	What it does	Command	Valid targets
<b>Display management module clock information</b>	Displays the following information for the management module clock: <ul style="list-style-type: none"> <li>• current date and time</li> <li>• GMT (Greenwich-Mean Time) offset</li> <li>• daylight-savings time setting</li> </ul>	<code>clock</code>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Set management module date</b>	Sets the date for the management module clock.	<code>clock -d date</code>  where <i>date</i> is the current calendar date in mm/dd/yyyy format.  The month and day can be input as single digits. The year must be a four-digit number between 2000 and 2089, inclusive.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Set management module time</b>	Sets the time for the management module clock.	<code>clock -t time</code>  where <i>time</i> is the current time in 24-hour hh:mm:ss format.  The hours, minutes, and seconds can all be input as single digits.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.

Table 7. clock command (continued)

Function	What it does	Command	Valid targets
Set management module clock GMT offset	Sets the time for the management module clock.	<p>clock -g <i>offset</i></p> <p>where <i>offset</i> is a value between +12 and -12, in hours and minutes. Positive offsets are entered using the form: GMT+hh:mm, +hh:mm, +hh, hh:mm, or hh; where, the hours and minutes can be input as single digits. Negative offsets are entered using the form: GMT-hh:mm, -hh:mm, or -hh; where, the hours and minutes can be input as single digits. Valid offsets are:</p> <ul style="list-style-type: none"> <li>• GMT+0:00</li> <li>• GMT+1:00</li> <li>• GMT+2:00</li> <li>• GMT+3:00</li> <li>• GMT+3:30</li> <li>• GMT+4:00</li> <li>• GMT+4:30</li> <li>• GMT+5:00</li> <li>• GMT+5:30</li> <li>• GMT+6:00</li> <li>• GMT+7:00</li> <li>• GMT+8:00</li> <li>• GMT+9:00</li> <li>• GMT+9:30</li> <li>• GMT+10:00</li> <li>• GMT+11:00</li> <li>• GMT+12:00</li> <li>• GMT-12:00</li> <li>• GMT-11:00</li> <li>• GMT-10:00</li> <li>• GMT-9:00</li> <li>• GMT-8:00</li> <li>• GMT-7:00</li> <li>• GMT-6:00</li> <li>• GMT-5:00</li> <li>• GMT-4:00</li> <li>• GMT-3:30</li> <li>• GMT-3:00</li> <li>• GMT-2:00</li> <li>• GMT-1:00</li> </ul> <p>(continued on next page)</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 7. clock command (continued)

Function	What it does	Command	Valid targets
<p><b>Set management module clock GMT offset</b></p> <p>(continued)</p>		<p>For some time zones that use daylight-savings time (GMT +10, +2, -5, -6, -7, -8, -9), a special value for the <code>-dst</code> option must be specified to identify the correct daylight-savings time scheme to use in that time zone.</p> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	
<p><b>Set management module clock daylight-savings time mode</b></p>	<p>Sets the daylight-savings time mode for the management module clock.</p>	<p><code>clock -dst <i>dst_mode</i></code></p> <p>where <i>dst_mode</i> is one of the following:</p> <ul style="list-style-type: none"> <li>• off</li> <li>• on</li> <li>• for GMT+2:00: <ul style="list-style-type: none"> <li>– off</li> <li>– ee (Eastern Europe)</li> <li>– gtb (Great Britain)</li> <li>– egt (Egypt)</li> <li>– fle (Finland)</li> </ul> </li> <li>• for GMT+10:00: <ul style="list-style-type: none"> <li>– off</li> <li>– ea (Eastern Australia)</li> <li>– tas (Tasmania)</li> <li>– vlad (Vladivostok)</li> </ul> </li> <li>• for GMT-9:00 to GMT-5:00: <ul style="list-style-type: none"> <li>– off</li> <li>– uc (United States and Canada)</li> <li>– other (other locations)</li> </ul> </li> <li>• for GMT-4:00: <ul style="list-style-type: none"> <li>– off</li> <li>– can (Canada)</li> <li>– other (other locations)</li> </ul> </li> </ul> <p>Daylight-savings time is not observed in the following GMT offsets: GMT+4:00, GMT+4:30, GMT+5:30, GMT+6:00, GMT+7:00, GMT+8:00, GMT+11:00, GMT-12:00, GMT-11:00, and GMT-10:00.</p> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p><code>-T system:mm[x]</code></p> <p>where <i>x</i> is the primary management-module bay number.</p>



**Example:** To set the management-module for operation in the US Eastern time zone in compliance with new daylight-savings time rules, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
clock -g +5 -dst uc
```

To display the clock information for the primary management module, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
clock
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> clock -g +5 -dst uc
OK
system:mm[1]> clock
10/17/2006 02:27:11 GMT+5:00 dst uc
system:mm[1]>
```

## config command

This command sets and displays the name of the management module or blade server and the location and contact name for the management module.

Table 8. config command

Function	What it does	Command	Valid targets
<b>Display name of blade server</b>	Displays the name of the specified blade server.	config	-T system:blade[x]  where <i>x</i> is the blade server bay number.
<b>Display name of management module</b>	Displays the following information for the command target: <ul style="list-style-type: none"> <li>• Name</li> <li>• Location</li> <li>• Contact name</li> </ul>	config	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Display identifying information for BladeCenter unit</b>	Displays the following information for the command target: <ul style="list-style-type: none"> <li>• Universally unique identifier</li> <li>• Serial number</li> <li>• Type/model</li> </ul>	config	-T system
<b>Set name of management module or blade server</b>	Sets the name of the primary management module or specified blade server.	config -name <i>name</i>  where <i>name</i> is up to 15 characters in length.  Blade server names cannot contain angle brackets (" <i>&lt;</i> " and " <i>&gt;</i> "), and management module names can only contain alphanumeric characters, hyphens, pound signs, underscores, and periods.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x] -T system:blade[x]  where <i>x</i> is the primary management-module or a blade server bay number.
<b>Set location of management module</b>	Sets the location of the primary management module.	config -loc " <i>location</i> "  where " <i>location</i> " is up to 47 characters in length and contained within double-quotes.  Management module locations can contain any character other than " <i>&lt;</i> " and " <i>&gt;</i> ".  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.

Table 8. config command (continued)

Function	What it does	Command	Valid targets
<b>Set contact name for management module</b>	Sets the contact name for the primary management module.	<p>config -contact "<i>contact_name</i>"</p> <p>where "<i>contact_name</i>" is up to 47 characters in length and contained within double-quotes.</p> <p>Management module contact names can contain any character other than "&lt;" and "&gt;".</p> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>Set universally unique identifier (UUID) for BladeCenter unit</b>	<p>Sets the universally unique identifier for the BladeCenter unit.</p> <p><b>Notes:</b></p> <ul style="list-style-type: none"> <li>• Change the -uuid value only if you are certain it was not programmed correctly on the hardware. To prevent disrupting the operation of IBM Director, you should edit this field only if the midplane of your system has been replaced with a new midplane that does not have this information programmed on it.</li> <li>• If you change the UUID on an existing system to a random new value, IBM Director will treat this as a new system, distinct from the one identified by the old UUID.</li> <li>• Changes to the UUID take effect after the next restart of the management module.</li> </ul>	<p>config -uuid "<i>unique_id</i>"</p> <p>where "<i>unique_id</i>" is 32 hexadecimal digits and is contained within double-quotes.</p> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	-T system
<b>Set type/model for BladeCenter unit</b>	<p>Sets the type or model designator for the BladeCenter unit.</p> <p><b>Notes:</b></p> <ul style="list-style-type: none"> <li>• Change the -tm value only if you are certain it was not programmed correctly on the hardware. To prevent disrupting the operation of IBM Director, you should edit this field only if the midplane of your system has been replaced with a new midplane that does not have this information programmed on it.</li> <li>• Changes to the type/model take effect after the next restart of the management module.</li> </ul>	<p>config -tm "<i>type_model</i>"</p> <p>where "<i>type_model</i>" is up to seven characters in length and contained within double-quotes.</p> <p>Management module type / model designators can contain any character other than "&lt;" and "&gt;".</p> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	-T system

Table 8. config command (continued)

Function	What it does	Command	Valid targets
<b>Set serial number for BladeCenter unit</b>	<p>Sets the serial number for the BladeCenter unit.</p> <p><b>Notes:</b></p> <ul style="list-style-type: none"> <li>Change the -sn value only if you are certain it was not programmed correctly on the hardware. To prevent disrupting the operation of IBM Director, you should edit this field only if the midplane of your system has been replaced with a new midplane that does not have this information programmed on it.</li> <li>Changes to the serial number take effect after the next restart of the management module.</li> </ul>	<p>config -sn "serial_number"</p> <p>where "serial_number" is up to seven characters in length and contained within double-quotes.</p> <p>Management module serial numbers can contain any character other than "&lt;" and "&gt;".</p> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	-T system

**Example:**

To set the management module name to IBM\_lab, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
config -name IBM_lab
```

To display the management module name, location, and contact name, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
config
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> config -name IBM_lab
OK
system:mm[1]> config
-name IBM_lab
-contact John_Doe
-loc Main_Lab
system:mm[1]>
```

## console command

This command sets up a serial over LAN connection to the command console of a blade server.

To end an SOL session, press Esc followed by an open parenthesis:

Esc (

Table 9. console command

Function	What it does	Command	Valid targets
<b>Create SOL session with blade server</b>	Creates an SOL connection to the specified blade server.	console  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where <i>x</i> is the blade server bay number.
<b>Create override SOL session with blade server</b>	Creates an SOL connection to the specified blade server, with the override option enabled. This enables you to end an existing SOL session to that blade server and start a new one.	console -o  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where <i>x</i> is the blade server bay number.

**Example:** To start an SOL connection to the blade server in blade bay 14, while this blade server is set as the persistent command environment, at the `system:mm[x]>` prompt, type

```
console -T system:blade[14]
```

## dhcpcinfo command

This command displays the IP configuration that is assigned to the primary management module by the DHCP server.

**Note:** The `dhcpcinfo` command does not apply to `eth1`, which always uses a static IP configuration.

Table 10. `dhcpcinfo` command

Function	What it does	Command	Valid targets
Display Ethernet channel 0 DHCP configuration	If the IP configuration for <code>eth0</code> is assigned by a DHCP server, the configuration that is assigned by the DHCP server and DHCP server information is displayed. If the IP configuration for <code>eth0</code> is <i>not</i> assigned by a DHCP server, an error message is displayed. Possible configuration values returned are: <ul style="list-style-type: none"><li>• <code>-server dhcp_ip_address</code></li><li>• <code>-n hostname</code></li><li>• <code>-i ip_address</code></li><li>• <code>-g gateway_address</code></li><li>• <code>-s subnet_mask</code></li><li>• <code>-d domainname</code></li><li>• <code>-dns1 primary_dns_ip_address</code></li><li>• <code>-dns2 secondary_dns_ip_address</code></li><li>• <code>-dns3 tertiary_dns_ip_1address</code></li></ul>	<code>dhcpcinfo -eth0</code>	<code>-T system:mm[x]</code> where <i>x</i> is the primary management-module bay number.

**Example:** To display the DHCP server assigned network settings for Ethernet channel 0, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
dhcpcinfo -eth0
```

The following example shows the information that is returned:

```
system:mm[1]> dhcpcinfo -eth0
-server 192.168.70.29
-n MM00096BCA0C80
-i 192.168.70.183
-g 192.168.70.29
-s 255.255.255.0
-d linux-sp.raleigh.ibm.com
-dns1 192.168.70.29
-dns2 0.0.0.0
-dns3 0.0.0.0
system:mm[1]>
```

## displaylog command

This command displays management-module event log entries.

Table 11. *displaylog (display management-module event log) command*

Function	What it does	Command	Valid targets
Display management-module event log entries	Displays five entries from the management-module event log. The first time the command is executed, the five most recent log entries are displayed. Each subsequent time the command is issued, the next five entries in the log display.	displaylog	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
Display management-module event log entries (reset counter)	Resets the counter and displays the first five most recent entries in the management-module event log.	displaylog -f	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.

### Example:

To display all log entries generated by the management module in bay 1 other than those in the audit log, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type

```
displaylog -src !Audit -T mm[1]
```

To display audit log entries generated by the management module in bay 1, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type

```
displaylog -src Audit -T mm[1]
```

The following example shows the information that is returned from these commands:

```
system> displaylog -src !Audit -T mm[1]
1      I      SERVPROC  08/04/08  14:18:06  Recovery Event log full
2      I      SERVPROC  08/04/08  14:18:06  Alarm Manager removed a MNR
                                           alert during recovery of
                                           Event log full

(There are no more entries in the event log.)
system> displaylog -src audit -T mm[1]
1      I      Audit      08/04/08  14:28:38  Remote logoff successful for
                                           user 'spdev' from Telnet at
                                           IP 9.44.124.157
2      I      Audit      08/04/08  14:28:18  Remote login successful for
                                           user 'spdev' from Telnet at
                                           IP 9.44.124.157
3      I      Audit      08/04/08  14:18:15  Audit log cleared by 'spdev'.
(There are no more entries in the event log.)
system>
```

## dns command

This command configures and displays the management-module DNS settings.

Table 12. dns command

Function	What it does	Command	Valid targets
Display DNS configuration of management module	Displays the current DNS configuration of the management module. Possible return values are: <ul style="list-style-type: none"> <li>• enabled</li> <li>• disabled</li> <li>• -i1 <i>first ip_address</i></li> <li>• -i2 <i>second ip_address</i></li> <li>• -i3 <i>third ip_address</i></li> </ul>	dns	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
DNS - enable / disable	Enables or disables the management-module DNS configuration.	dns -state  where <i>state</i> is on or off.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
DNS first IP address - set	Checks syntax and sets the first IP address.	dns -i1 <i>ip_address</i>  where <i>ip_address</i> is the first IP address.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
DNS second IP address - set	Checks syntax and sets the second IP address.	dns -i2 <i>ip_address</i>  where <i>ip_address</i> is the second IP address.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
DNS third IP address - set	Checks syntax and sets the third IP address.	dns -i3 <i>ip_address</i>  where <i>ip_address</i> is the third IP address.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.

**Example:** To set the first IP address of the management-module DNS server to 192.168.70.29 and enable DNS on the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
dns -i1 192.168.70.29 -on
```

To display the DNS status of the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
dns
```



The following example shows the information that is returned from these two commands:

```
system:mm[1]> dns -i1 192.168.70.29 -on
Changes to the network settings will take effect after the next reset of the MM.
system:mm[1]> dns
Enabled
-i1 192.168.70.29
-i2 0.0.0.0
-i3 0.0.0.0
system:mm[1]>
```

## env (environment) command

This command sets the persistent environment for commands that are entered during the remainder of the current session.

The persistent command environment is indicated by the command prompt. When you start the command-line interface, the persistent command environment is the BladeCenter unit, denoted as `system` by the command prompt. You can target a single command to an environment other than the one that is set as the default by adding a `-T` option to the command that includes a valid target destination (see “Selecting the command target” on page 4 for information). Target environments can be specified using the full path name, or using a partial path name based on the persistent command environment. Full path names always begin with `system`. The levels in a path name are divided by using a colon ( `:` ).

The following table lists BladeCenter components and the command paths that are supported as targets by the `env` command.

Table 13. Components and command paths

Component	Target path
BladeCenter unit	<code>system</code>
Management module	<code>system:mm[x]</code>
Blade server	<code>system:blade[x]</code>
Blade server integrated system management processor (BMC or service processor)	<code>system:blade[x]:sp</code>
Blade server I/O-expansion card	<code>system:blade[x]:dtr[y]</code>
Blade server high-speed expansion card	<code>system:blade[x]:hsdc</code>
Blade server microprocessor	<code>system:blade[x]:cpu[y]</code>
Blade server storage expansion unit	<code>system:blade[x]:be</code>
I/O (switch) module	<code>system:switch[x]</code>
Power module	<code>system:power[x]</code>
Blower	<code>system:blower[x]</code>
Media tray	<code>system:mt</code>

Table 14. `env (environment) command`

Function	What it does	Command	Valid targets
<b>Set BladeCenter unit as command target</b>	Sets the BladeCenter unit as the persistent target for commands during the current session. This is the persistent command environment you are in at the beginning of each command-line interface session, indicated by the <code>system&gt;</code> prompt.	<code>env</code> <code>env -T system</code>	The <code>env</code> command can be directed to any installed device.

Table 14. `env` (environment) command (continued)

Function	What it does	Command	Valid targets
<b>Set management module as command target</b>	Sets the management module as the persistent target for commands during the current session.	<code>env -T system:mm[x]</code>  where <i>x</i> is the bay (1 or 2) that identifies the management module.	The <code>env</code> command can be directed to any installed device, in this case <code>-T system:mm[x]</code>  where <i>x</i> is the management-module bay number.
<b>Set blade server as command target</b>	Sets the specified blade server as the persistent target for commands during the current session.	<code>env -T system:blade[x]</code>  where <i>x</i> is the blade bay that identifies the blade server. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies.	The <code>env</code> command can be directed to any installed device, in this case <code>-T system:blade[x]</code>  where <i>x</i> is the blade bay that identifies the blade server.
<b>Set blade server sub-component as command target</b>	Sets the specified sub-component on the specified blade server as the persistent target for commands during the current session. Valid sub-components are: <ul style="list-style-type: none"> <li>• Integrated system management processor (BMC or service processor)</li> <li>• I/O-expansion card</li> <li>• Microprocessor</li> <li>• High-speed expansion card</li> <li>• Storage expansion unit</li> </ul>	<code>env -T system:blade[x]:comp</code>  where <i>x</i> is the blade bay that identifies the blade server on which the sub-component is installed. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies.  where <i>comp</i> is the sub-component: <ul style="list-style-type: none"> <li>• <code>sp</code> for BMC or service processor</li> <li>• <code>dtr[x]</code> for I/O-expansion card (where <i>x</i> identifies the expansion card)</li> <li>• <code>cpu[x]</code> for microprocessor (where <i>x</i> identifies the microprocessor)</li> <li>• <code>hsdc</code> for high-speed expansion card</li> <li>• <code>be[x]</code> for storage expansion unit (where <i>x</i> identifies the expansion unit)</li> </ul>	The <code>env</code> command can be directed to any installed device, in this case <code>-T system:blade[x]:comp</code>  where <i>x</i> is the blade bay that identifies the blade server on which the integrated system management processor is installed.  where <i>comp</i> is the sub-component: <ul style="list-style-type: none"> <li>• <code>sp</code> for BMC or service processor</li> <li>• <code>dtr[x]</code> for I/O-expansion card (where <i>x</i> identifies the expansion card)</li> <li>• <code>hsdc</code> for high-speed expansion card</li> <li>• <code>cpu[x]</code> for microprocessor (where <i>x</i> identifies the microprocessor)</li> <li>• <code>be[x]</code> for storage expansion unit (where <i>x</i> identifies the expansion unit)</li> </ul>

Table 14. env (environment) command (continued)

Function	What it does	Command	Valid targets
<b>Set I/O module as command target</b>	Sets the specified I/O module as the persistent target for commands during the current session.	env -T system:switch[x]  where x is the I/O-module bay where the I/O module is installed.	The env command can be directed to any installed device, in this case -T system:switch[x]  where x is the I/O-module bay where the I/O module is installed.
<b>Set power module as command target</b>	Sets the specified power module as the persistent target for commands during the current session.	env -T system:power[x]  where x is the power module bay where the power module is installed.	The env command can be directed to any installed device, in this case -T system:power[x]  where x is the power module bay where the power module is installed.
<b>Set blower as command target</b>	Sets the specified blower as the persistent target for commands during the current session.	env -T system:blower[x]  where x is the blower bay where the blower is installed.	The env command can be directed to any installed device, in this case -T system:blower[x]  where x is the blower bay where the blower is installed.
<b>Set media tray as command target</b>	Sets the media tray as the persistent target for commands during the current session.	env -T system:mt	The env command can be directed to any installed device, in this case  -T system:mt

**Example:** To set the persistent target of commands to the service processor on the blade server in blade bay 5, while the BladeCenter unit is set as the default command target, at the system> prompt, type

```
env -T system:blade[5]:sp
```

The following example shows the information that is returned:

```
system> env -T system:blade[5]:sp
OK
system:blade[5]:sp>
```

To set the persistent target of commands to the service processor on the blade server in blade bay 5, while the BladeCenter unit is set as the default command target, at the system> prompt, you can also type

```
env -T blade[5]:sp
```

The following example shows the information that is returned:

```
system> env -T blade[5]:sp  
OK  
system:blade[5]:sp>
```

To issue the reset command on the blade server in blade bay 5, while the management module is set as the default command target, at the `system:mm[x]>` prompt, type

```
reset -T system:blade[5]
```

## exit command

This command exits the command-line interface, terminating the current session.

Table 15. *exit* command

Function	What it does	Command	Valid targets
Exit	Terminates the current command-line interface session.	<code>exit</code> <b>Note:</b> You can also use the Ctrl-D key combination to end the current session and exit the command-line interface.	Any installed device.

**Example:** To terminate the current command-line interface session, type  
`exit`

## fuelg command

This command displays power domain information, listing the power modules that are installed in the BladeCenter unit and information about how the power in each domain is used. This command also configures the power domain policies for oversubscription and quiet mode.

Table 16. *fuelg* command

Function	What it does	Command	Valid targets
Display power domain status overview	Displays health status and total power usage information for all power domains	fuelg	-T system
Display detailed power domain status	Displays detailed status and usage information for the specified power domains	fuelg <i>domain</i>  where <i>domain</i> is: <ul style="list-style-type: none"> <li>• pd1 for power domain 1.</li> <li>• pd2 for power domain 2.</li> <li>• If no <i>domain</i> is specified, a status overview for all power domains displays.</li> </ul>	-T system
Set power domain redundancy loss policy	Sets how the BladeCenter unit responds to a condition that could cause a loss of redundant power.	fuelg <i>domain</i> -os <i>policy</i>  where: <ul style="list-style-type: none"> <li>• <i>domain</i> is: <ul style="list-style-type: none"> <li>– pd1 for power domain 1.</li> <li>– pd2 for power domain 2.</li> <li>– If no <i>domain</i> is specified, the <i>policy</i> is applied to all power domains.</li> </ul> </li> <li>• <i>policy</i> of: <ul style="list-style-type: none"> <li>– none (default) allows loss of redundancy.</li> <li>– nonrecov prevents components from turning on that will cause loss of power redundancy.</li> <li>– recov power throttles components to maintain power redundancy and prevents components from turning on that will cause loss of power redundancy.</li> </ul> </li> </ul> Command use restricted (see “Commands and user authority” on page 6).	-T system

Table 16. `fuelg` command (continued)

Function	What it does	Command	Valid targets
Thermal event response (quiet mode)	Sets how the BladeCenter unit blowers respond to thermal events.	<code>fuelg -qm <i>setting</i></code>  where the quiet-mode <i>setting</i> of: <ul style="list-style-type: none"> <li>• off (default) allows blowers to increase speed to provide additional cooling.</li> <li>• on keeps blowers at a fixed speed and power throttles BladeCenter components to reduce power consumption (only for BladeCenter components that support power throttling).</li> </ul> Command use restricted (see “Commands and user authority” on page 6).	-T system

**Example:** To view a power domain status overview, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type `fuelg`

To reduce fan noise during thermal events for all power domains, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type `fuelg -qm on`

To view the detailed power domain status for power domain 1, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type `fuelg pd1`

The following example shows the information that is returned when the `fuelg` command is run.

```
system> fuelg
Note: All power values are displayed in Watts.
```

```
Power Domain 1
-----
Status: Power domain status is good.
Modules:
  Bay 1: 2000
  Bay 2: 2000
Power Budget: 3200
Reserved Power: 400
Remaining Power: 2800
Power in Use: 400
```

```
Power Domain 2
-----
Status: Power domain status is good.
Modules:
  Bay 3: 1800
```



```

Bay 4: 1800
Power Budget: 2880
Reserved Power: 0
Remaining Power: 2880
Power in Use: 0

```

```

-qm off
system> fuelg -qm on
OK
system> fuelg pd1

```

Bay(s)	Module	Power State	-- Allocated Current	Power Max	-- Min
Chassis Components					
	Midplane	On	10	10	10
no media tray					
Blowers					
	1 Blower 1 (NP)	On	120	120	120
	2 Blower 2 (NP)	On	120	120	120
Management Modules					
	1 WMN315619689	On	25	25	25
	2 Backup MM (NP)		25	25	25
I/O Modules					
	1 I/O Module 2 (NP)		45	45	45
	2 I/O Module 2 (NP)		45	45	45
Domain totals:					
	Allocated Power		390	390	390

Note: (T) means "throttled", (U) means "unable to power up",  
 \* means "the blade may throttle", (NP) means "the module is not present", (D) means "discovering", (C) means "comm error", SB means "Standby"

```

-os none
system>

```

## health command

This command displays the current health status of the command target. It can also be used to display the alerts that are active for the command target.

You can only specify one command target each time you run the health command.

Table 17. health command

Function	What it does	Command	Valid targets
Display health status	<p>Displays the current health status of the command target. Return values are different for the BladeCenter and BladeCenter T configurations.</p> <ul style="list-style-type: none"> <li>• Possible return values for the BladeCenter configuration are: <ul style="list-style-type: none"> <li>- ok</li> <li>- warning</li> <li>- critical</li> </ul> </li> <li>• Possible return values for the BladeCenter T configurations are: <ul style="list-style-type: none"> <li>- ok</li> <li>- minor</li> <li>- major</li> <li>- critical</li> </ul> </li> </ul>	health	<ul style="list-style-type: none"> <li>-T system</li> <li>-T system:mm[x]</li> <li>-T system:blade[x]</li> <li>-T system:switch[x]</li> <li>-T system:power[x]</li> <li>-T system:blower[x]</li> </ul> <p>where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.</p>
Display health status for tree	<p>Displays the current health status of the tree structure of devices present in the BladeCenter unit, starting at the command target level. If management-module bays are part of the tree, they will be identified as primary or standby (redundant). Return values are different for the BladeCenter and BladeCenter T configurations.</p> <ul style="list-style-type: none"> <li>• Possible return values for the BladeCenter configuration are: <ul style="list-style-type: none"> <li>- ok</li> <li>- warning</li> <li>- critical</li> </ul> </li> <li>• Possible return values for the BladeCenter T configurations are: <ul style="list-style-type: none"> <li>- ok</li> <li>- minor</li> <li>- major</li> <li>- critical</li> </ul> </li> </ul>	<p>health -l <i>depth</i></p> <p>where <i>depth</i></p> <ul style="list-style-type: none"> <li>• 1 displays health status of the current command target</li> <li>• 2, all, or a displays a full tree display, starting at the command target level</li> </ul>	<ul style="list-style-type: none"> <li>-T system</li> <li>-T system:mm[x]</li> <li>-T system:blade[x]</li> <li>-T system:switch[x]</li> <li>-T system:power[x]</li> <li>-T system:blower[x]</li> </ul> <p>where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.</p>

Table 17. health command (continued)

Function	What it does	Command	Valid targets
Display health status and alerts	<p>Displays the current health status and active alerts for the command target. Return values are different for the BladeCenter and BladeCenter T configurations.</p> <ul style="list-style-type: none"> <li>• Possible return values for the health status of the BladeCenter configuration are: <ul style="list-style-type: none"> <li>- ok</li> <li>- warning</li> <li>- critical</li> </ul> </li> <li>• Possible return values for the health status of the BladeCenter T configurations are: <ul style="list-style-type: none"> <li>- ok</li> <li>- minor</li> <li>- major</li> <li>- critical</li> </ul> </li> <li>• Active alert information provides short text descriptions of alerts that are active for each monitored component.</li> </ul> <p>The total amount of information returned from the health -f command is limited to 1024 bytes.</p>	health -f	<ul style="list-style-type: none"> <li>-T system</li> <li>-T system:mm[x]</li> <li>-T system:blade[x]</li> <li>-T system:switch[x]</li> <li>-T system:power[x]</li> <li>-T system:blower[x]</li> </ul> <p>where <i>x</i> is the primary management-module, blade server, I/O module, power module, or blower bay number.</p>

**Example:** To display the overall health status of the BladeCenter T unit, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

```
health
```

To display the health status of all components installed in the BladeCenter T unit, that are valid command targets, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

```
health -l a
```

To display the health status of the blade server installed in blade bay 5, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

```
health -T system:blade[5]
```

To display the health status and alerts for all components installed in the BladeCenter T unit, that are valid command targets, while the BladeCenter T unit is set as the default command target, at the system> prompt, type

```
health -l a -f
```

The following example shows the information that is returned from these commands:

```
system> health
system:major
system> health -l a
system: Major
      mm[1]      :      OK
      blade[1]   :      OK
      blade[3]   :      OK
      blade[5]   :      Minor
      power[1]   :      OK
      power[2]   :      Minor
      blower[1]  :      OK
      blower[2]  :      OK
      blower[3]  :      OK
      blower[4]  :      OK
      switch[1]  :      Major
system> health -T system:blade[5]
system: blade[5] :      Minor
system> health -l a -f
system: Major
      blade[5]   :      Minor
      5V over voltage
      CPU1 temperature warning
      power[2]   :      Minor
      5V over voltage
      switch[1]  :      Major
      temperature fault
system>
```

## help command

This command displays a list of all commands that are available in the command-line interface with a brief description of each command.

You can also issue the help command by typing ?. Adding a -h, -help, or ? option to a command displays syntax help for the command.

Table 18. help command

Function	What it does	Command	Valid targets
Help	Displays a list of commands and a brief description of each command.	help	Any installed device.
		?	Any installed device.

**Example:** To display a list of commands, while the management module in bay 1 is set as the default command target, at the system:mm[1]> prompt, type help

The following example shows the information that is returned:

```
system> help
?- Display commands
alertentries- View/edit remote alert recipients
boot- Boot target
clear- Clear the config
clearlog- Clear the event log
clock- View/edit date, time, GMT offset, and dst setting
config- View/edit general settings
console- Start SOL session to a blade
dhcpinfo- View DHCP server assigned settings
displaylog- Display log entries
dns- View/edit DNS config
env- Set persistent command target
exit- Log off
fuelg- Power management
health- View system health status
help- Display command list
history- Display command history
identify- Control target location LED
ifconfig- View/edit network interface config
info- Display identity and config of target
kvm- Controls the kvm owner
list- Display installed targets
mt- Controls the media tray owner
power- Control target power
reset- Reset target
shutdown- Shutdown target
slp- View/edit SLP parameters
smtp- View/edit SMTP config
snmp- View/edit SNMP config
sol- View SOL status and view/edit SOL config
tcpcmdmode- View/edit TCP command mode config
telnetcfg- View/edit telnet config
update- Update firmware from TFTP server
uplink- View/edit failover on network uplink loss config
users- View/edit user login profiles
```

Type "<command> -h" for individual command syntax help.

[ ] is used for indexing (by bay number)

< > denotes a variable

{ } denotes optional arguments

| denotes choice

```
system>
```

To obtain help about the env command, type one of the following commands:

- env -h
- env -help
- env ?

## history command

This command displays the last eight commands that were entered, allowing the user to choose and re-enter one of these commands.

You choose the command to re-enter from the displayed list by typing an exclamation point (!) followed immediately by the numeric designation the command is assigned in the list. You can also recall one of the past eight previously entered commands using the up-arrow and down-arrow keys.

Table 19. history command

Function	What it does	Command	Valid targets
Command history	Displays the last eight commands that were entered.	history	Any installed device.
Re-enter previous command using numeric designation	Re-enters a numerically-specified command from the command history.	! <i>x</i> where <i>x</i> is the number of the command (0 - 7) to re-enter from the command history list.	Any installed device.

**Example:** To display a list of the last eight commands entered, while management module 1 is set as the default command target, at the `system:mm[1]>` prompt, type `history`

To re-enter the command designated by "2" in the command history, type `!2`

The following example shows the information that is returned from these two commands:

```
system:mm[1]> history
0 dns
1 dns -on
2 dns
3 dns -i1 192.168.70.29
4 dns
5 dns -i1 192.168.70.29 -on
6 dns
7 history
system:mm[1]> !2
Enabled
-i1 192.168.70.29
-i2 0.0.0.0
-i3 0.0.0.0
system:mm[1]>
```

## identify (location LED) command

This command controls operation of the location LED in a blade server or in the BladeCenter unit. It can also be used to display the state of a location LED.

Table 20. *identify (location LED) command*

Function	What it does	Command	Valid targets
<b>Display location LED state</b>	Displays the current state of the location LED in the command target.  Possible LED states are: <ul style="list-style-type: none"> <li>• off</li> <li>• on</li> <li>• blink</li> </ul>	<code>identify</code>	-T system -T system:blade[x]  where <i>x</i> is the blade bay number.
<b>Set location LED state</b>	Sets the state of the location LED in the command target.	<code>identify -s state</code>  where <i>state</i> is <ul style="list-style-type: none"> <li>• on</li> <li>• off</li> <li>• blink</li> </ul> Command use restricted (see “Commands and user authority” on page 6).	-T system -T system:blade[x]  where <i>x</i> is the blade bay number.
<b>Turn on BladeCenter unit location LED for specified period of time</b>	Turns on the location LED in the BladeCenter unit for a specified period of time before turning it off automatically.	<code>identify -s on -d time</code>  where <i>time</i> is the number of seconds the location LED will remain lit.  Command use restricted (see “Commands and user authority” on page 6).	-T system

**Example:** To display the status of the location LED in the blade server in blade bay 4, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type  
`identify -T system:blade[4]`

To light the location LED in the blade server in blade bay 4, while the BladeCenter unit is set as the persistent command environment, at the `system>` prompt, type  
`identify -s on -T system:blade[4]`

The following example shows the information that is returned from a series of `identify` commands:

```
system> identify -T system:blade[4]
-s off
system> identify -s on -T system:blade[4]
OK
system> identify -T system:blade[4]
-s on
system>
```



## ifconfig command

This command configures and displays the network interface settings for the management-module Ethernet interface, I/O-module Ethernet interface, and the blade server integrated system management processors.

Table 21. *ifconfig* command

Function	What it does	Command	Valid targets
<b>Display Ethernet channel 0 configuration</b>	Displays the current configuration of Ethernet channel 0. Possible return values are: <ul style="list-style-type: none"> <li>• enabled</li> <li>• disabled</li> <li>• -i <i>static_ip_address</i></li> <li>• -g <i>gateway_address</i></li> <li>• -s <i>subnet_mask</i></li> <li>• -n <i>hostname</i></li> <li>• -c <i>config_method</i></li> <li>• -r <i>data_rate</i></li> <li>• -d <i>duplex_mode</i></li> <li>• -m <i>mtu</i></li> <li>• -l <i>locally_administered_mac_addr</i></li> <li>• -b <i>burnedin_mac_address</i></li> </ul>	<code>ifconfig -eth0</code>	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Set Ethernet channel 0 static IP address</b>	Checks syntax and sets the static IP address for Ethernet channel 0.	<code>ifconfig -eth0 -i <i>ip_address</i></code>  where <i>ip_address</i> is the static IP address for Ethernet channel 0.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Set Ethernet channel 0 gateway IP address</b>	Checks syntax and sets the gateway IP address for Ethernet channel 0.	<code>ifconfig -eth0 -g <i>ip_address</i></code>  where <i>ip_address</i> is the gateway IP address for Ethernet channel 0.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Set Ethernet channel 0 subnet mask</b>	Checks syntax and sets the subnet mask for Ethernet channel 0.	<code>ifconfig -eth0 -s <i>sub_mask</i></code>  where <i>sub_mask</i> is the subnet mask for Ethernet channel 0.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 21. *ifconfig* command (continued)

Function	What it does	Command	Valid targets
<b>Set Ethernet channel 0 hostname</b>	Checks syntax and sets the host name for Ethernet channel 0.	<code>ifconfig -eth0 -n <i>hostname</i></code>  where <i>hostname</i> is the host name for Ethernet channel 0.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Set Ethernet channel 0 configuration method</b>	Checks syntax and sets the configuration method for Ethernet channel 0.  A value of <i>dthens</i> will try the DHCP configuration and default to the static IP configuration if DHCP is unsuccessful.  A value of <i>dthens</i> will try the DHCP configuration and default to the static IP configuration if DHCP is unsuccessful after 2 minutes. <b>Note:</b> If the management module DHCP setting is set to try the DHCP server and then use the static IP address, the management module will use the static IP address when the DHCP server is not available during management module start up. When this occurs, the IP address might not be reachable if multiple management modules were started with the same static IP address.	<code>ifconfig -eth0 -c <i>config_method</i></code>  where <i>config_method</i> is <ul style="list-style-type: none"> <li>• dhcp</li> <li>• static</li> <li>• dthens</li> </ul> Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Set Ethernet channel 0 data rate</b>	Checks syntax and sets the data rate for Ethernet channel 0.	<code>ifconfig -eth0 -r <i>data_rate</i></code>  where <i>data_rate</i> is <ul style="list-style-type: none"> <li>• auto</li> <li>• 10</li> <li>• 100</li> </ul> Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Set Ethernet channel 0 duplex mode</b>	Checks syntax and sets the duplex mode for Ethernet channel 0.	<code>ifconfig -eth0 -d <i>duplex_mode</i></code>  where <i>duplex_mode</i> is <ul style="list-style-type: none"> <li>• auto</li> <li>• half</li> <li>• full</li> </ul> Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.

Table 21. *ifconfig* command (continued)

Function	What it does	Command	Valid targets
<b>Set Ethernet channel 0 MTU</b>	Checks syntax and sets the MTU (maximum transmission unit) for Ethernet channel 0.	<code>ifconfig -eth0 -m <i>mtu</i></code>  where <i>mtu</i> is between 60 and 1500, inclusive.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Set Ethernet channel 0 static MAC address (locally administered)</b>	Checks syntax and sets the locally administered MAC address to the specified MAC address for Ethernet channel 0.	<code>ifconfig -eth0 -l <i>address</i></code>  where <i>address</i> is the locally administered MAC address for Ethernet channel 0.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Display Ethernet channel 1 configuration</b>	Displays the current configuration of Ethernet channel 1. Possible return values are: <ul style="list-style-type: none"> <li>• enabled</li> <li>• disabled</li> <li>• -i <i>static_ip_address</i></li> <li>• -g <i>gateway_address</i></li> <li>• -s <i>subnet_mask</i></li> <li>• -r <i>data_rate</i></li> <li>• -d <i>duplex_mode</i></li> <li>• -m <i>mtu</i></li> <li>• -l <i>locally_administered_mac_addr</i></li> <li>• -b <i>burnedin_mac_address</i></li> </ul>	<code>ifconfig -eth1</code>	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Set Ethernet channel 1 static IP address</b>	Checks syntax and sets the static IP address for Ethernet channel 1.	<code>ifconfig -eth1 -i <i>ip_address</i></code>  where <i>ip_address</i> is the static IP address for Ethernet channel 1.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Set Ethernet channel 1 gateway IP address</b>	Checks syntax and sets the gateway IP address for Ethernet channel 1.	<code>ifconfig -eth1 -g <i>ip_address</i></code>  where <i>ip_address</i> is the gateway IP address for Ethernet channel 1.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.

Table 21. ifconfig command (continued)

Function	What it does	Command	Valid targets
<b>Set Ethernet channel 1 subnet mask</b>	Checks syntax and sets the subnet mask for Ethernet channel 1.	<code>ifconfig -eth1 -s <i>sub_mask</i></code>  where <i>sub_mask</i> is the subnet mask for Ethernet channel 1.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Set Ethernet channel 1 static MAC address (locally administered)</b>	Checks syntax and sets the locally administered MAC address to the specified MAC address for Ethernet channel 1.	<code>ifconfig -eth1 -l <i>address</i></code>  where <i>address</i> is the locally administered MAC address for Ethernet channel 1.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Enable Ethernet channel 1</b>	Enables Ethernet channel 1.	<code>ifconfig -eth1 -up</code>  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Disable Ethernet channel 1</b>	Disables Ethernet channel 1.	<code>ifconfig -eth1 -down</code>  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Display starting IP address for blade server integrated system management processor</b>	Displays the starting point of the integrated system management processor IP addresses for blade servers that are installed in the BladeCenter unit.	<code>ifconfig</code>	-T system:blade[1]:sp
<b>Set starting IP address for blade server integrated system management processor</b>	Sets the starting point of the integrated system management processor IP addresses for blade servers that are installed in the BladeCenter unit.	<code>ifconfig -i <i>ip_address</i></code>  where <i>ip_address</i> is the starting IP address for all blade servers that are installed in the BladeCenter unit.  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[1]:sp

Table 21. *ifconfig* command (continued)

Function	What it does	Command	Valid targets
<b>Display network settings for I/O module</b>	Displays network settings for the specified I/O module. Depending on the type of I/O module targeted, valid return values might include one or more of the following: <ul style="list-style-type: none"> <li>• I/O-module type</li> <li>• Config. Method <i>config_method</i></li> <li>• -i <i>ip_address</i></li> <li>• -s <i>subnet_mask</i></li> <li>• -g <i>gateway_address</i></li> <li>• -em <i>ext_mgt_status</i></li> <li>• -ep <i>ext_port_status</i></li> </ul>	<i>ifconfig</i>	-T system:switch[x]  where <i>x</i> is the I/O-module bay number.
<b>Set starting IP address for I/O module</b>	Sets the IP addresses for a specified I/O module that supports IP address configuration.	<i>ifconfig -i ip_address</i>  where <i>ip_address</i> is the IP address of the specified I/O module.  Command use restricted (see “Commands and user authority” on page 6).	-T system:switch[x]  where <i>x</i> is the I/O-module bay number.
<b>Enable / disable external management for I/O module</b>	Enables or disables external management on all ports for a specified I/O module that supports this feature.	<i>ifconfig -em state</i>  where <i>state</i> is enabled or disabled.  Command use restricted (see “Commands and user authority” on page 6).	-T system:switch[x]  where <i>x</i> is the I/O-module bay number.
<b>Enable / disable external ports for I/O module</b>	Enables or disables external ports for the specified I/O module that supports this feature.	<i>ifconfig -ep state</i>  where <i>state</i> is enabled or disabled.  Command use restricted (see “Commands and user authority” on page 6).	-T system:switch[x]  where <i>x</i> is the I/O-module bay number.

**Example:**

To display the configuration for Ethernet channel 0, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type *ifconfig -eth0*

To set the static IP address for Ethernet channel 0 to 192.168.70.133, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type *ifconfig -eth0 -i 192.168.70.133 -c static*

The following example shows the information that is returned from these two commands:

```
system:mm[1]> ifconfig -eth0
Enabled
-i 10.10.10.10
-g 0.0.0.0
-s 255.255.255.0
-n MM00096BCA0C80
-c Try DHCP server.  If it fails, use static IP config.
-r Auto
-d Auto
-m 1500
-l 00:00:00:00:00:00
-b 00:09:6B:CA:0C:80
system:mm[1]> ifconfig -eth0 -i 192.168.70.133 -c static
Changes to the network settings will take effect after the next reset of the MM.
system:mm[1]>
```

## info (configuration information) command

This command displays information about BladeCenter components and their configuration, and how to reload the component information.

Table 22. info (configuration information) command

Function	What it does	Command	Valid targets
<b>Display component information</b>	Displays identification and configuration information for the command target.	info  <b>Note:</b> Only one target at a time can be viewed with the info command.	-T system -T system:mm[x] -T system:blade[x] -T system:blower[x] -T system:ncc[x] -T system:mux[x] -T system:tap -T system:blade[x]:dtr[y] -T system:blade[x]:hsdc -T system:blade[x]:sp -T system:blade[x]:be -T system:blade[x]:cpu[y] -T system:switch[x] -T system:power[x] -T system:mt  where: <ul style="list-style-type: none"> <li>• x is the management-module bay number, blade server bay number, I/O-module bay number, microprocessor number, power module bay number, or daughter-card number.</li> <li>• y is the: <ul style="list-style-type: none"> <li>– blade server I/O expansion card number (dtr).</li> <li>– microprocessor number (CPU).</li> </ul> </li> </ul>
<b>Reload component information for firmware</b>	Reloads vital product data (VPD) for firmware.	info -reload fw	-T system
<b>Reload component information for hardware</b>	Reloads vital product data (VPD) for hardware.	info -reload hw	-T system
<b>Reload information on MAC addresses</b>	Reloads vital product data (VPD) for MAC addresses.	info -reload mac	-T system
<b>Reload WWN and GUID information</b>	Reloads vital product data (VPD) for world-wide name (WWN) and globally-unique identifier (GUID).	info -reload wwn	-T system

Table 22. info (configuration information) command (continued)

Function	What it does	Command	Valid targets
<b>Reload all component information</b>	Forces reload of all VPD and MAC address information.	info -reload all	-T system

**Notes:**

1. The command targets -T system:blade[x]:cpu[y] and -T system:blade[x]:dtr[y] are shown with a line break before the :cpu[y] or :dtr[y]. When these command targets are entered, the entire entry must all be on one line.
2. This command returns vital product data (VPD) information that is unique for each command target.
3. Even if the command target is specified, the -reload option acts globally, reloading information not just for the specified target but for all targets in the corresponding category; for example, all MAC addresses are reloaded for all targets when the command is info -reload mac with system:blade[x] as the target.

**Example:** To view the information about a management module in management-module bay 1, while this management module is set as the persistent command environment, at the system:mm[1]> prompt, type

```
info
```

The following example shows the information that might be returned from the info command:

```
system:mm[1]> info
UUID: 0000 0000 0000 0000 0000 0000 0000 0000
Manuf ID: SLRM
Mach type/model: Management Module
Mach serial number: n/a
Manuf date: 4102
Part no.: 02R1606
FRU no.: 59P6622
FRU serial no.: J1P702A511F
Main application
- Build ID: DVETXX-
- File name: CNETMNUS.PKT
- Rel date: 05-27-04
- Rev: 16
Boot ROM
- Build ID: BRBR14-
- File name: CNETBRUS.PKT
- Rel date: 09-12-02
- Rev: 16
Remote control
- Build ID: BRRG14-
- File name: CNETRGUS.PKT
- Rel date: 09-12-02
- Rev: 16
>system:mm[1]>
```



## kvm (keyboard, video, mouse) command

This command sets and displays the blade server that is in control of the BladeCenter unit shared KVM.

Table 23. *kvm* command

Function	What it does	Command	Valid targets
Display KVM owner	Displays the number of the blade server that has KVM ownership and the global local KVM switching state for all blade servers. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies. A return value of 0 indicates that no owner is set.	kvm	-T system
Set KVM owner	Sets a blade server as the KVM owner.	kvm -b <i>blade_server</i>  where <i>blade_server</i> is the blade-bay number that identifies the blade server. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies. A setting of 0 sets no owner.  Command use restricted (see “Commands and user authority” on page 6).	-T system
Enable / disable local KVM switching globally	Enable or disable local KVM switching globally for all blade servers.	kvm -local <i>state</i>  where <i>state</i> is enabled or disabled.  Command use restricted (see “Commands and user authority” on page 6).	-T system

### Example:

To set the KVM owner to the blade server in blade bay 1, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
kvm -T system -b 1
```

To display the KVM owner and global local KVM switching state for all blade servers, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
kvm -T system
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> kvm -T system -b 1
OK
system:mm[1]> kvm -T system
-b 1
-local enabled
system:mm[1]>
```

## list (system physical configuration) command

This command displays a list of devices present within the command target. It can be used to determine how many management modules are installed in the BladeCenter unit and which management module is set as primary.

Table 24. list (system physical configuration) command

Function	What it does	Command	Valid targets
<b>View command target</b>	Displays the current command target. If a management-module bay is the current command target, it will be identified as primary or standby (redundant).	list	Any installed device.
<b>View system configuration tree</b>	Displays the tree structure of devices present in the BladeCenter unit, starting at the command target level. If management-module bays are part of the tree, they will be identified as primary or standby (redundant). For components that have been assigned a name, this name will be displayed next to the component bay number.	list -l <i>depth</i>  where <i>depth</i> is <ul style="list-style-type: none"> <li>• all or a for full tree display, starting at the command target level</li> <li>• 1 to display the current command target</li> <li>• 2 displays the content of the current command target plus one level below it</li> </ul>	Any installed device.

**Example:** To display a list of devices installed in the BladeCenter unit, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

```
list -l a
```

(This is the command syntax that can be used to determine the primary management module.)

The following example shows the information that is returned when the command is run on a management module:

```
system> list -l a
system
  mm[1]      primary
  power[4]
  blower[1]
  blower[2]
  switch[1]
  switch[2]
  switch[3]
  switch[4]
  blade[1]
    sp
    dtr[1]
  blade[5]
    sp
  blade[6]
    sp
  blade[7]
    sp
  blade[8]
    sp
  mt
system>
```

## mt (media tray) command

This command sets and displays the blade server that is in control of the BladeCenter unit shared media tray.

Table 25. *mt* command

Function	What it does	Command	Valid targets
<b>Display media tray owner</b>	Displays the number of the blade server that has media tray ownership and the global local and remote media tray switching states for all blade servers. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies. A return value of 0 indicates that no owner is set.	mt	-T system
<b>Set media tray owner</b>	Sets a blade server as the media tray owner.	mt -b <i>blade_server</i>  where <i>blade_server</i> is the blade bay that identifies the blade server. A blade server that occupies more than one blade bay is identified by the lowest bay number that it occupies. A setting of 0 sets no owner.  Command use restricted (see "Commands and user authority" on page 6).	-T system
<b>Enable / disable local media tray switching globally</b>	Enable or disable local media tray switching globally for all blade servers.	mt -local <i>state</i>  where <i>state</i> is enabled or disabled.  Command use restricted (see "Commands and user authority" on page 6).	-T system
<b>Enable / disable remote media tray switching globally</b>	Enable or disable remote media tray switching globally for all blade servers.	mt -remote <i>state</i>  where <i>state</i> is enabled or disabled.  Command use restricted (see "Commands and user authority" on page 6).	-T system

**Example:**

To set the media tray owner to the blade server in blade bay 1, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
mt -T system -b 1
```

To display the media tray owner and the global local and remote media tray switching states for all blade servers, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
mt -T system
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> mt -T system -b 1
OK
system:mm[1]> mt -T system
-b 1
-local enabled
-remote enabled
system:mm[1]>
```

## power command

This command turns on and turns off blade servers and I/O modules.

Table 26. power command

Function	What it does	Command	Valid targets
<b>Power on</b>	Turns on the specified command target.	power -on  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x] -T system:switch[x]  where <i>x</i> is the blade server or I/O-module bay.
<b>Power on to command console</b>	Opens a command console with an SOL session when the specified blade server is turned on.	power -on -c  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where <i>x</i> is the blade server bay number.
<b>Power off</b>	Turns off the specified command target.	power -off  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x] -T system:switch[x]  where <i>x</i> is the blade server, I/O-module bay, or network clock module number.
<b>Shutdown and power off blade server</b>	Shuts down the operating system and turns off the specified blade server.	power -softoff  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where <i>x</i> is the blade server number.
<b>Power cycle</b>	Cycles power for the specified blade server or I/O module. If the blade server or I/O module is off, it will turn on. If the blade server or I/O module is on, it will turn off and then turn on.	power -cycle  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x] -T system:switch[x]  where <i>x</i> is the blade server or I/O-module bay number.
<b>Power cycle to command console</b>	Cycles power for the specified blade server. If the blade server is off, it opens a command console with an SOL session when it is turned on. If the blade server is on, it will turn off and then turn on.	power -cycle -c  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where <i>x</i> is the blade server bay number.
<b>Display power state</b>	Displays the current power state for the specified blade server or I/O module. Possible return values are off, on, standby, or hibernate.	power -state	-T system:blade[x] -T system:switch[x]  where <i>x</i> is the blade server or I/O-module bay number.
<b>Enable / disable Wake on LAN globally</b>	Enables or disables Wake on LAN globally for all blade servers.	power -wol <i>state</i>  where <i>state</i> is enabled or disabled.  Command use restricted (see “Commands and user authority” on page 6).	-T system

Table 26. power command (continued)

Function	What it does	Command	Valid targets
<b>Enable / disable Wake on LAN for blade server</b>	Enables or disables Wake on LAN for the specified blade server.	power -wol <i>state</i>  where <i>state</i> is enabled or disabled.  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[ <i>x</i> ]  where <i>x</i> is the blade server bay number.
<b>Enable / disable local power control globally</b>	Enables or disables local power control globally for all blade servers.	power -local <i>state</i>  where <i>state</i> is enabled or disabled.  Command use restricted (see “Commands and user authority” on page 6).	-T system
<b>Enable / disable local power control for blade server</b>	Enables local power control for the specified blade server.	power -local <i>state</i>  where <i>state</i> is enabled or disabled.  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[ <i>x</i> ]  where <i>x</i> is the blade server bay number.
<b>Display fast POST setting for I/O module</b>	Displays the current fast POST setting for specified I/O module. <b>Note:</b> This target works only for some I/O modules.	power	-T system:switch[ <i>x</i> ]  where <i>x</i> is the I/O-module bay number.
<b>Enable / disable fast POST for I/O module</b>	Enables or disables fast POST globally for the specified I/O module. <b>Note:</b> This option works only for some I/O modules.	power -fp <i>state</i>  where <i>state</i> is enabled or disabled.  Command use restricted (see “Commands and user authority” on page 6).	-T system:switch[ <i>x</i> ]  where <i>x</i> is the I/O-module bay number.

Table 26. power command (continued)

Function	What it does	Command	Valid targets
Display POST status for I/O module	<p>Displays the POST status for the specified I/O module. If the command is run while POST is in progress, it returns the level of POST that is currently in process. If the command is run after POST is complete, it displays one of the following return values:</p> <ul style="list-style-type: none"> <li>• The POST results could not be read. message displays if there was an internal error during POST.</li> <li>• The POST results not complete: hex_code message displays if POST results are not available after POST completes.</li> <li>• If POST returns valid results, one of the following messages displays: <ul style="list-style-type: none"> <li>– hex_code: Base internal function failure detected.</li> <li>– hex_code: Internal interface failure detected.</li> <li>– hex_code: External interface failure detected.</li> <li>– hex_code: Module completed POST successfully.</li> <li>– hex_code: Cannot decode POST result code.</li> </ul> </li> <li>• The Invalid POST results. message displays if none of the above conditions is true.</li> </ul> <p>Where <i>hex_code</i> is a hexadecimal code. See the documentation that comes with your I/O module for information.</p> <p><b>Note:</b> This command option is not supported for serial concentrator I/O modules.</p>	power -state -post	<p>-T system:switch[x]</p> <p>where <i>x</i> is the I/O-module bay number.</p>

**Example:**

To display the power state for the blade server in blade bay 5, while this blade server is set as the persistent command environment, at the system:blade[5]> prompt, type

```
power -state
```

To turn on the blade server in blade bay 5, while this blade server is set as the persistent command environment, at the system:blade[5]> prompt, type

```
power -on
```

To display the power state for the blade server in blade bay 5 again, while this blade server is set as the persistent command environment, at the system:blade[5]> prompt, type



```
power -state
```

The following example shows the information that is returned from these three commands:

```
system:blade[5]> power -state  
Off  
system:blade[5]> power -on  
OK  
system:blade[5]> power -state  
On  
system:blade[5]>
```

## reset command

This command resets blade servers, blade server integrated system management processors (service processors), I/O modules, or the primary management module.

Table 27. *reset command*

Function	What it does	Command	Valid targets
<b>Reset</b>	Performs an immediate reset and restart of the specified device.	reset  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x] -T system:switch[x] -T system:blade[x]:sp -T system:mm[x]  where <i>x</i> is the blade server, I/O-module, or primary management-module bay number.
<b>Reset blade server to command console</b>	Opens a command console with an SOL session when the specified blade server is reset.	reset -c  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where <i>x</i> is the blade server bay number.
<b>Reset with failover</b>	Resets the specified command target, enabling failover if a redundant (standby) component for the command target is present.  An error message is displayed if you try to failover a management module when a standby management module is not installed or if the firmware in the one of the management modules is updating.	reset -f  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Reset I/O module with standard diagnostics</b>	Performs an immediate reset and restart of the specified device, running standard diagnostics on the I/O module after it restarts.  Running the reset -std command gives the same result as running the reset command on a I/O module.	reset -std  Command use restricted (see “Commands and user authority” on page 6).	-T system:switch[x]  where <i>x</i> is the I/O-module bay number.
<b>Reset I/O module with extended diagnostics</b>	Performs an immediate reset and restart of the specified device, running extended diagnostics on the I/O module after it restarts.	reset -exd  Command use restricted (see “Commands and user authority” on page 6).	-T system:switch[x]  where <i>x</i> is the I/O-module bay number.
<b>Reset I/O module with full diagnostics</b>	Performs an immediate reset and restart of the specified device, running full diagnostics on the I/O module after it restarts.	reset -full  Command use restricted (see “Commands and user authority” on page 6).	-T system:switch[x]  where <i>x</i> is the I/O-module bay number.

Table 27. reset command (continued)

Function	What it does	Command	Valid targets
<b>Restart blade server with NMI</b>	<p>Performs an immediate reset and restart of the specified blade server. Command results depend on the blade server model that is specified:</p> <ul style="list-style-type: none"> <li>• For a JS12 or JS22 blade server, this option is not available.</li> <li>• For a JS20 blade server, the command performs an immediate reset and restart of the specified blade server with non-maskable interrupt (NMI).</li> <li>• For all other blade servers, the command performs an immediate reset and restart of the specified blade server.</li> </ul>	<p>reset -sft</p> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:blade[x]</p> <p>where <i>x</i> is the blade server bay number.</p>
<b>Restart blade server and clear NVRAM</b>	<p>Performs an immediate reset and restart of the specified blade server. Command results depend on the blade server model that is specified:</p> <ul style="list-style-type: none"> <li>• For a JS12 or JS22 blade server, this option is not available.</li> <li>• For a JS20 blade server, the command performs an immediate reset and restart of the specified JS20 blade server and clears all settings stored in non-volatile memory (NVRAM).</li> <li>• For all other blade servers, the command performs an immediate reset and restart of the specified blade server.</li> </ul>	<p>reset -clr</p> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:blade[x]</p> <p>where <i>x</i> is the blade server bay number.</p>
<b>Restart blade server and run diagnostics</b>	<p>Performs an immediate reset and restart of the specified blade server. Command results depend on the blade server model that is specified:</p> <ul style="list-style-type: none"> <li>• For a JS12 or JS22 blade server, this option is not available.</li> <li>• For a JS20 blade server, the command performs an immediate reset and restart of the specified JS20 blade server and runs diagnostics.</li> <li>• For all other blade servers, the command performs an immediate reset and restart of the specified blade server.</li> </ul>	<p>reset -dg</p> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:blade[x]</p> <p>where <i>x</i> is the blade server bay number.</p>

Table 27. reset command (continued)

Function	What it does	Command	Valid targets
Restart blade server and run diagnostics using default boot sequence	<p>Performs an immediate reset and restart of the specified blade server. Command results depend on the blade server model that is specified:</p> <ul style="list-style-type: none"> <li>• For a JS12 or JS22 blade server, this option is not available.</li> <li>• For a JS20 blade server, the command performs an immediate reset and restart of the specified JS20 blade server and runs diagnostics using the default boot sequence configured for the blade server.</li> <li>• For all other blade servers, the command performs an immediate reset and restart of the specified blade server.</li> </ul>	<p>reset -ddg</p> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:blade[x]</p> <p>where <i>x</i> is the blade server bay number.</p>

**Example:** To reset the service processor on the blade server in blade bay 5, while the BladeCenter unit is set as the persistent command environment, at the system> prompt, type

```
reset
```

The following example shows the information that is returned:

```
system> reset -T blade[5]:sp
OK
system>
```

## shutdown command

This command forces a blade server to shut down.

Table 28. shutdown command

Function	What it does	Command	Valid targets
Shutdown blade server	Forces a shutdown for the specified blade server.	shutdown -f  Command use restricted (see “Commands and user authority” on page 6).	-T system:blade[x]  where <i>x</i> is the blade server bay number.

### Example:

To force a shutdown for the blade server in blade bay 5, while this blade server is set as the persistent command environment, at the system:blade[5]> prompt, type  
shutdown -f

The following example shows the information that is returned from this command:

```
system:blade[5]> shutdown -f
OK
system:blade[5]>
```

## slp command

This command sets and displays the service location protocol (SLP) settings for the management module.

Table 29. *slp command*

Function	What it does	Command	Valid targets
<b>Display management-module SLP settings</b>	Displays the SLP settings for the primary management module. Returned values are: <ul style="list-style-type: none"><li>• <i>-t address_type</i></li><li>• <i>-i multicast_addr</i></li></ul>	<code>slp</code>	<code>-T system:mm[x]</code> where <i>x</i> is the primary management-module bay number.
<b>Set management-module SLP address type</b>	Sets the SLP address type for the primary management module.	<code>slp -t address_type</code>  where <i>address_type</i> is multicast or broadcast.  Command use restricted (see “Commands and user authority” on page 6).	<code>-T system:mm[x]</code>  where <i>x</i> is the primary management-module bay number.
<b>Set management-module SLP multicast address</b>	Sets the SLP multicast address for the primary management module.	<code>slp -i multicast_addr</code>  where <i>multicast_addr</i> is the multicast IP address.  Command use restricted (see “Commands and user authority” on page 6).	<code>-T system:mm[x]</code>  where <i>x</i> is the primary management-module bay number.

### Example:

To set the SLP address type of the management module to multicast, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
slp -t multicast
```

To display the SLP settings of the management module, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
slp
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> slp -t multicast
OK
system:mm[1]> slp
-t multicast
-i 255.255.255.255
system:mm[1]>
```

## smtp command

This command configures and displays the management-module SMTP settings.

Table 30. *smtp* command

Function	What it does	Command	Valid targets
Display SMTP server host name or IP address	Displays the SMTP server host name or IP address.	smtp	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Server host name or IP address - set	Checks syntax and sets the server host name or IP address.	smtp -s <i>hostname/ip_address</i>  where <i>hostname/ip_address</i> is the host name or IP address of the server.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

### Example:

To set the SMTP server host name to us.ibm.com, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type  
smtp -s us.ibm.com

To display the SMTP configuration, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type  
smtp

The following example shows the information that is returned from these two commands:

```
system:mm[1]> smtp -s us.ibm.com
OK
system:mm[1]> smtp
-s us.ibm.com
system:mm[1]>
```

## snmp command

This command configures and displays the management-module SNMP settings.

Table 31. snmp command

Function	What it does	Command	Valid targets
<b>Display SNMP configuration of management module</b>	Displays the current SNMP configuration of the management module.	snmp	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>SNMPv1 agent - enable/disable</b>	Enables or disables the management-module SNMPv1 agent.	snmp -a <i>-state</i> where <i>state</i> is on or off. Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>SNMPv3 agent - enable/disable</b>	Enables or disables the management-module SNMPv3 agent.	snmp -a3 <i>-state</i> where <i>state</i> is on or off. Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>SNMP traps - enable/disable</b>	Enables or disables the management-module SNMP traps.	snmp -t <i>-state</i> where <i>state</i> is on or off. Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>SNMP community 1 name - set</b>	Sets the name of community 1.	snmp -c1 <i>name</i> where <i>name</i> is a descriptive name of community 1. <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the snmp command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.



Table 31. snmp command (continued)

Function	What it does	Command	Valid targets
SNMP Community 1, first host name - set access to SET (wildcard)	Sets the access type for community 1 to SET.	<pre>snmp -ca1 set -cli1 0.0.0.0</pre> <ul style="list-style-type: none"> <li>• With the access type of SET, anyone can query the management information base (MIB) and set MIB values. Using 0.0.0.0 IP address with SET access allows open access to the management module for write (SET) operations. A 0.0.0.0 address cannot be a trap receiver.</li> <li>• Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>• If this argument is not specified, the snmp command clears this option.</li> <li>• You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Table 31. snmp command (continued)

Function	What it does	Command	Valid targets
<b>SNMP Community 1, first host name or IP address - set access to GET (wildcard)</b>	Sets the access type for community 1 to GET.	<pre>snmp -ca1 get -cli1 0.0.0.0</pre> <ul style="list-style-type: none"> <li>With the access type of GET, anyone can query the MIB. Using 0.0.0.0 IP address with GET access allows open access to the management module for read (GET). A 0.0.0.0 address cannot be a trap receiver.</li> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the snmp command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
<b>SNMP community 1 second host name or IP address - set</b>	Checks syntax and sets the second host name or IP address of community 1.	<pre>snmp -cli2 hostname/ip_address</pre> <p>where <i>hostname/ip_address</i> is the second host name or IP address of community 1.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the snmp command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Table 31. *snmp* command (continued)

Function	What it does	Command	Valid targets
<b>SNMP community 1 third host name or IP address - set</b>	Checks syntax and sets the third host name or IP address of community 1.	<p><code>snmp -c1i3 <i>hostname/ip_address</i></code></p> <p>where <i>hostname/ip_address</i> is the third host name or IP address of community 1.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the <code>snmp</code> command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>SNMPv3 community 1 view type - set</b>	Sets the SNMPv3 view type for community 1.	<p><code>snmp -ca1 <i>type</i></code></p> <p>where <i>type</i> is</p> <ul style="list-style-type: none"> <li>get</li> <li>set</li> <li>trap</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>SNMP community 2 name - set</b>	Sets the name of community 2.	<p><code>snmp -c2 <i>name</i></code></p> <p>where <i>name</i> is a descriptive name of community 2.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the <code>snmp</code> command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 31. snmp command (continued)

Function	What it does	Command	Valid targets
<b>SNMP community 2 first host name or IP address - set</b>	Checks syntax and sets the first host name or IP address of community 2.	<p>snmp -c2i1 <i>hostname/ip_address</i></p> <p>where <i>hostname/ip_address</i> is the first host name or IP address of community 2.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the snmp command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>SNMP community 2 second host name or IP address - set</b>	Checks syntax and sets the second host name or IP address of community 2.	<p>snmp -c2i2 <i>hostname/ip_address</i></p> <p>where <i>hostname/ip_address</i> is the second host name or IP address of community 2.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the snmp command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 31. *snmp* command (continued)

Function	What it does	Command	Valid targets
<b>SNMP community 2 third host name or IP address - set</b>	Checks syntax and sets the third host name or IP address of community 2.	<p><code>snmp -c2i3 hostname/ip_address</code></p> <p>where <i>hostname/ip_address</i> is the third host name or IP address of community 2.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the <code>snmp</code> command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>SNMPv3 community 2 view type - set</b>	Sets the SNMPv3 view type for community 2.	<p><code>snmp -ca2 type</code></p> <p>where <i>type</i> is</p> <ul style="list-style-type: none"> <li>get</li> <li>set</li> <li>trap</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>SNMP community 3 name - set</b>	Sets the name of community 3.	<p><code>snmp -c3 name</code></p> <p>where <i>name</i> is a descriptive name of community 3.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the <code>snmp</code> command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 31. snmp command (continued)

Function	What it does	Command	Valid targets
<b>SNMP community 3 first host name or IP address - set</b>	Checks syntax and sets the first host name or IP address of community 3.	<p>snmp -c3i1 <i>hostname/ip_address</i></p> <p>where <i>hostname/ip_address</i> is the first host name or IP address of community 3.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the snmp command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
<b>SNMP community 3 second host name or IP address - set</b>	Checks syntax and sets the second host name or IP address of community 3.	<p>snmp -c3i2 <i>hostname/ip_address</i></p> <p>where <i>hostname/ip_address</i> is the second host name or IP address of community 3.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the snmp command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

Table 31. *snmp* command (continued)

Function	What it does	Command	Valid targets
<b>SNMP community 3 third host name or IP address - set</b>	Checks syntax and sets the third host name or IP address of community 3.	<p><code>snmp -c3i3 <i>hostname/ip_address</i></code></p> <p>where <i>hostname/ip_address</i> is the third host name or IP address of community 3.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the <code>snmp</code> command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>SNMPv3 community 3 view type - set</b>	Sets the SNMPv3 view type for community 3.	<p><code>snmp -ca3 <i>type</i></code></p> <p>where <i>type</i> is</p> <ul style="list-style-type: none"> <li>get</li> <li>set</li> <li>trap</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>SNMP contact name - set</b>	Sets the contact name.	<p><code>snmp -cn <i>contact_name</i></code></p> <p>where <i>contact_name</i> is the name of the party to be contacted when SNMP traps an event.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the <code>snmp</code> command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 31. snmp command (continued)

Function	What it does	Command	Valid targets
SNMP location - set	Sets the location.	<p>snmp -l <i>hostname/ip_address</i></p> <p>where <i>hostname/ip_address</i> identifies the web site supporting SNMP for this management module.</p> <ul style="list-style-type: none"> <li>Arguments containing spaces must be enclosed in quotation marks. No leading or trailing spaces are allowed in arguments.</li> <li>If this argument is not specified, the snmp command clears this option.</li> <li>You can also clear this option by assigning an empty string as its value.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

**Example:** To view the SNMP configuration, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
snmp
```

To enable the SNMP agent and SNMP traps, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
snmp -a -on -t -on
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> snmp
-a Disabled
-t Disabled
-l No Location Configured
-cn No Contact Configured
-c1 com1
-c1i1 1.2.3.4
-c1i2
-c1i3
-c2 com2
-c2i1 1.2.3.4
-c2i2
-c2i3
-c3
-c3i1
-c3i2
-c3i3
system:mm[1]> snmp -a -on -t -on
Changes to the network settings will take effect after the next reset of the MM.
system:mm[1]>
```



## sol (serial over LAN) command

This command configures SOL functions and indicates SOL status.

Table 32. sol (serial over LAN) command

Function	What it does	Command	Valid targets
Display SOL status	<p>Displays the SOL status for the targeted device:</p> <ul style="list-style-type: none"> <li>When the command target is the primary management module, it displays the following values: <ul style="list-style-type: none"> <li>-status <i>on/off</i> (global SOL status)</li> <li>-c <i>retry_count</i></li> <li>-e <i>CLI_key_sequence</i></li> <li>-i <i>retry_interval</i></li> <li>-r <i>reset_blade_key_seq</i></li> <li>-s <i>send_threshold</i></li> <li>-t <i>accumulate_timeout</i></li> <li>-v <i>VLAN_id</i></li> </ul> </li> </ul> <p><b>Note:</b> The <i>VLAN_id</i> is identified by the "-v" value that is returned.</p> <ul style="list-style-type: none"> <li>When the command target is a blade server, it displays the following: <ul style="list-style-type: none"> <li>-status <i>on/off</i> (SOL status for the blade server)</li> <li>Status of any SOL sessions for that blade server: <ul style="list-style-type: none"> <li>- There is no SOL session opening for that blade.</li> <li>- There is an SOL session opening for that blade.</li> <li>- There is an SOL session opening and it is connected to a Telnet session.</li> </ul> </li> </ul> </li> </ul>	sol	<p>-T system:mm[x] -T system:blade[x]</p> <p>where <i>x</i> is the primary management-module or blade server bay number.</p>
SOL retry interval - set	Sets the SOL retry interval to the input value.	<p>sol -i <i>value</i></p> <p>where <i>value</i> is from 10 ms to 2550 ms, inclusive, in 10 ms increments. If you enter a value less than 10 ms, the retry interval will be set to 10 ms. If you enter a value greater than 2550 ms, the retry interval will be set to 2550 ms.</p> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 32. sol (serial over LAN) command (continued)

Function	What it does	Command	Valid targets
<b>SOL retry count - set</b>	Sets the SOL retry count to the input value.	sol -c <i>value</i>  where <i>value</i> is from 0 to 7, inclusive. If you enter a value of 0, no retries will be attempted. If you enter a value greater than 7, an error will be displayed.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>SOL send threshold - set</b>	Sets the SOL send threshold to the input value. Setting the threshold value to 1 causes the blade server integrated system management processor to send an SOL packet as soon as the first character is received.	sol -s <i>value</i>  where <i>value</i> is from 1 to 251, inclusive. If you enter a value outside this range, an error will be displayed.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>SOL accumulate timeout - set</b>	Sets the SOL accumulate timeout to the input value.	sol -t <i>value</i>  where <i>value</i> is from 5 ms to 1275 ms, inclusive. If you enter a value less than 5 ms, the accumulate timeout will be set to 5 ms. If you enter a value greater than 1275 ms, an error will be displayed.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>SOL enable - global</b>	Enables SOL globally for the BladeCenter unit. The global SOL enable command does not affect the SOL session status for each blade server.	sol -status on  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>SOL enable - blade server</b>	Enables SOL for the specified blade server.	sol -status on  Command use restricted (see "Commands and user authority" on page 6).	-T system:blade[x]  where <i>x</i> is the blade server bay number.
<b>SOL disable - global</b>	Disables SOL globally for the BladeCenter unit. The global SOL disable command does not affect the SOL session status for each blade server.	sol -status off  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>SOL disable - blade server</b>	Disables SOL for the specified blade server.	sol -status off  Command use restricted (see "Commands and user authority" on page 6).	-T system:blade[x]  where <i>x</i> is the blade server bay number.

Table 32. sol (serial over LAN) command (continued)

Function	What it does	Command	Valid targets
<b>SOL VLAN ID - set</b>	Sets the SOL VLAN ID to the input value.	sol -v <i>value</i>  where <i>value</i> is from 1 to 4095, inclusive. If you enter a value outside this range, an error will be displayed.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>CLI key sequence - set</b>	Sets the key sequence that is used to enter the CLI while a Telnet session in SOL mode.	sol -e <i>value</i>  where <i>value</i> is the key sequence. In this sequence, a ^ (the carat symbol) indicates a Ctrl that maps to control-key sequences; for example: <ul style="list-style-type: none"> <li>• ^[ (the carat symbol followed by a left bracket) means Esc</li> <li>• ^M (the carat symbol followed by a capitol M) means carriage return.</li> </ul> Refer to an ASCII-to-key conversion table for a complete listing of control-key sequences.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.
<b>Reset blade server key sequence - set</b>	Sets the key sequence that will reset a blade server while a Telnet session in SOL mode.	sol -r <i>value</i>  where <i>value</i> is the key sequence. In this sequence, a ^ (the carat symbol) indicates a Ctrl that maps to control-key sequences; for example: <ul style="list-style-type: none"> <li>• ^[ (the carat symbol followed by a left bracket) means Esc</li> <li>• ^M (the carat symbol followed by a capitol M) means carriage return.</li> </ul> Refer to an ASCII-to-key conversion table for a complete listing of control-key sequences.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x]  where <i>x</i> is the primary management-module bay number.

**Example:**

To set the SOL accumulate timeout to 25 ms, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
sol -t 25
```

To set the reset blade server key sequence to Esc R Esc r Esc R, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
sol -r ^[R^[r^[R
```

To display the SOL settings for the management module, while the management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
sol
```

To display the SOL settings for the server blade in the third bay, while blade 3 is set as the persistent command environment, at the `system:blade[3]>` prompt, type

```
sol
```

The following example shows the information that is returned from these commands:

```
system:mm[1]> sol -t 25
OK
system:mm[1]> sol
-status enabled
-c 3
-e ^[(
-i 250
-r ^[R^[r^[R
-s 250
-t 5
VLAN ID 4095
system:mm[1]>
system:blade[3]> sol
-status enabled
SOL Session: Not Ready
SOL retry interval: 250 ms
SOL retry count: 3
SOL bytes sent: 0
SOL bytes received: 0
SOL destination IP address: 10.10.10.80
SOL destination MAC: 00:00:00:00:00:00
SOL I/O module slot number: 0
SOL console user ID:
SOL console login from:
SOL console session started:
SOL console session stopped:
Blade power state: On
SOL recommended action: Internal network path between the AMM and this
blade server is currently not available. Please refer to AMM user guide for
troubleshooting information.
system:blade[3]>
```

## tcpcmdmode command

This command displays and changes the timeout of the TCP command-mode sessions that are used by IBM Director software for out-of-band communication with the management module. This command is also used to enable or disable the TCP command-mode sessions.

Table 33. *tcpcmdmode* command

Function	What it does	Command	Valid targets
<b>Display TCP command-mode session status and timeout</b>	Displays the TCP command-mode session status (on or off) and timeout.	tcpcmdmode	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Set TCP command-mode session timeout</b>	Sets the TCP command-mode session timeout value.	tcpcmdmode -t <i>timeout</i>  where <i>timeout</i> is from 0 seconds (no timeout) to 4294967295 seconds, inclusive. If you enter a value outside this range, an error will be displayed.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Enable / disable TCP command-mode sessions</b>	Enables or disables TCP command-mode sessions that are used by IBM Director software for out-of-band communication with the management module.	tcpcmdmode -status <i>state</i> where <i>state</i> is on or off.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

**Example:** To enable a TCP command-mode session for the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
tcpcmdmode -status on
```

To set the TCP command-mode session timeout for the primary management module to 6 minutes, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
tcpcmdmode -t 360
```

To display the TCP command-mode session status and timeout for the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
tcpcmdmode
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> tcpcmdmode -status on
OK
system:mm[1]> tcpcmdmode -t 360
OK
system:mm[1]> tcpcmdmode
-status on
-t 360
system:mm[1]>
```

## telnetcfg (Telnet configuration) command

This command displays and configures the command-line session parameters of the primary management module.

Table 34. *telnetcfg* (Telnet configuration) command

Function	What it does	Command	Valid targets
Display command-line session configuration	Displays the command-line session configuration of the primary management module.	telnetcfg	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
Set command-line session timeout for primary management module	Sets the command-line session timeout value for the primary management module.	telnetcfg -t <i>timeout</i>  where <i>timeout</i> is from 0 seconds (no timeout) to 4294967295 seconds, inclusive. If you enter a value outside this range, an error will be displayed.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

**Example:** To set the command-line session timeout for the primary management module to 6 minutes, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
telnetcfg -t 360
```

To display the command-line session configuration for the primary management module, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
telnetcfg
```

The following example shows the information that is returned from these two commands:

```
system:mm[1]> telnetcfg -t 360
OK
system:mm[1]> telnetcfg
-t 360
system:mm[1]>
```

## update (update firmware) command

This command updates firmware using a Trivial File Transfer Protocol (TFTP) server and displays information about firmware installed in BladeCenter components.

Table 35. update (update firmware) command

Function	What it does	Command	Valid targets
<b>Display firmware attributes</b>	<p>Displays attributes of the firmware installed in the command target. Return values are:</p> <ul style="list-style-type: none"> <li>• Firmware type</li> <li>• Build ID</li> <li>• Filename</li> <li>• Release date</li> <li>• Revision level</li> </ul> <p><b>Notes:</b></p> <ul style="list-style-type: none"> <li>• When the command target is the primary management module, this command will return the values for the currently active firmware and for the pending firmware, that will become active after the next management module reboot.</li> <li>• For I/O modules that support it, this command will also display firmware image information.</li> </ul>	update -a	<p>-T system:mm[x] -T system:blade[x]:sp -T system:switch[x]</p> <p>where <i>x</i> is the primary management-module, blade server, or I/O module bay number.</p>
<b>Update firmware</b>	<p>Update firmware for the command target.</p> <p><b>Important:</b> Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware.</p> <p><b>Note:</b> The P6 blade server firmware is too large to be updated using this command. See the <i>User's Guide</i> for your P6 blade server for information about updating firmware.</p>	<p>update -i <i>ip_address</i> -l <i>filename</i></p> <p>where:</p> <ul style="list-style-type: none"> <li>• <i>ip_address</i> is the IP address of TFTP server.</li> <li>• <i>filename</i> is the path name of the of the firmware update file.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x] -T system:blade[x]:sp -T system:switch[x]</p> <p>where <i>x</i> is the primary management-module, blade server, or I/O module bay number.</p>



Table 35. update (update firmware) command (continued)

Function	What it does	Command	Valid targets
<b>Update firmware (verbose)</b>	<p>Update firmware for the command target, showing details of the firmware download and flash operations. The detailed information is not shown until the update is complete, which might take several minutes.</p> <p><b>Important:</b> Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware.</p> <p><b>Note:</b> The P6 blade server firmware is too large to be updated using this command. See the <i>User's Guide</i> for your P6 blade server for information about updating firmware.</p>	<pre>update -i ip_address -l filename -v</pre> <p>where:</p> <ul style="list-style-type: none"> <li>• <i>ip_address</i> is the IP address of TFTP server.</li> <li>• <i>filename</i> is the path name of the of the firmware update file.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<pre>-T system:mm[x] -T system:blade[x]:sp -T system:switch[x]</pre> <p>where <i>x</i> is the primary management-module, blade server, or I/O module bay number.</p>

**Example:** To update the firmware and display update details for the management module in management-module bay 1, while this management module is set as the persistent command environment, type the following command at the `system:mm[1]>` prompt. For this example, the IP address of the TFTP server is 192.168.70.120 and the firmware file containing the update is named `dev_mm.pkt`.

```
update -v -i 192.168.70.120 -l dev_mm.pkt
```

To display information about firmware installed in the management module in management-module bay 1, while this management module is set as the persistent command environment, at the `system:mm[1]>` prompt, type

```
update -a
```

To update the service-processor firmware in the blade server in blade bay 8 (not using verbose mode), while the management module in management-module bay 1 is set as the persistent command environment, type the following command at the `system:mm[1]>` prompt. For this example, the IP address of the TFTP server is 192.168.70.120 and the firmware file containing the update is named `h8.pkt`.

```
update -i 192.168.70.120 -l h8.pkt -T system:blade[8]:sp
```

The following example shows the information that is returned from these three update commands:

```
system:mm[1]> update -v -i 192.168.70.120 -l dev_mm.pkt
TFTP file upload successful 1517829.
Starting flash packet preparation.
Flash preparation - packet percent complete 24.
Flash preparation - packet percent complete 48.
Flash preparation - packet percent complete 72.
Flash preparation - packet percent complete 96.
Flash preparation - packet percent complete 100.
Flash operation phase starting.
Flashing - packet percent complete 34.
Flashing - packet percent complete 38.
Flashing - packet percent complete 50.
Flashing - packet percent complete 55.
Flashing - packet percent complete 80.
```

```
Flashing - packet percent complete 90.  
Flash operation complete. The new firmware will become active after the next  
reset of the MM.  
OK  
system:mm[1]> update -a  
Bay 1 Name 1  
Firmware type: Main application  
Build ID: BRETkd+  
Filename: CNETMNUS.PKT  
Released: 11-17-03  
Revision: 16  
Firmware type: Boot ROM  
Build ID: BRBR1B+  
Filename: CNETBRUS.PKT  
Released: 10-27-03  
Revision: 16  
Firmware type: Remote control  
Build ID: BRRG1B+  
Filename: CNETRGUS.PKT  
Released: 10-27-03  
Revision: 16  
OK  
system:mm[1]> update -i 192.168.70.120 -l h8.pkt -T system:blade[8]:sp  
OK  
system:mm[1]>
```

## uplink (management module failover) command

This command displays and configures the management-module uplink failover feature. If the physical external network interface of the primary management module fails, this feature forces a failover to the standby management module, if one is installed.

Table 36. uplink command

Function	What it does	Command	Valid targets
<b>Display uplink failover status</b>	Displays the management-module uplink failover status (enabled or disabled) and the failover delay.	uplink	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Set physical network uplink failover delay</b>	Sets the amount of time between detection of a management-module physical uplink failure and failover to the standby management module.	uplink -del <i>delay</i>  where <i>delay</i> is from 1 to 255 minutes, inclusive. If you enter a value outside this range, an error will be displayed.  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Enable physical uplink failover</b>	Enables failover to the standby management module if the external physical network interface of the primary management module fails.	uplink -on  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Disable physical uplink failover</b>	Disables failover to the standby management module if the external physical network interface of the primary management module fails.	uplink -off  Command use restricted (see “Commands and user authority” on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

**Example:** To enable failover to the standby management module if the external network interface of the primary management module fails, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
uplink -on
```

To set the uplink failover delay to 3 minutes, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
uplink -del 3
```

To display the uplink failover configuration, while management module 1 is set as the persistent command environment, at the `system:mm[1]>` prompt, type `uplink`

The following example shows the information that is returned from these three commands:

```
system:mm[1]> uplink -on
OK
system:mm[1]> uplink -del 3
Uplink delay set to 3 minute(s).
OK
system:mm[1]> uplink
Failover on network uplink loss is enabled.
Uplink delay: 3 minute(s)
system:mm[1]>
```

## users command

This command displays and configures user accounts, also called user profiles, of the primary management module.

**Important:** Command authority definitions might change between firmware versions. Make sure that the command authority level set for each user is correct after updating management-module firmware.

Table 37. *users (management-module users) command*

Function	What it does	Command	Valid targets
<b>Display all user profiles</b>	Displays all 12 management-module user profiles. Returned values are: <ul style="list-style-type: none"> <li>• User name</li> <li>• Authority level</li> </ul>	users	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Display single user profile</b>	Displays the specified management-module user profile. Returned values are: <ul style="list-style-type: none"> <li>• User name</li> <li>• Authority level</li> <li>• Context name</li> <li>• Authentication protocol</li> <li>• Privacy protocol</li> <li>• Access type</li> <li>• Hostname/IP address</li> </ul>	users - <i>user_number</i> where <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.	-T system:mm[x] where <i>x</i> is the primary management-module bay number.
<b>Delete user profile</b>	Delete the specified management-module user profile.	users - <i>user_number</i> -clear where <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list. It is possible to delete an empty user profile.  Command use restricted (see "Commands and user authority" on page 6).	-T system:mm[x] where <i>x</i> is the primary management-module bay number.

Table 37. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
<b>Create user profile</b>	<p>Create the specified management-module user profile.</p> <p>All fields must be specified when creating a user profile for the BladeCenter T management module.</p> <p>For management modules other than those installed in a BladeCenter T unit, only the following user-profile fields are required:</p> <ul style="list-style-type: none"> <li>• <i>-user_number</i></li> <li>• <i>-n user_name</i></li> <li>• <i>-a user_authority</i></li> <li>• <i>-p user_password</i></li> </ul>	<pre>users -user_number -n user_name -p user_password -a user_authority -cn context_name -ap auth_protocol -pp privacy_protocol -ppw privacy_pwd -at access_type -i ip_addr/hostname</pre> <p>where:</p> <ul style="list-style-type: none"> <li>• <i>user_number</i> is a number from 1 to 12 that corresponds to an unused user number in the "Display all user profiles" list.</li> <li>• <i>user_name</i> is a alphanumeric string up to 15 characters in length that can include periods ( . ) and underscores ( _ ). Each of the 12 user names must be unique.</li> <li>• <i>user_password</i> can be blank or an alphanumeric string up to 15 characters in length that can include periods ( . ) and underscores ( _ ), and must include at least one alphabetic and one non-alphabetic character.</li> <li>• <i>user_authority</i> is one of the following: <ul style="list-style-type: none"> <li>– operator (read-only)</li> <li>– rbs (see Set user authority level for more information)</li> </ul> </li> <li>• <i>context_name</i> is a string for SNMPv3 context that is up to 31 characters in length. Each of the 12 context names must be unique.</li> </ul> <p>(continued on next page)</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 37. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
<p>Create user profile (continued)</p>		<ul style="list-style-type: none"> <li>• <i>auth_protocol</i> is an SNMPv3 authentication protocol of               <ul style="list-style-type: none"> <li>– sha</li> <li>– md5</li> <li>– blank (no entry) for none</li> </ul> </li> <li>• <i>privacy_protocol</i> is an SNMPv3 privacy protocol of des or blank (no entry) for none. If the privacy protocol is set to none, no -ppw command option (privacy password) is required.</li> <li>• <i>privacy_pwd</i> is an SNMPv3 privacy password string of up to 31 characters in length. If the privacy protocol is set to none, the -ppw command option does not need to be used unless a privacy password is required.</li> <li>• <i>access_type</i> is an SNMPv3 access type of               <ul style="list-style-type: none"> <li>– read</li> <li>– write</li> <li>– traps</li> </ul> </li> <li>• <i>ip_addr/hostname</i> is a valid SNMPv3 static IP address or an alphanumeric hostname string up to 63 characters in length.</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	

Table 37. *users* (management-module users) command (continued)

Function	What it does	Command	Valid targets
<b>Set user name</b>	Sets a user name in the specified management-module user profile.	<p><code>users -user_number -n user_name</code></p> <p>where:</p> <ul style="list-style-type: none"> <li><code>user_number</code> is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.</li> <li><code>user_name</code> is a alphanumeric string up to 15 characters in length that can include periods ( . ) and underscores ( _ ). Each of the 12 user names must be unique.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>Set user password</b>	Sets a user password in the specified management-module user profile.	<p><code>users -user_number -p user_password</code></p> <p>where:</p> <ul style="list-style-type: none"> <li><code>user_number</code> is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.</li> <li><code>user_password</code> can be blank or an alphanumeric string up to 15 characters in length that can include periods ( . ) and underscores ( _ ), and must include at least one alphabetic and one non-alphabetic character.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>



Table 37. *users* (management-module users) command (continued)

Function	What it does	Command	Valid targets
Set user authority level	Sets a user authority level in the specified management-module user profile.	<p><code>users -user_number -a user_authority</code></p> <p>where:</p> <ul style="list-style-type: none"> <li>• <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.</li> <li>• <i>user_authority</i> is <ul style="list-style-type: none"> <li>– operator (read-only)</li> <li>– rbs (custom)</li> </ul> </li> </ul> <p>The custom authority level parameter is specified using the following syntax:</p> <p><code>rbs:levels:devices</code></p> <p>where the <i>levels</i> are one or more of the following authority levels, separated by a vertical bar (   ): <ul style="list-style-type: none"> <li>• super (Supervisor)</li> <li>• cam (Chassis User Account Management)</li> <li>• c1m (Chassis Log Management)</li> <li>• co (Chassis Operator)</li> <li>• cc (Chassis Configuration)</li> <li>• ca (Chassis Administration)</li> <li>• bo (Blade Operator)</li> <li>• brp (Blade Remote Present)</li> <li>• bc (Blade Configuration)</li> <li>• ba (Blade Administration)</li> <li>• so (I/O Module Operator)</li> <li>• sc (I/O Module Configuration)</li> <li>• sa (I/O Module Administration)</li> </ul> </p> <p>(continued on next page)</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 37. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
<p><b>Set user authority level</b> (continued)</p>		<p>where the <i>devices</i> are one or more of the following devices, separated by a vertical bar (   ). Ranges of devices are separated by a dash ( - ).</p> <ul style="list-style-type: none"> <li>• <i>cn</i> (Chassis <i>n</i>, where <i>n</i> is a valid chassis number. Use c1 for single-chassis environments.)</li> <li>• <i>bn</i> (Blade <i>n</i>, where <i>n</i> is a valid blade bay number in the chassis)</li> <li>• <i>sn</i> (I/O module <i>n</i>, where <i>n</i> is a valid I/O module bay number in the chassis)</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	
<p><b>Set SNMPv3 user context name</b></p>	<p>Sets an SNMPv3 context name in the specified management-module user profile.</p> <p>The context name defines the context the SNMPv3 user is working in. A context name can be shared by multiple users.</p>	<p>users -<i>user_number</i> -cn <i>context_name</i></p> <p>where:</p> <ul style="list-style-type: none"> <li>• <i>user_number</i> is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.</li> <li>• <i>context_name</i> is a string up to 31 characters in length. Each of the 12 context names must be unique.</li> </ul> <p>Command use restricted (see “Commands and user authority” on page 6).</p>	<p>-T system:mm[<i>x</i>]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 37. *users* (management-module *users*) command (continued)

Function	What it does	Command	Valid targets
<b>Set SNMPv3 user authentication protocol</b>	Sets the SNMPv3 authentication protocol to be used for the specified management-module user profile.	<p><code>users -user_number -ap auth_protocol</code></p> <p>where:</p> <ul style="list-style-type: none"> <li><code>user_number</code> is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.</li> <li><code>auth_protocol</code> is <ul style="list-style-type: none"> <li>- sha,</li> <li>- md5</li> <li>- blank (no entry) for none</li> </ul> </li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>Set SNMPv3 user privacy protocol</b>	<p>Sets the SNMPv3 privacy protocol to be used for the specified management-module user profile.</p> <p>If the privacy protocol is set to none, no -ppw command option (privacy password) is required.</p>	<p><code>users -user_number -pp privacy_protocol</code></p> <p>where:</p> <ul style="list-style-type: none"> <li><code>user_number</code> is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.</li> <li><code>privacy_protocol</code> is des or blank (no entry) for none.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>
<b>Set privacy password for SNMPv3 user</b>	Sets an SNMPv3 privacy password in the specified management-module user profile.	<p><code>users -user_number -ppw privacy_pwd</code></p> <p>where:</p> <ul style="list-style-type: none"> <li><code>user_number</code> is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.</li> <li><code>privacy_pwd</code> is a string up to 31 characters in length.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where <i>x</i> is the primary management-module bay number.</p>

Table 37. users (management-module users) command (continued)

Function	What it does	Command	Valid targets
<b>Set access type for SNMPv3 user</b>	<p>Sets an SNMPv3 access type for the specified management-module user profile.</p> <p>This command supports the following access types:</p> <ul style="list-style-type: none"> <li>• read: the user can query Management Information Base (MIB) objects and receive traps.</li> <li>• write: the user can query and set MIB objects and receive traps.</li> <li>• traps: the user can only receive traps.</li> </ul>	<p>users -user_number -at access_type</p> <p>where:</p> <ul style="list-style-type: none"> <li>• user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.</li> <li>• access_type is <ul style="list-style-type: none"> <li>- read</li> <li>- write</li> <li>- traps</li> </ul> </li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>
<b>Set IP address or hostname for SNMPv3 trap receiver</b>	<p>Sets the IP address or hostname that will receive SNMPv3 traps for the specified management-module user profile.</p>	<p>users -user_number -i ip_addr/hostname</p> <p>where:</p> <ul style="list-style-type: none"> <li>• user_number is a number from 1 to 12 that corresponds to the user number assigned in the "Display all user profiles" list.</li> <li>• ip_addr/hostname is a valid static IP address or an alphanumeric hostname string up to 63 characters in length.</li> </ul> <p>Command use restricted (see "Commands and user authority" on page 6).</p>	<p>-T system:mm[x]</p> <p>where x is the primary management-module bay number.</p>

**Example:** To create user number 3 with a user name of user3 who has supervisor rights to all BladeCenter components, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
users -3 -n user3 -p passw0rd -a rbs:super:c1|b1-b14|s1-s4 -cn joe -ap md5 -pp des -ppw passw0rd -at read -I 192.168.70.129
```

**Note:** The entry beginning with users -3 -n... is shown with a line break after -pp des. When this command is entered, the entire entry must all be on one line.

To set the command authority for an existing user number 4 to Blade Operator for blade 1, blade 2, and blade 3 and Chassis Log Management, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

```
users -4 -rbs:bo|c|m:b1-b3|c1
```

To display all users, while management module 1 is set as the persistent command environment, at the system:mm[1]> prompt, type

users

The following example shows the information that is returned from these two commands:

```
system:mm[1]> users -3 -n user3 -p passwd -a rbs:super:c1|b1-b14|s1-s4
-cn joe -ap md5 -pp des -ppw passwd -at read -I 192.168.70.129
OK
system:mm[1]> users -4 -rbs:bo|c1m:b1-b3|c1
OK
system:mm[1]> users
1. USERID
   Role:supervisor
   Blades:1|2|3|4|5|6|7|8|9|10|11|12|13|14
   Chassis:1
   Switches:1|2|3|4
2. <not used>
3. user3
   Role:supervisor
   Blades:1|2|3|4|5|6|7|8|9|10|11|12|13|14
   Chassis:1
   Switches:1|2|3|4
4. user4
   Role:blade operator|chassis log management
   Blades:1|2|3
   Chassis:1
   Switches:N/A
5. <not used>
6. <not used>
7. <not used>
8. <not used>
9. <not used>
10. <not used>
11. <not used>
12. <not used>
system:mm[1]>
```

**Note:** The entry beginning with users -3 -n... is shown with a line break after -a rbs:super:c1|b1-b14|s1-s4. When this command is entered, the entire entry must all be on one line.



---

## Chapter 4. Error messages

This topic lists error messages for the BladeCenter command-line interface.

The command-line interface provides error messages specific to each command. The following topics list the common error messages that apply to all commands and command-specific error messages, along with their definitions.

- “Common errors” on page 114
- “alarm command errors” on page 116
- “alertentries command errors” on page 117
- “boot command errors” on page 118
- “clear command errors” on page 118
- “clearlog command errors” on page 118
- “clock command errors” on page 119
- “config command errors” on page 120
- “console command errors” on page 120
- “dhcpinfo command errors” on page 121
- “displaylog command errors” on page 121
- “dns command errors” on page 121
- “env command errors” on page 122
- “exit command errors” on page 122
- “fuelg command errors” on page 122
- “health command errors” on page 125
- “help command errors” on page 126
- “history command errors” on page 126
- “identify command errors” on page 126
- “ifconfig command errors” on page 127
- “info command errors” on page 130
- “kvm command errors” on page 131
- “list command errors” on page 131
- “mt command errors” on page 131
- “power command errors” on page 132
- “reset command errors” on page 132
- “shutdown command errors” on page 133
- “slp command errors” on page 133
- “smtp command errors” on page 133
- “snmp command errors” on page 134
- “sol command errors” on page 135
- “tcpcmdmode command errors” on page 136
- “telnetcfg command errors” on page 137
- “update command errors” on page 137
- “uplink command errors” on page 140
- “users command errors” on page 140

## Common errors

This topic lists error messages that apply to all commands.

Each command that has unique errors will also have a list of command-specific error messages.

Table 38. Common errors

Error message	Definition
Alarm panel card is not present in this slot.	The user tries to issue a command to an empty alarm panel card slot.
Backplane Mux card is not present in this slot.	The user tries to issue a command to an empty backplane mux card slot.
Command cannot be issued to this target. Type <code>env - h</code> for help on changing targets.	The user tries to issue a command to a target that does not support that command.
Command line contains extraneous arguments.	Extra command arguments were entered.
Duplicate option: <i>option</i> where <i>option</i> identifies the command option that was entered more than once.	A user tries to enter the same command option in a single command multiple times. For example, <code>dns -i 192.168.70.29 -i</code>
Each option can only be used once per command.	A user tries to enter the same command option in a single command multiple times. For example, <code>env -T system:blade[4] -T system:blade[5]</code> .
Error: Command not recognized. Type 'help' to get a list of supported commands.	A user tries to enter a command that does not exist.
Error reading data for the option - <i>option</i> where <i>option</i> identifies the command option that is returning an error.	An error occurs while the management module is reading data of a option.
Error writing data for the option <i>option</i> where <i>option</i> identifies the command option that is returning an error.	An error occurs while the management module is writing a command option value.
Firmware update is in progress. Try again later.	Firmware update is in progress.
Illegal option: <i>option</i> where <i>option</i> identifies the illegal short command option that was entered.	An illegal short command option is entered.
Integer argument out of range ( <i>range - range</i> ) for <i>option: argument</i> where: <ul style="list-style-type: none"><li>• <i>range</i> identifies the range limits</li><li>• <i>option</i> identifies the command option</li><li>• <i>argument</i> identifies the integer that is out of range</li></ul>	An integer is entered that is out of range.
Internal error.	An internal error occurs.
Invalid integer argument for <i>option: argument</i> where: <ul style="list-style-type: none"><li>• <i>option</i> identifies the command option</li><li>• <i>argument</i> identifies the invalid argument</li></ul>	An invalid integer is entered.
Invalid option.	An invalid command option is entered.



Table 38. Common errors (continued)

Error message	Definition
Invalid option argument for <i>option</i> : <i>argument</i> where: <ul style="list-style-type: none"> <li>• <i>option</i> identifies the command option</li> <li>• <i>argument</i> identifies the invalid argument</li> </ul>	An invalid argument for a command option is entered.
Invalid option for this target: <i>option</i> where <i>option</i> identifies the option that is invalid.	A user tries to issue a command with an invalid option for the target.
Invalid parameter. Input must be numeric.	A user tries to enter a non-numeric argument.
Invalid syntax. Type <i>command</i> - h for help. where <i>command</i> identifies the command that is returning an error.	A user tries to enter a command that is not syntactically correct.
Invalid target path.	A user tries to issue a command to a target that is not valid.
Long option <i>option</i> requires an argument where <i>option</i> identifies the long command option that is missing an argument.	A long command option is entered without a required argument.
Missing option name	A dash (-) is entered without a command option name.
Network Clock card is not present in this slot.	The user tries to issue a command to an empty network card slot.
Read/write command error.	An error occurs while the management module is executing the command.
Short option <i>option</i> requires an argument where <i>option</i> identifies the short command option that is missing an argument.	A short command option is entered without a required argument.
Syntax error. Type <i>command</i> -h for help. where <i>command</i> identifies the command that is returning an error.	A user tries to enter a command improperly.
That blade is presently not available. Please try again shortly.	A user tries to connect to a blade that is already in use.
The argument for the option <i>arg</i> is outside the valid range. where <i>arg</i> identifies the command option that is out of range.	A user tries to enter an arg outside the option's valid range.
The target bay is empty.	The user tries to issue a command to an empty blade bay, blower bay, I/O-module bay, management-module bay, or power bay.
The target bay is out of range.	A user tries to issue a command to a target that is out of range for that target. For example, the <code>env -T system:blade[15]</code> command is out of range because the BladeCenter unit has only 14 blade bays.
The target slot is out of range.	The user tries to issue a command to a target which is out of range for that target.
There is no blade present in that bay.	The user tries to issue a command to an empty blade bay.

Table 38. Common errors (continued)

Error message	Definition
There is no blower present in that bay.	The user tries to issue a command to an empty chassis cooling unit bay.
There is no management module present in that bay.	The user tries to issue a command to an empty management module bay.
There is no power source present in that bay.	The user tries to issue a command to an empty power module bay.
There is no switch present in that bay.	The user tries to issue a command to an empty I/O module bay.
Unknown long option: <i>option</i> where <i>option</i> identifies the command option that is unknown.	A user tries to enter a long option that is not valid for the command.
Unknown option: <i>option</i> where <i>option</i> identifies the command option that is unknown.	An unknown option is used.
Unrecognized long option: <i>option</i> where <i>option</i> identifies the illegal long command option that was entered.	An illegal long command option is entered.
Unsupported target type.	A user tries to issue a command to an unsupported target.
User does not have the authority to issue this command.	A user lacks the authority level necessary to execute a command.

## alarm command errors

This topic lists error messages for the alarm command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 39. alarm command errors

Error message	Definition
A duplicate option is found in the requested command.	A duplicate argument is entered.
Alarm Description must be provided for setting an alarm.	The user tries to set an alarm without providing an alarm description.
Alarm ID must be from 1 to 255.	An invalid alarm ID is entered.
Category must be from 1 to 255.	An invalid category argument is entered.
Generator ID must be from 1 to 255.	An invalid generator ID is entered.
Generator ID must be provided.	A generator information ID is provided without a generator ID.
Module ID must be from 1 to 255.	An invalid module ID is entered.
No active alarm.	No active alarm is found for the command target.
No matching alarm.	No matching alarm is found for the command target.
Reading system health summary failed.	An error occurs while the management module is getting the system health summary.

Table 39. alarm command errors (continued)

Error message	Definition
Severity level must be provided for setting an alarm.	The user tries to set an alarm without specifying the severity level.
Software Generator ID must be from 1 to 255.	The user tries to enter an invalid generator information.
The entered Alarm Key is not in proper format.	The user tries to enter an invalid alarm key.
Unable to acknowledge the requested alarm.	An error occurs while the management module is acknowledging an alarm.
Unable to clear the requested alarm.	An error occurs while the management module is clearing an alarm.
Unable to set the requested alarm.	An error occurs while the management module is setting an alarm.

## alertentries command errors

This topic lists error messages for the alertentries command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 40. alertentries command errors

Error message	Definition
-test must be used exclusive of other options.	The user tries to issue a command with the -test option at the same time as the other options.
An entry cannot be modified and deleted in the same command.	A user tries to modify an entry and delete it in the same command.
Arguments containing spaces must be enclosed in quotation marks.	A user tries to enter a string containing spaces that has an opening quotation mark without a closing quotation mark.
Enabling the application alert failed.	An error occurs while the management module is enabling the application alert.
Generating test alert failed.	An error occurs while the management module is generating a test alert.
Invalid input. Angle brackets are not allowed in the name field.	A user tries to enter a string parameter containing < or > for the -n (name) command option.
Invalid option.	An invalid command option is entered. This includes numeric options for the alert recipient that are not from 1 through 12.
Invalid parameter. Input must be numeric.	A user tries to enter a parameter value containing non-numeric characters for a command option requiring numeric input.
Restoring previous configured value for the application alert failed.	An error occurs while the management module is restoring previous configured value for the application alert.
Syntax error. -e can only be used in conjunction with the email argument.	A user tries to enter an invalid email address for the -e command option.
Syntax error. -i can only be used in conjunction with the director argument.	A user tries to enter an invalid IP address for the -i command option.
Syntax error. Type alertentries -h for help.	An alert entry number is entered without the leading dash ( - ).

Table 40. alertentries command errors (continued)

Error message	Definition
The name must be less than 32 characters long.	A user tries to enter too many characters in an input field.
When creating a new entry, all options are required.	A required command option is missing when creating a user.

---

## boot command errors

This topic lists errors for the boot command.

There are no unique errors for the boot command. See “Common errors” on page 114 for a list of error messages that apply to all commands.

---

## clear command errors

This topic lists error messages for the clear command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 41. clear command errors

Error message	Definition
Firmware update is in progress. Try again later.	The user tries to reset the management module to its default configuration during a firmware update. The error message displays and the management-module configuration does not reset.
Internal error resetting to defaults.	An error occurs while the management module is resetting the management module to its default configuration. The error message displays and the management-module configuration does not reset.

---

## clearlog command errors

This topic lists error messages for the clearlog command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 42. clearlog command errors

Error message	Definition
Error clearing the event log.	An error occurs while the management module is clearing the event log.

## clock command errors

This topic lists error messages for the clock command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 43. clock command errors

Error message	Definition
GMT+2:00 requires one of the following dst values: off, ee, gtb, egt, or fle	The user tries to change the Greenwich mean-time (GMT) offset to +2:00 without adjusting the DST setting.
GMT+10:00 requires one of the following dst values: off, ea, tas, or vlad	The user tries to change the GMT offset to +10:00 without adjusting the DST setting.
GMT $offset$ requires one of the following dst values: off, uc, other where $offset$ is the daylight-savings time offset.	The user tries to change the GMT offset to -9, -8, -7, -6, or -5 without adjusting the DST setting.
Invalid dst setting for GMT+10:00: $setting$ where $setting$ is the illegal daylight-savings time setting that was entered.	The user tries to enter an invalid -dst setting for a GMT offset of 10.
Invalid dst setting for GMT+2:00: $setting$ where $setting$ is the illegal daylight-savings time setting that was entered.	The user tries to enter an invalid -dst setting for a GMT offset of 2.
Invalid dst setting for GMT $offset$ : $setting$ where $setting$ is the daylight-savings time offset and $setting$ is the illegal daylight-savings time setting that was entered.	The user tries to enter an invalid -dst setting for a GMT offset of -9, -8, -7, -6, or -5.
Invalid dst setting. The gmt offset does not support dst.	The user tries to turn on dst for a GMT offset that does not support daylight-savings time.
Invalid input for -dst.	A user tries to enter an invalid argument for the option -dst.
Reading date and time failed.	An error occurs while the management module is reading the date and time.
Reading GMT offset failed.	An error occurs while the management module is reading the GMT offset.
Reading status of daylight savings time failed.	An error occurs while the management module is reading the daylight savings time status.
The gmt offset you entered does not support dst. Turning dst off.	A user tries to enter a GMT offset that does not support daylight savings time.

---

## config command errors

This topic lists error messages for the config command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 44. config command errors

Error message	Definition
Arguments containing spaces must be enclosed in quotation marks.	The user tries to enter an management module Contact or Location without ending double quotes.
Contact must be enclosed in quotation marks.	The user tries to enter an management module Contact without enclosing it in double quotes.
Invalid input. Contact may not contain angle brackets.	The user tries to enter an management module Contact containing angle brackets (" $<$ " and " $>$ ").
Invalid input. Location may not contain angle brackets.	The user tries to enter an management module Location containing angle brackets (" $<$ " and " $>$ ").
Invalid input. Name must be less than 16 characters.	The user tries to enter a name that is more than 15 characters in length.
Invalid input. Name may not contain angle brackets.	The user tries to enter a blade server name that contains angle brackets: " $<$ " or " $>$ ".
Invalid input. Only alphanumeric characters, underscores, hyphens, pound signs, and periods are allowed.	The user tries to enter a name for the management module that is not valid.
Invalid input. -sn should have exactly seven alphanumeric characters.	The user tries to enter a serial number that is not exactly seven alphanumeric characters.
Invalid input. -tm should have exactly seven alphanumeric characters.	The user tries to enter a type or model name that is not exactly seven alphanumeric characters.
Invalid input. -uuid should have exactly 32 hex digits.	The user tries to enter a universally unique ID that is not exactly 32 hex digits.
Location must be enclosed in quotation marks.	The user tries to enter an management module Location without enclosing it in double quotes.
Reading SNMPv1/SNMPv3 status failed.	An internal errors occurs while the management module is reading the SNMPv1/v3status.
System location and contact must be defined when SNMPv1 or SNMPv3 agent is enabled.	The user tries to undefine the system location or contact information while an SNMPv1 or SNMPv3 agent is enabled.

---

## console command errors

This topic lists error messages for the console command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 45. console command errors

Error message	Definition
A SOL session socket was not available.	The command-line interface fails to establish an SOL connection to a blade server.
Error entering console mode.	An error occurs while the management module is trying to establish an SOL connection.

Table 45. console command errors (continued)

Error message	Definition
Global SOL is not enabled	SOL is not enabled globally.
Internal Error	An error occurs while the management module is processing the command.
SOL is not ready	The blade server is not available, or when a socket needed to establish a connection to the blade server is not available.
SOL on blade is not enabled	SOL is not enabled on the blade server where the user is trying to start an SOL session.
SOL session is already active	The user cannot start an SOL session with a blade server because an SOL session with that blade server is already in progress.
The maximum number of sessions to this blade has been reached.	The blade server has no available sessions for a user to connect to.
Unknown error occurred while attempting to connect.	An unknown error occurs when connecting to a blade server.

## dhcpcfg command errors

This topic lists errors for the dhcpcfg command.

There are no unique errors for the dhcpcfg command. See “Common errors” on page 114 for a list of error messages that apply to all commands.

## displaylog command errors

This topic lists error messages for the displaylog command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 46. displaylog command errors

Error message	Definition
(There are no more entries in the event log.)	There are no more event log entries to display.

## dns command errors

This topic lists error messages for the dns command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 47. dns command errors

Error message	Definition
-on and -off cannot both be used in the same command.	A user tries to enable and disable DNS in the same command.
At least one address is required to enable DNS.	A user tries to enable DNS without configuring at least one address.
DNS State Can not be determined.	An error occurs while the management module is reading the DNS state.

Table 47. dns command errors (continued)

Error message	Definition
Input length is greater than the maximum characters allowed.	A user tries to enter too many characters in an input field.
Invalid ip address	A user tries to set an invalid IP address.
Reading status of DNS failed.	An error occurs while the management module is reading the DNS state.
Reading status of interface failed.	An error occurs while the management module is reading the status of an interface.

---

## env command errors

This topic lists errors for the env command.

There are no unique errors for the env command. See “Common errors” on page 114 for a list of error messages that apply to all commands.

---

## exit command errors

This topic lists errors for the exit command.

There are no unique errors for the exit command. See “Common errors” on page 114 for a list of error messages that apply to all commands.

---

## fuelg command errors

This topic lists error messages for the fuelg command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 48. fuelg command errors

Error message	Definition
-am cannot be enabled while -e is set to nebs.	The user attempts to enable the acoustic mode while the environment is set to nebs.
-ps and -dps cannot be enabled at the same time.	The user attempts to enable -ps and idps at the same time.
A power module failure in domain <i>domain_number</i> can result in an immediate shutdown. where <i>domain_number</i> identifies the power domain.	A power module fails and the domain in which it is installed loses redundancy. The BladeCenter unit might turn itself off, based on the power management configuration.
Blade <i>blade_number</i> is not allowed to power on because of insufficient power. where <i>blade_number</i> identifies the blade server.	There is insufficient power available in the power domain to turn on this blade server.
Blade <i>blade_number</i> is throttled. where <i>blade_number</i> identifies the blade server.	The specified blade server has reduced power (power throttling) in response to a thermal event or oversubscription condition.
Blade <i>blade_number</i> was instructed to power off due to power budget restrictions. where <i>blade_number</i> identifies the blade server.	BladeCenter power management turns off a blade server that is already on in response to a oversubscription condition.



Table 48. fuelg command errors (continued)

Error message	Definition
Blade must be powered on to enable/disable dps.	The user attempts to enable or disable dynamic power server mode for a blade server while its power is off.
Checking if power is preallocated to switch <i>number</i> failed.  where the <i>number</i> I/O-module bay number.	An error occurs while the management module is checking if power is preallocated for the specified I/O module.
Demand exceeds a single power module. Throttling can occur in power domain <i>domain_number</i> .  where <i>domain_number</i> identifies the power domain.	The power requirements of components installed in a power domain exceed the level required for redundant operation. Power throttling of BladeCenter components might be able to correct the problem.
Getting blade health state parameters failed.	An error occurs while the management module is reading the blade server health state parameters.
Getting blade pcap maximum value failed.	An error occurs while the management module is reading the blade server power cap maximum value.
Getting blade pcap minimum value failed.	An error occurs while the management module is reading the blade server power cap minimum value.
Getting blade power cap level failed.	An error occurs while the management module is reading the blade server power cap level.
Getting data of domain 1 (or 2 ) failed.	An error occurs while the management module is reading the data of power domain 1 (or 2).
Getting domain latest power sample failed.	An error occurs while the management module is reading the latest power domain sample.
Getting duty cycle numbers failed.	An error occurs while the management module is reading the duty cycle numbers.
Getting duty cycle numbers of blade <i>blade_number</i> failed.  where <i>blade_number</i> identifies the blade server.	An error occurs while the management module is reading the duty cycle numbers of specified blade server.
Getting dynamic power management capability of bladeblade <i>number</i> failed.  where <i>blade_number</i> identifies the blade server.	An error occurs while the management module is reading the dynamic power management capability of specified blade server.
Getting information of powernumber failed.  where the <i>number</i> identifies the specified power module.	An error occurs while the management module is reading data of specified power module.
Getting module domain map for blower <i>number</i> failed.  where the <i>number</i> identifies the specified chassis cooling unit.	An error occurs while the management module is reading module domain map of specified chassis cooling unit.
Getting module domain map for midplane failed.	An error occurs while the management module is reading the module domain map for midplane.
Getting module domain map for MM <i>number</i> failed.  where the <i>number</i> identifies the specified management module.	An error occurs while the management module is reading the module domain map of specified management module.
Getting module domain map for mux <i>number</i> failed.  where the <i>number</i> identifies the location of the component.	An error occurs while the management module is reading the module domain map of specified mux.

Table 48. fuelg command errors (continued)

Error message	Definition
Getting module domain map for NC <i>number</i> failed. where the <i>number</i> identifies the location of the component.	An error occurs while the management module is reading the module domain map of specified network clock module.
Getting module domain map of mt <i>number</i> failed. where the <i>number</i> identifies the specified mt.	An error occurs while the management module is reading the module domain map of specified mt.
Getting module domain map of PM Cooling Device <i>number</i> failed. where <i>number</i> identifies the blade server.	An error occurs while the management module is reading the module domain map of specified power module Cooling Device.
Getting module domain map of switch <i>number</i> failed. where the <i>number</i> represents the specified I/O module.	An error occurs while the management module is reading the module domain map of specified I/O module.
Getting module domain map of Telco alarm panel failed.	An error occurs while the management module is reading the module domain map of Telco alarm panel.
Getting power management policy for domain <i>domain_number</i> failed where <i>domain_number</i> is the number of the domain that was entered.	An error occurs while the management module is reading the power management policy of specified domain.
Getting power state of bladeblade_ <i>number</i> failed. where <i>blade_number</i> identifies the blade server.	An error occurs while the management module is reading the power state of specified blade server.
Getting power values for blower <i>number</i> failed. where the <i>number</i> identifies the location of the component.	An error occurs while the management module is reading the power values of specified chassis cooling unit.
Getting power values for DSS <i>number</i> failed. where the <i>number</i> represents the specified DSS.	An error occurs while the management module is reading the power values of specified DSS.
Getting power values for MM <i>number</i> failed. where the <i>number</i> identifies the location of the component.	An error occurs while the management module is reading the power values of specified management module.
Getting power values for NC <i>number</i> failed. where the <i>number</i> represents the specified NC.	An error occurs while the management module is reading the power values of specified network clock module.
Getting power values for switch <i>number</i> failed. where the <i>number</i> represents the specified I/O module.	An error occurs while the management module is reading the power values of specified I/O module.
Getting power values of midplane within domain failed.	An error occurs while the management module is reading the power values of midplane within domain.
Getting power values of mt <i>number</i> within domain failed. where the <i>number</i> represents the specified mt.	An error occurs while the management module is reading the power values within domain of specified media tray.
Getting power values of mux <i>number</i> within domain failed. where the <i>number</i> represents the specified mux.	An error occurs while the management module is reading the power values within domain of specified mux.

Table 48. *fuelg* command errors (continued)

Error message	Definition
Getting power values of PM Cooling Device <i>number</i> failed where the <i>number</i> represents the specified PM cooling device.	An error occurs while the management module is reading the power values of specified power module cooling device.
Getting power values of Telco alarm panel within domain failed.	An error occurs while the management module is reading the power values of Telco alarm panel within domain.
Getting status of domain <i>domain_number</i> failed where <i>domain_number</i> identifies the power domain.	An error occurs while the management module is reading the status of specified domain.
Getting the power control setting on blade failed.	An error occurs while the management module is reading the power control setting on blade server.
Invalid option for this blade: <i>option</i> where <i>option</i> identifies the unacceptable option.	The user attempts to issue a command with an option which is invalid for the targeted blade server.
Maximum CPU Speed not available.	An error occurs while the management module is reading maximum CPU Speed.
pcap must be between <i>min</i> and <i>max</i> Watts. where <i>min</i> and <i>max</i> represent the minimum and maximum wattage values permitted.	The user input for power cap is out of the range.
Power value is not in the guaranteed capping range.	The user attempts to set a power value that is out of range.
Setting <i>-e</i> to nebs automatically disables <i>-am</i> , so " <i>-am on</i> " will be ignored.	The user attempts to set the environment to nebs and to enable the acoustic mode at the same time.
There are mismatched power modules in power domain <i>domain_number</i> . where <i>domain_number</i> identifies the power domain.	The power modules installed in a power domain have different ratings.
There is no thermal trending data to display.	An error occurs while the management module is reading thermal trending data.
There is no trending data to display.	An error occurs while the management module is reading power trending data.
Unable to change power management settings, domain may be oversubscribed.	An error occurs while the management module is configuring the power management policy.

## health command errors

This topic lists errors for the health command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 49. *health* command errors

Error message	Definition
Getting system health summary failed.	An error occurs while the management module is reading the system health summary.

---

## help command errors

This topic lists errors for the help command.

There are no unique errors for the help command. See “Common errors” on page 114 for a list of error messages that apply to all commands.

---

## history command errors

This topic lists errors for the history command.

There are no unique errors for the history command. See “Common errors” on page 114 for a list of error messages that apply to all commands.

---

## identify command errors

This section lists error messages for the identify command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 50. identify command errors

Error message	Definition
-d can only be used on the system target.	The user tries to issue a command with the -d option to a target other than system.
-d can only be used with the -s on.	The user tries to issue a command with the -d option without -s on setting.
Delay value must be less than <i>max</i> where <i>max</i> is the preset maximum.	The user input for option -d exceeds the maximum.
Delay value must be less than 60.	A user tries to enter a -d value that is greater than 60 seconds.
Error accessing remote LED.	An error occurs while the management module is accessing a remote LED.
Error getting LED status.	An error occurs while the management module is reading the blade LED status.
Error reading system LED state.	An error occurs while the management module is reading the system LED status.
Error setting system LED.	An error occurs while the management module is setting the system LED.
Error unknown command.	The user tries to enter unrecognized command.
Identify: Error accessing remote LED.	An error occurs while the management module is processing the command.
Identify: error getting LED status.	An error occurs while the management module is processing the command.
Identify: error setting Management Module LED.	An error occurs while the management module is processing the command.
Identify: Error unknown command.	An error occurs while the management module is processing the command.
Identify: LED status not supported.	The user tries to get the status of an LED that is not supported by a blade server.

Table 50. identify command errors (continued)

Error message	Definition
Identify: unknown LED state <i>state</i> where <i>state</i> identifies the LED state that was returned.	An LED state other than on, off, or blinking is returned.
Identify: Unknown return status <i>status</i> where the <i>status</i> value varies based on the problem that was encountered.	An error occurs while the management module is processing the command.
Syntax error.	The user tries to enter an invalid command option. Type <code>identify -h</code> for command help.
The chassis identification LED cannot be turned off at this time because one or more blades have their location LED active.	The user tries to turn off the chassis identification LED under conditions that do not permit this action.

## ifconfig command errors

This topic lists error messages for the ifconfig command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 51. ifconfig command errors

Error message	Definition
<i>-option</i> is not supported by this type of I/O Module. where <i>option</i> is <i>ir</i> , <i>gr</i> , or <i>sr</i> .	The user tries to issue a command with an option <code>-ir</code> , <code>-gr</code> , or <code>-sr</code> which is not supported by the targeted I/O module.
<code>-up</code> and <code>-down</code> can not be both used in same line.	The user tries to issue a command with both the <code>-up</code> and <code>-down</code> options.
Cannot apply network configuration. Blade in configuration phase.	An error occurs while the management module is setting the network configuration.
Configuration not supported on this I/O Module type.	The user tries to issue a command for the configuration which is not supported by targeted I/O module type.
Configuration not supported on this switch type.	The user tries to issue a command to an unsupported I/O module type.
Enabling/Disabling new IP configuration failed.	An error occurs while the management module is enabling or disabling the new IP configuration.
Error reading gateway address.	An error occurs while the management module is reading the gateway address of a network interface ( <code>eth0</code> or <code>eth1</code> ).
Error reading IP Address.	An error occurs while the management module is reading the IP address of the integrated system management processor on a blade server, or while reading the IP address of a network interface ( <code>eth0</code> or <code>eth1</code> ).
Error reading the burned-in MAC address.	An error occurs while the management module is reading the burned-in MAC address of a network interface ( <code>eth0</code> or <code>eth1</code> ).
Error reading the data rate.	An error occurs while the management module is reading the data rate setting of a network interface ( <code>eth0</code> or <code>eth1</code> ).

Table 51. ifconfig command errors (continued)

Error message	Definition
Error reading the DHCP configuration.	An error occurs while the management module is reading the DHCP setting of a network interface (eth0).
Error reading the duplex setting.	An error occurs while the management module is reading the duplex setting of a network interface (eth0 or eth1).
Error reading the hostname.	An error occurs while the management module is reading the host name of a network interface (eth0).
Error reading the locally administered MAC address.	An error occurs while the management module is reading the locally administered MAC address of a network interface (eth0 or eth1).
Error reading the maximum transmission unit.	An error occurs while the management module is reading the maximum transmission unit (MTU) setting of a network interface (eth0 or eth1).
Error reading the subnet mask.	An error occurs while the management module is reading the subnet mask of a network interface (eth0 or eth1).
Error writing IP Address.	An error occurs while the management module is setting the IP address of the integrated system management processor on a blade server.
Getting interface status failed.	An error occurs while the management module is reading the interface status.
I/O Module is in Stacking Mode and cannot change its Gateway configuration.	The user tries to issue a command to change the Gateway configuration with the I/O Module in Stacking Mode.
I/O Module is in Stacking Mode and cannot change its IP configuration.	The user tries to issue a command to change the IP configuration with the I/O Module in Stacking Mode.
I/O Module is in Stacking Mode and cannot change its Subnet configuration.	The user tries to issue a command to change Subnet configuration with I/O Module in Stacking Mode.
Invalid gateway address.	The user tries to enter an invalid gateway address.
Invalid hostname.	The user tries to enter an invalid hostname.
Invalid hostname arg for <i>option: hostname</i> . Consecutive dots  where: • <i>option</i> identifies the command option • <i>hostname</i> identifies the invalid hostname argument	The user tries to enter consecutive periods ( . ) as part of a hostname.
Invalid hostname arg for <i>option: hostname</i> . Length has to be < 64 characters  where: • <i>option</i> identifies the command option • <i>hostname</i> identifies the invalid hostname argument	The user tries to enter a hostname longer than 63 characters.
Invalid hostname arg for <i>option: hostname</i> . Only alphanumeric chars and ._- allowed  where: • <i>option</i> identifies the command option • <i>hostname</i> identifies the invalid hostname argument	The user tries to enter a hostname that contains invalid characters. Valid characters that can be used in a hostname are letters, numbers, periods ( . ), dashes ( - ), and underscores ( _ ).

Table 51. ifconfig command errors (continued)

Error message	Definition
Invalid ip address.	Displays for one of the following errors: <ul style="list-style-type: none"> <li>• A user tries to set the IP address of system:blade[1]:sp to an invalid IP address.</li> <li>• A user tries to set an IP address whose last part is greater than 255 (the maximum number of blade servers).</li> <li>• A user tries to enter an invalid IP address for the -i (static IP address) command option.</li> </ul>
Invalid IP arg for <i>option: ip_address</i> . Each byte has to be in the range (0-255)  where: <ul style="list-style-type: none"> <li>• <i>option</i> identifies the command option</li> <li>• <i>ip_address</i> identifies the invalid IP address argument</li> </ul>	The user tries to enter an IP address that is out of range. IP addresses must follow the standard format: <i>xxx.xxx.xxx.xxx</i> , where each <i>xxx</i> is a number from 0 to 255.
Invalid IP arg for <i>option: ip_address</i> . Enter 4 bytes separated by 3 dots  where: <ul style="list-style-type: none"> <li>• <i>option</i> identifies the command option</li> <li>• <i>ip_address</i> identifies the invalid IP address argument</li> </ul>	The user tries to enter an IP address that is too long. IP addresses must follow the standard format: <i>xxx.xxx.xxx.xxx</i> , where each <i>xxx</i> is a number from 0 to 255.
Invalid IP arg for <i>option: ip_address</i> . Too few bytes  where: <ul style="list-style-type: none"> <li>• <i>option</i> identifies the command option</li> <li>• <i>ip_address</i> identifies the invalid IP address argument</li> </ul>	The user tries to enter an IP address with too few bytes. IP addresses must follow the standard format: <i>xxx.xxx.xxx.xxx</i> , where each <i>xxx</i> is a number from 0 to 255.
Invalid IP arg for <i>option: ip_address</i> . Too many bytes  where: <ul style="list-style-type: none"> <li>• <i>option</i> identifies the command option</li> <li>• <i>ip_address</i> identifies the invalid IP address argument</li> </ul>	The user tries to enter an IP address with too many bytes. IP addresses must follow the standard format: <i>xxx.xxx.xxx.xxx</i> , where each <i>xxx</i> is a number from 0 to 255.
Invalid mac address.	The user tries to enter an invalid MAC address.
Invalid MAC arg for <i>option: address</i> . Invalid syntax  where: <ul style="list-style-type: none"> <li>• <i>option</i> identifies the command option</li> <li>• <i>address</i> identifies the invalid MAC address argument</li> </ul>	The user tries to enter an invalid MAC address.
Invalid MAC arg for <i>option: address</i> . Multicast addresses not allowed  where: <ul style="list-style-type: none"> <li>• <i>option</i> identifies the command option</li> <li>• <i>address</i> identifies the invalid MAC address argument</li> </ul>	The user tries to enter a multicast address.
Invalid MAC arg for <i>option: address</i> . Too few bytes  where: <ul style="list-style-type: none"> <li>• <i>option</i> identifies the command option</li> <li>• <i>address</i> identifies the invalid MAC address argument</li> </ul>	The user tries to enter a MAC address with too few bytes.
Invalid MAC arg for <i>option: address</i> . Too many bytes  where: <ul style="list-style-type: none"> <li>• <i>option</i> identifies the command option</li> <li>• <i>address</i> identifies the invalid MAC address argument</li> </ul>	The user tries to enter a MAC address with too many bytes.
Invalid option for ethernet interface.	A user tries to change a static property of eth1 (hostname, DHCP, data rate, duplex).

Table 51. *ifconfig* command errors (continued)

Error message	Definition
Invalid parameter. The locally administered MAC address cannot be a multicast address.	The user tries to set the locally administered MAC address to a multicast address.
Invalid parameter. The MTU must be between 60 and 1500, inclusive.	The user tries to enter an MTU outside the valid range.
Invalid parameter. Valid values for -c are dhcp, static, or dthens.	A user tries to enter an invalid parameter for the -c (Ethernet configuration method) command option.
Invalid parameter. Valid values for -d are auto, half, and full.	The user tries to enter an invalid parameter with the -d option.
Invalid parameter. Valid values for -r are auto, 10, and 100.	The user tries to enter an invalid parameter with the -r option.
Invalid subnet mask.	The user tries to enter an invalid subnet mask.
Maybe blade network configuration is still in discovery phase. Please check and try again.	An error occurs while the management module is reading the blade network configuration.
Please check blade health status and try again.	An error occurs while the management module is reading the blade health status.
The target must be system:blade[1]:sp for this command	A user tries to issue the <code>ifconfig -i ip address -T system:blade[x]:sp</code> to a blade server other than blade[1].  where <i>ip address</i> is a valid ip address and <i>x</i> identifies the selected blade server.

## info command errors

This topic lists error messages for the `info` command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 52. *info* command errors

Error message	Definition
Device not found	No VPD is available for the targeted device.
Getting blade H8 firmware VPD data of blade <i>blade_number</i> failed.  where <i>blade_number</i> identifies the blade server.	An error occurs while the management module is reading the blade H8 firmware VPD data of the targeted blade server.
Getting compact flash cards information failed.	An error occurs while the management module is reading the compact flash cards information.
Getting firmware's VPD data of <i>type</i> failed.	An error occurs while the management module is reading the firmware's VPD data of targeted type.
Getting name of blade <i>blade_number</i> failed.  where <i>blade_number</i> identifies the blade server.	An error occurs while the management module is reading the name of the targeted blade server.
Getting name of mm <i>bay_number</i> failed.  where the <i>bay_number</i> specifies the management module.	An error occurs while the management module is reading the name of the targeted management module.
Reload Firmware VPD failed.	An error occurs while the management module is reloading the firmware VPD.
Reload Hardware VPD failed.	An error occurs while the management module is reloading the hardware VPD.



Table 52. info command errors (continued)

Error message	Definition
Reload all failed.	An error occurs while the management module is reloading all VPD and MAC addresses.
Reload MAC address failed.	An error occurs while the management module is reloading the MAC address.
Reload WWN failed.	An error occurs while the management module is reloading WWN.
Status: Unable to read status.	An error occurs while the management module is reading the firmware update status.
Unknown device type.	The command is targeted to an unknown device type.

---

## kvm command errors

This topic lists errors for the kvm command.

There are no unique errors for the kvm command. See “Common errors” on page 114 for a list of error messages that apply to all commands.

---

## list command errors

This topic lists error messages for the list command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 53. list command errors

Error message	Definition
The level must be non-zero.	The user tries to enter a level of depth for tree-structure display of 0.

---

## mt command errors

This topic lists errors for the mt command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 54. mt command errors

Error message	Definition
Remote media tray switching must be enabled to change the media tray owner.	A user tries to issue a command to change the media tray owner while media tray switching is not enabled.

---

## power command errors

This topic lists error messages for the power command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 55. power command errors

Error message	Definition
Invalid POST results.	The POST results are not valid.
Not supported by this type of I/O module. Type env -h for help on changing targets.	The user attempts to apply the -fp option to an I/O module that does not support this option.
POST results could not be read.	An error occurs during POST.
POST results not complete: <i>hex_code</i> where the <i>hex_code</i> value varies based on the problem that was encountered.	The POST results are not available. See the documentation that comes with the device that failed to respond correctly to the power command for information about the <i>hex_code</i> value.
Powering on/off blade failed.	An error occurs while powering the blade server on or off.
Powering on/off I/O Module failed.	An error occurs while the management module is powering the I/O module on or off.
Resetting blade failed.	An error occurs while the management module is resetting the blade server.
Shutting down OS and powering off blade failed.	An error occurs while the management module is shutting down the operating system and powering off the blade server.

---

## reset command errors

This topic lists error messages for the reset command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 56. reset command errors

Error message	Definition
An error occurred while disabling failover.	An error occurs while the management module is disabling failover.
An error occurred while enabling failover.	An error occurs while the management module is enabling failover.
Firmware update is in progress. Try again later.	The user tries to reset the management module during a firmware update. The error message displays and the management module does not reset.
Rebooting blade failed.	An error occurs while the management module is rebooting the blade server.
Resetting and running standard/extended/full diagnostics for I/O module failed.	An error occurs while the management module is resetting and running diagnostics for the I/O module.
Resetting I/O module failed.	An error occurs while the management module is resetting the I/O module.
There is no backup management module installed.	A user tries to enable failover on a management-module reset and there is no standby management module.

Table 56. reset command errors (continued)

Error message	Definition
Resetting blade <i>blade_number</i> with NMI not supported. where the <i>blade_number</i> identifies the blade server.	A user tries to reset a blade server that does not support non-maskable interrupts (NMI).
Resetting blade <i>blade_number</i> with NMI failed. where the <i>blade_number</i> identifies the blade server.	An error occurs while the management module is resetting a blade server with NMI.

---

## shutdown command errors

This topic lists errors for the shutdown command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 57. shutdown command errors

Error message	Definition
Invalid option. This command must have the -f option.	The user tries to issue a command without the -f option.

---

## slp command errors

This topic lists errors for the slp command.

There are no unique errors for the slp command. See “Common errors” on page 114 for a list of error messages that apply to all commands.

---

## smtp command errors

This topic lists error messages for the smtp command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 58. smtp command errors

Error message	Definition
Getting SMTP server host name or IP address failed.	An error occurs while the management module is reading the SMTP server host name or IP address.
Input length is greater than the maximum characters allowed.	A user tries to enter too many characters in an input field.
Invalid host name or ip address.	A user tries to set the SMTP host name or IP address to an invalid value.
Removing SMTP server name or IP address failed.	An error occurs while the management module is removing an SMTP server host name or IP address.
Setting SMTP server name or IP address failed.	An error occurs while the management module is setting an SMTP server host name or IP address.
SMTP server host name or IP address is not set.	A user tries to view the SMTP host name or IP address when the values are not set.

---

## snmp command errors

This topic lists error messages for the snmp command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 59. snmp command errors

Error message	Definition
Arguments containing spaces must be enclosed in quotation marks	A user tries to enter a string containing spaces that has an opening quotation mark without a closing quotation mark.
At least one configured community is required to enable SNMP.	A user tries to enable SNMP without configuring at least one community name.
Config failed. IP address of 0.0.0.0 is allowed only for the first host name in the first community.	A user tries to set an IP address of 0.0.0.0 for something other than the first host name of the first community.
Config failed. IP address of 0.0.0.0 is allowed only when the first community is configured as Get access type.	A user tries to set an IP address of 0.0.0.0 for the first host name of the first community when the first community is not configured with the Get access type.
Config failed. You defined a community without an IP address or host name.	A user tries to define a community without specifying an IP address or host name.
Config failed. You defined a duplicate community name.	A user tries to define a two communities with the same name.
Enabling/Disabling snmp interface failed.	An error occurs while the management module is enabling or disabling an snmp interface.
Enabling/Disabling snmp traps failed.	An error occurs while the management module is enabling or disabling the snmp traps.
Enabling/Disabling SNMPv3 Agent failed.	An error occurs while the management module is enabling or disabling the SNMPv3 Agent.
Input length is greater than the maximum characters allowed.	A user tries to enter too many characters in an input field.
Invalid community name.	A user tries to set a community name to an invalid value.
Invalid host name or ip address.	A user tries to set the SNMP host name or IP address to an invalid value.
Setting access type of <i>type</i> for SNMPv3 failed where <i>type</i> is the type of SNMPv3 access desired.	An error occurs while the management module is setting access type for an SNMPv3.
Setting location/contact of the SNMP agent failed.	An error occurs while the management module is setting the location or contact of the SNMP agent.

## sol command errors

This topic lists error messages for the sol command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 60. sol command errors

Error message	Definition
An error occurred while disabling SOL globally.	An error occurs while the management module is disabling SOL globally.
An error occurred while disabling SOL on that blade.	An error occurs while the management module is disabling SOL on a blade server.
An error occurred while enabling SOL globally.	An error occurs while the management module is enabling SOL globally.
An error occurred while enabling SOL on that blade.	An error occurs while the management module is enabling SOL on a blade server.
An error occurred while reading the global SOL status.	An error occurs while the management module is reading the global SOL status.
An error occurred while reading the SOL accumulate timeout.	An error occurs while the management module is reading the SOL accumulate timeout.
An error occurred while reading the SOL retry count.	An error occurs while the management module is reading the SOL retry count.
An error occurred while reading the SOL retry interval.	An error occurs while the management module is reading the SOL retry interval.
An error occurred while reading the SOL send threshold.	An error occurs while the management module is reading the SOL send threshold.
An error occurred while reading the SOL session status on that blade.	An error occurs while the management module is reading the SOL session status on a blade server.
An error occurred while reading the SOL VLAN ID.	An error occurs while the management module is reading the SOL VLAN ID.
An error occurred while setting the SOL accumulate timeout.	An error occurs while the management module is setting the SOL accumulate timeout.
An error occurred while setting the SOL blade reset sequence.	An error occurs while the management module is processing the command.
An error occurred while setting the SOL escape sequence.	An error occurs while the management module is processing the command.
An error occurred while setting the SOL retry count.	An error occurs while the management module is setting the SOL retry count.
An error occurred while setting the SOL retry interval.	An error occurs while the management module is setting the SOL retry interval.
An error occurred while setting the SOL send threshold.	An error occurs while the management module is setting the SOL send threshold.
An error occurred while setting the SOL vlan id.	An error occurs while the management module is processing the command.
Checking if this blade supports SOL failed.	An error occurs while the management module is checking if the selected blade supports SOL.
Invalid arg for -status. Must be on or off.	A user tries to enter an invalid argument for the -status command option.

Table 60. sol command errors (continued)

Error message	Definition
Invalid arg for -status. Must be enabled or off.	A user tries to enter an invalid argument for the -status command option.
Invalid parameter. The accumulate timeout must be between 1 and 251 inclusive.	A user tries to enter an accumulate timeout that is outside of the valid range.
Invalid parameter. The retry count must be between 0 and 7, inclusive.	A user tries to enter a retry count that is outside of the valid range.
Invalid parameter. The send threshold must be between 1 and 251 inclusive.	A user tries to enter a send threshold that is outside of the valid range.
Invalid parameter. The vlan id must be between 1 and 4095 inclusive.	A user tries to enter a VLAN ID that is out of range.
Retry interval range is too large. Setting to 2550.	A user tries to enter a retry interval that is greater than 2550 ms. If the user tries to enter a retry interval greater than 2550 ms, the retry interval will be set to 2550 ms.
Setting retry interval to 2500 failed.	An error occurs while the management module is setting the retry interval to 2550.
This blade does not support SOL.	A user tries to issue the SOL command to a blade server that does not support SOL.

## tcpcmdmode command errors

This topic lists error messages for the tcpcmdmode command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 61. tcpcmdmode command errors

Error message	Definition
Error changing TCP command mode connection.	An error occurs while the management module is changing the TCP command mode Connection.
Error disabling tcpcmdmode.	An error occurs while the management module is disabling the TCP command mode.
Error enabling TCP command mode.	An error occurs while the management module is enabling the TCP command mode.
Invalid parameter. Input must be numeric.	A user tries to enter a parameter value for the -t (timeout) command option containing non-numeric characters. For example, tcpcmdmode -t 200m.
Invalid parameter. The timeout must be between 0 and 4294967295 seconds.	A user tries to enter a parameter value for the -t (timeout) command option that is outside of the valid range.
Maximum connections can not exceed <i>maximum</i> where <i>maximum</i> designates the total number of permitted connections.	A user attempted to configure more connections than the maximum number of connections supported.
No valid server certificate is in place for Secure TCP Command Mode. Use the sslcfg command to generate a certificate.	The user issues a command to enable the Secure TCP Command Mode when a valid server certificate is not in place.

Table 61. *tcpcmdmode* command errors (continued)

Error message	Definition
The total number of secure and legacy connections of TCP Command Mode cannot exceed <i>maximum</i>  where <i>maximum</i> designates the total number of permitted connections.	A user attempted to configure more TCP Command Mode connections than the maximum number of secure and legacy connections supported.
Warning: Communication with IBM Director via Secure TCP Command Mode has been disabled.	A user has disabled the Secure TCP command mode.
Warning: Communication with IBM Director via TCP Command Mode has been disabled.	A user has disabled the TCP command mode.

## telnetcfg command errors

This topic lists error messages for the `telnetcfg` command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 62. *telnetcfg* command errors

Error message	Definition
Invalid parameter. Input must be numeric.	A user tries to enter a Telnet timeout value containing non-numeric characters. For example, <code>telnetcfg -t 200w</code> .
Invalid parameter. The telnet timeout range must be less than 4294967295.	The user tries to enter a timeout value greater than 4294967295 seconds.
Invalid parameter. The timeout must be between 0 and 4294967295 seconds.	A user tries to enter a Telnet timeout value that is out of range.

## update command errors

This topic lists error messages for the `update` command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 63. *update* command errors

Error message	Definition
Cannot perform this command right now. The agent is not active.	A user tries to enter a command while the agent is not active.
Disabling failover failed.	An error occurs while the management module is turning off the automatic failover feature.
Error reading information for firmware image <i>index.maximum</i>  where <i>index</i> specifies the firmware image.	An error occurs while the management module is reading information for a specified firmware image.
Error reading the number of firmware images.	An error occurs while the management module is reading the number of firmware images.
Flash operation failed.	An error occurs during the flash firmware update.

Table 63. update command errors (continued)

Error message	Definition
Flash operation failed status <i>percentage</i> where the <i>percentage</i> value varies based on when the problem was encountered.	An error occurs during the flash firmware update.
Flash operation not in process or status unavailable.	An error occurs during the flash firmware update.
Flash operation timed out <i>percentage</i> . where the <i>percentage</i> value varies based on when the problem was encountered.	An error occurs during the flash firmware update.
Flash preparation - error sending packet file <i>filename</i> . where <i>filename</i> identifies the file being updated.	An error occurs during the flash firmware update.
Flash preparation error. Packet percent complete <i>percentage</i> . Flash percent complete <i>percentage</i> . where the <i>percentage</i> value varies based on when the problem was encountered.	An error occurs during the flash firmware update.
Flash preparation error. Timeout on packet preparation operation <i>percentage</i> . where the <i>percentage</i> value varies based on when the problem was encountered.	An error occurs during the flash firmware update.
Flashing not supported on this target.	A user attempts to run the update command on a module that does not support flash firmware updates.
Getting data encryption setting failed. If data encryption is enabled and you are updating the firmware to a level which does not support data encryption, you will lose all your configuration settings as a result.	An error occurs while the management module is reading the data encryption setting.
Getting name of mm <i>bay_number</i> failed. where the <i>bay_number</i> identifies the management module specified.	An error occurs while the management module is reading the name of the management module in designated bay.
Invalid image index. Index must be less than <i>maximum</i> where <i>maximum</i> designates the largest permitted index value.	A user tries to enter an image index that is greater than the maximum permitted index value.
Invalid option.	An invalid command option is entered. For the update command, invalid command option errors include: <ul style="list-style-type: none"> <li>the -i (IP address) command option does not have an IP address parameter</li> <li>the -i (IP address) command option specifies an invalid IP address</li> <li>attempting to enter the -i (IP address) command option without the -n (filename) command option</li> <li>the -n (filename) command option does not have a file name parameter</li> <li>attempting to enter the -n (filename) command option without the -i (IP address) command option</li> <li>attempting to enter the -v (verbose) command option without the -i (IP address) command option and -n (filename) command option</li> <li>attempting to enter the -v (verbose) command option with the -a command option</li> </ul>



Table 63. update command errors (continued)

Error message	Definition
<p>Management Module <i>bay_number</i> is not installed.</p> <p>where the <i>bay_number</i> identifies the management module specified.</p>	<p>The command is targeted to a management module bay where no management module is installed.</p>
<p>Status: Unable to read status.</p>	<p>An error occurs while the management module is reading status.</p>
<p>TFTP Error: <i>error_code</i>.</p> <p>where the <i>error_code</i> can have one of the following values:</p> <ul style="list-style-type: none"> <li>• Access violation.</li> <li>• Connection failure.</li> <li>• Disk full or allocation exceeded.</li> <li>• File already exists.</li> <li>• File error.</li> <li>• File not found.</li> <li>• Illegal option negotiation.</li> <li>• Illegal TFTP operation.</li> <li>• Unable to allocate memory.</li> <li>• Unknown transfer ID.</li> <li>• Unknown user.</li> </ul>	<p>An error occurs when the user attempts to set up the TFTP connection.</p>
<p>Unable to read blade server VPD bay <i>bay_number name</i>.</p> <p>where the <i>bay_number</i> and <i>name</i> identify the blade server by location and name.</p>	<p>The command specifies an empty blade server bay or an error occurs when reading the VPD.</p>
<p>Unable to read I/O Module VPD bay <i>bay_number name</i>.</p> <p>where the <i>bay_number</i> and <i>name</i> identify the I/O module by location and name.</p>	<p>The command specifies an empty I/O-module bay or an error occurs when reading the VPD.</p>
<p>Unable to read MM VPD bay <i>bay_number name</i>.</p> <p>where the <i>bay_number</i> and <i>name</i> identify the management module by location and name.</p>	<p>The command specifies an empty management module bay or an error occurs when reading the VPD.</p>
<p>Unable to read VPD for Blade <i>blade_number name</i>.</p> <p>where the <i>blade_number</i> and <i>name</i> identify the blade server by location and name.</p>	<p>An error occurs while the management module is reading the VPD of the targeted blade server.</p>
<p>Unknown device type.</p>	<p>The command is targeted to an unknown device type.</p>
<p>Update error. Invalid destination.</p>	<p>A user tries to issue a command to a target that is not valid.</p>
<p>Update Failed, there was a problem retrieving the file.</p>	<p>The management module was unable to complete the update because it was unable to retrieve the file from the TFTP server.</p>

---

## uplink command errors

This topic lists error messages for the uplink command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 64. uplink command errors

Error message	Definition
-ip must be a valid IP address before enabling -el	The user tries to issue a command to enable the -el without a valid -ip setting.
Getting status of failver on Lose/Logical of Physical Link failed.	An error occurs while the management module is reading status of failver on Lose/Logical of Physical Link.
Invalid uplink delay value.	A user tries to enter a delay value that is less than 1 or greater than 255. For example, uplink -del 0.
The option argument for <i>option</i> is out of the valid range (between 1 and 2880 minutes). where <i>option</i> is the number of minutes specified.	The user input for an option is out of the range.
The option argument for <i>option</i> is out of the valid range (between 10 and 172800 seconds). where <i>option</i> is the number of seconds specified.	The user input for an option is out of the range.

---

## users command errors

This topic lists error messages for the users command.

See “Common errors” on page 114 for a list of error messages that apply to all commands.

Table 65. users command errors

Error message	Definition
-af contains invalid characters. Only alphanumeric, comma, asterisk, question mark, hyphen, period, and exclamation point characters are valid.	The user input for the -af option is invalid.
-af must start with from=.	The user input for the -af option is invalid.
-cm is greater than 255 characters.	The user input for the -cm option exceeds the maximum.
-cm must be quote-delimited.	The user input for the -cm option is not quote-delimited.
An entry cannot be modified and deleted in the same command.	A user tries to simultaneously modify and delete a user in the same command.
Arguments containing spaces must be enclosed in quotation marks.	A user tries to enter a context name containing spaces that does not have opening and closing quotation marks.
Checking if passwords are required failed.	An error occurs while the management module is checking if passwords are required.
Deleting user failed.	An error occurs while the management module is deleting an user.
Error: the RBS permissions capability is not enabled.	The user tries to run use the -a rbs: command option on management-module firmware that does not support this option.

Table 65. users command errors (continued)

Error message	Definition
Error converting RBS permissions.	An error occurs while the management module is converting permissions data to the role-based security (RBS) format.
Error creating user.	An error occurs while the management module is creating a user.
Error creating user: The authentication protocol cannot be none because the security settings require passwords.	The user tries to issue a command to create a user with no authentication protocol when the security settings require passwords.
Error reading certificate details.	An error occurs while the management module is reading certificate details.
Error reading key.	An error occurs while the management module is reading the key.
Error setting the access type.	An error occurs while the management module is setting the access type.
Error setting the authentication protocol.	An error occurs while the management module is setting the authentication protocol.
Error setting the authority level.	An error occurs while the management module is setting the authority level.
Error setting the context name.	An error occurs while the management module is setting the context name.
Error setting the hostname/IP address.	An error occurs while the management module is setting the hostname or IP address.
Error setting the password.	An error occurs while the management module is setting the password.
Error setting the password. The new password is not compliant.	The user tries to issue a command to set the new password which is not compliant.
Error setting the privacy password.	An error occurs while the management module is setting the privacy password.
Error setting the privacy protocol.	An error occurs while the management module is setting the privacy protocol.
Error setting the username.	An error occurs while the management module is setting the username.
Error transferring file.	An error occurs while the management module is transferring file.
Getting a summary of all keys of user <i>index</i> failed. where the <i>index</i> value varies based on the problem that was encountered.	An error occurs while the management module is reading a summary of all keys of the targeted user.
Getting authority level of user <i>index</i> failed. where the <i>index</i> value varies based on the problem that was encountered.	An error occurs while the management module is reading authority level of the targeted user.
Getting role-based security level of user <i>index</i> failed. where the <i>index</i> value varies based on the problem that was encountered.	An error occurs while the management module is reading role-based security level of the targeted user.
Incorrect login permission option: <i>permission</i> where the <i>permission</i> value varies based on the problem that was encountered.	A user tries to specify an invalid login permission for the -a command option.

Table 65. users command errors (continued)

Error message	Definition
Invalid argument. Valid arguments for -at are read, write, and traps.	A user tries to set an invalid argument for the -at command option.
Invalid argument. Valid choices are des or <none>.	A user tries to set an invalid argument for the -pp command option.
Invalid argument. Valid choices are md5, sha, or <none>.	A user tries to set an invalid argument for the -ap command option.
Invalid authority level.	This error message indicates one of the following errors: <ul style="list-style-type: none"> <li>• A user tries to set an authority level that is invalid.</li> <li>• A user tries to set a custom authority level without specifying any customization information.</li> </ul>
Invalid device number (first number must be smaller): <i>device_A-device_B</i> .  where <i>device_A</i> and <i>device_B</i> identify the ends of the invalid device range being specified.	A user specifies an invalid device range while trying to create or modify a user.
Invalid device number: <i>device_number</i> .  where <i>device_number</i> identifies the device number that is invalid.	A user provides a device number that is out of range while trying to create or modify a user.
Invalid hostname or ip address.	A user tries to set an invalid host name or IP address for the -i command option.
Invalid key index for this command.	The user input for index is invalid.
Invalid rbs device: <i>device</i> .  where <i>device</i> identifies the device that is invalid.	A user specifies an invalid device while trying to create or modify a user.
Invalid rbs device: Must specify device number	A user specifies an invalid device number while trying to create or modify a user.
Invalid rbs device list.	A user does not specify a device list while trying to create or modify a user.
Invalid rbs device (must be same device): <i>device</i> .  where <i>device</i> identifies the device that is invalid.	A user specifies an invalid device while trying to create or modify a user.
Invalid rbs role: <i>role</i> .  where <i>role</i> identifies the role that is invalid.	A user specifies an invalid role while trying to create or modify a user.
Invalid rbs role list.	A user fails to specify a role list while trying to modify or create a user.
Invalid username. The username can only contain numbers, letters, dots, and underscores.	The user tries to enter The username that contains invalid characters. Valid characters that can be used in a username are letters, numbers, periods (.), and underscores (_).
Max retries changing password reached.	The user tries to issue a command to change a password after the max retries of changing password limit is reached.
Must be set at least one rbs role for this user.	The user tries to issue a command to create a user without the rbs role settings.
Old password is incorrect.	The user tries to issue a command to change a password with an incorrect old password.
Old password must be specified by long option op.	The user tries to issue a command to change a password without the -op option.

Table 65. users command errors (continued)

Error message	Definition
Specify your new password with '-p' option.	The user tries to issue a command to change a password without the -p option.
Syntax error. -a option must have an argument.	A user tries to attempt to enter the command with an -a command option that has no argument.
Syntax error. -at option must have an argument.	A user tries to attempt to enter the command with an -at command option that has no argument.
Syntax error. -cn option must have an argument.	A user tries to attempt to enter the command with a -cn command option that has no argument.
Syntax error. -i option must have an argument.	A user tries to attempt to enter the command with an -i command option that has no argument.
Syntax error. -n option must have an argument.	A user tries to attempt to enter the command with an -n command option that has no argument.
Syntax error. -ppw option must have an argument.	A user tries to attempt to enter the command with a -ppw command option that has no argument.
Syntax error. Multiple -a options found.	A user tries to enter the -a command option in a single command multiple times.
Syntax error. Multiple -ap options found.	A user tries to enter the -ap option flag in a single command multiple times.
Syntax error. Multiple -at options found.	A user tries to enter the -at option flag in a single command multiple times.
Syntax error. Multiple -cn options found.	A user tries to enter the -cn option flag in a single command multiple times.
Syntax error. Multiple -i options found.	A user tries to enter the -i option flag in a single command multiple times.
Syntax error. Multiple -n options found.	A user tries to enter the -n option flag in a single command multiple times.
Syntax error. Multiple -p options found.	A user tries to enter the -p option flag in a single command multiple times.
Syntax error. Multiple -pp options found.	A user tries to enter the -pp option flag in a single command multiple times.
Syntax error. Multiple -ppw options found.	A user tries to enter the -ppw option flag in a single command multiple times.
Syntax error. Type users -h for help.	A user tries to set an invalid value for a command option.
The context name must be less than 32 characters long.	A user tries to set a context name that is longer than 31 characters.
The -i and -l options must both be specified when using -upld.	The user tries to issue a -upld command without -i and -l.
The accept_from_string must be quote-delimited.	The user input for the -af option is not quote-delimited.
The key is greater than 6000 bytes.	The user input for the key exceeds the maximum.
The password must be at least 5 characters long, but no more than 15 characters long.	The user tries to enter a password that is too short or too long.
The password must contain at least one alphabetic and one non-alphabetic character.	The user tries to enter a password that does not have at least one alphabetic and one non-alphabetic character.
The privacy password must also be set when setting the privacy protocol.	Displays if the user tries to set the privacy protocol to des without a specifying a privacy password (-ppw command option).

Table 65. users command errors (continued)

Error message	Definition
The privacy password must be less than 32 characters long.	A user tries to set a privacy password that is longer than 31 characters.
The user index must be different than that of the current user.	The user tries to issue a command to delete the account of current user.
The username cannot be longer than 15 characters.	A user tries to set a user name that is longer than 15 characters.
There was a problem retrieving the file.	An error occurs while the management module is retrieving the file.
Unable to change password. The minimum password change interval has not expired. Please try again later.	The user tries to issue a command to change a password while the minimum password change interval has not expired.
Unable to read the complex password requirement.	An error occurs while the management module is reading the complex password requirement.
Unable to read the password required setting.	An error occurs while the management module is reading the password required setting.
Unexpected error: Unable to change password.	An error occurs while the management module is changing the password.
When creating a new user, a username and authority level must be specified.	The user tries to issue a command to create a user without the -n and -a options.
When creating a new user, all options are required.	A user tries to create a new user without defining all of the command options and arguments.

---

## Appendix. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about IBM products, you will find a wide variety of sources available from IBM to assist you. This section contains information about where to go for additional information about IBM and IBM products, what to do if you experience a problem with your system, and whom to call for service, if it is necessary.

---

### Before you call

Before you call, make sure that you have taken these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Use the troubleshooting information in your system documentation, and use the diagnostic tools that come with your system. Information about diagnostic tools is in the *Problem Determination and Service Guide* on the IBM Documentation CD that comes with your system.
- Go to the IBM support Web site at <http://www.ibm.com/systems/support/> to check for technical information, hints, tips, and new device drivers or to submit a request for information.

You can solve many problems without outside assistance by following the troubleshooting procedures that IBM provides in the online help or in the documentation that is provided with your IBM product. The documentation that comes with IBM systems also describes the diagnostic tests that you can perform. Most systems, operating systems, and programs come with documentation that contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

---

### Using the documentation

Information about your IBM system and preinstalled software, if any, or optional device is available in the documentation that comes with the product. That documentation can include printed documents, online documents, readme files, and help files. See the troubleshooting information in your system documentation for instructions for using the diagnostic programs. The troubleshooting information or the diagnostic programs might tell you that you need additional or updated device drivers or other software. IBM maintains pages on the World Wide Web where you can get the latest technical information and download device drivers and updates. To access these pages, go to <http://www.ibm.com/systems/support/> and follow the instructions. Also, some documents are available through the IBM Publications Center at <http://www.ibm.com/shop/publications/order/>.

---

## Getting help and information from the World Wide Web

On the World Wide Web, the IBM Web site has up-to-date information about IBM systems, optional devices, services, and support. The address for IBM System x and xSeries information is <http://www.ibm.com/systems/x/>. The address for IBM BladeCenter information is <http://www.ibm.com/systems/bladecenter/>. The address for IBM IntelliStation<sup>®</sup> information is <http://www.ibm.com/intellistation/>.

You can find service information for IBM systems and optional devices at <http://www.ibm.com/systems/support/>.

---

## Software service and support

Through IBM Support Line, you can get telephone assistance, for a fee, with usage, configuration, and software problems with System x and xSeries servers, BladeCenter products, IntelliStation workstations, and appliances. For information about which products are supported by Support Line in your country or region, see <http://www.ibm.com/services/sl/products/>.

For more information about Support Line and other IBM services, see <http://www.ibm.com/services/>, or see <http://www.ibm.com/planetwide/> for support telephone numbers. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

---

## Hardware service and support

You can receive hardware service through your IBM reseller or IBM Services. To locate a reseller authorized by IBM to provide warranty service, go to <http://www.ibm.com/partnerworld/> and click **Find a Business Partner** on the right side of the page. For IBM support telephone numbers, see <http://www.ibm.com/planetwide/>. In the U.S. and Canada, call 1-800-IBM-SERV (1-800-426-7378).

In the U.S. and Canada, hardware service and support is available 24 hours a day, 7 days a week. In the U.K., these services are available Monday through Friday, from 9 a.m. to 6 p.m.

---

## IBM Taiwan product service

台灣 IBM 產品服務聯絡方式：  
台灣國際商業機器股份有限公司  
台北市松仁路 7 號 3 樓  
電話：0800-016-888

IBM Taiwan product service contact information:

IBM Taiwan Corporation  
3F, No 7, Song Ren Rd.  
Taipei, Taiwan  
Telephone: 0800-016-888



---

## Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing  
IBM Corporation  
North Castle Drive  
Armonk, NY 10504-1785  
U.S.A.*

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product, and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

---

## Trademarks

IBM, the IBM logo, and [ibm.com](http://ibm.com)<sup>®</sup> are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. If these and other IBM trademarked terms are marked on their first occurrence in this information with a trademark symbol (<sup>®</sup> or <sup>™</sup>), these symbols indicate U.S. registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common

law trademarks in other countries. A current list of IBM trademarks is available on the Web at "Copyright and trademark information" at <http://www.ibm.com/legal/copytrade.shtml>.

Adobe and PostScript are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Cell Broadband Engine is a trademark of Sony Computer Entertainment, Inc., in the United States, other countries, or both and is used under license therefrom.

Intel, Intel Xeon, Itanium, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Java™ and all Java-based trademarks are trademarks of Sun Microsystems, Inc., in the United States, other countries, or both.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Other company, product, or service names may be trademarks or service marks of others.

---

## Important notes

Processor speeds indicate the internal clock speed of the microprocessor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1024 bytes, MB stands for 1 048 576 bytes, and GB stands for 1 073 741 824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1 000 000 bytes, and GB stands for 1 000 000 000 bytes. Total user-accessible capacity may vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard disk drive bays with the largest currently supported drives available from IBM.

Maximum memory might require replacement of the standard memory with an optional memory module.

IBM makes no representation or warranties regarding non-IBM products and services that are ServerProven, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. These products are offered and warranted solely by third parties.

IBM makes no representations or warranties with respect to non-IBM products. Support (if any) for the non-IBM products is provided by the third party, not IBM.

Some software may differ from its retail version (if available), and may not include user manuals or all program functionality.



---

# Index

## Special characters

! 57

? 55

## A

accessibility features for this product 2

accumulate timeout

set for SOL 92

acknowledge alarms

alarm ID 20

complete alarm key 20

generator ID 19

generator information 20

alarm 18

acknowledge (alarm ID) 20

acknowledge (complete alarm key) 20

acknowledge (generator ID) 19

acknowledge (generator information) 20

clear (alarm ID) 21

clear (complete alarm key) 21

clear (generator ID) 20

clear (generator information) 21

display (alarm ID) 19

display (all) 18

display (complete alarm key) 19

display (generator ID) 18

display (generator information) 19

display (power) 18

options

c, a 21

c, g 20

c, k 21

c, o 21

p 18

q, a 19

q, g 18

q, k 19

q, o 19

r, a 20

r, g 19

r, k 20

r, o 20

s, l 21

set 21

alarm command 18

alarm command errors 116

alarm commands

example 22

alert notification method, set 26

alert recipient, create 24, 25

alert recipient, delete 23

alert recipient, set email address 27

alert recipient, set hostname for alerts 27

alert recipient, set IP address for alerts 27

alert recipient, set name 25

alert recipient, set status 25

alert recipients, manage 23

alert type, filter 26

alert type, set 26

alertentries 23

options

1 through 12 23

create (n, status, f, t, e, i) 24

del 23

e 27

f 26

i 27

n 25

status 25

t 26

alertentries command 23

alertentries command errors 117

alertentries commands

example 27

alerts, display 53

algorithms, encryption 10

all information reload 66

assistance, getting 145

attributes, display for firmware 98

authority, command 6

## B

blade server

boot 29

boot (to console) 29

command target 45

config command 36, 38

example 38

cycle power 29, 72

display name 36

display power state 72

enable local power control 73

enable Wake on LAN 73

power off 72

power on 72

power on (to console) 72

reset 29, 76

reset (clear NVRAM) 77

reset (run diagnostics with boot sequence) 78

reset (run diagnostics) 77

reset (to console) 29, 76

reset (with NMI) 77

set as KVM owner 67

set as media tray owner 70

set name 36

shutdown 72, 79

turn off 72

turn on 72

turn on (to console) 72

blade servers

display starting IP address 62

set starting IP address 62

BladeCenter T specific commands 17

BladeCenter unit

command target 44

configuring 12

display serial number 36

display type/model 36

display uuid 36

blink location LED 58

blower

command target 46

BMC

command target 45

boot 29

blade server 29

options

c 29

p powercycle 29

p reset 29

boot (to console)

blade server 29

boot command errors 118

boot commands 29

example 29

built-in commands 16

## C

change command environment 15, 44

clear

options

config 30

clear alarms

alarm ID 21

complete alarm key 21

generator ID 20

generator information 21

clear command 30

clear command errors 118

clear commands

example 30

clear event log

management module 31

clear management module event log

commands 31

example 31

clearlog

l 31

clearlog command errors 118

clearlog commands 31

example 31

CLI key sequence

set for SOL 93

clock 32

options

d 32

dst 34

g 33

t 32

clock command errors 119

clock commands 32

example 35

- clock settings
  - display for management module 32
- command
  - health 52, 53
  - system physical configuration 69
- command authority 6
- command environment selecting 4
- command history 57
- command redirect 15, 44
- command syntax 17
- command target 15, 44
  - blade server 45
  - BladeCenter unit 44
  - blower 46
  - BMC 45
  - high-speed expansion card 45
  - I/O module 46
  - I/O-expansion card 45
  - integrated system management processor 45
  - management module 45
  - media tray 46
  - microprocessor 45
  - power module 46
  - service processor 45
  - storage expansion unit 45
  - switch module 46
  - temporary 5
  - view 69
- command target selection 4
- command-line interface
  - errors 113
  - guidelines 3
    - case sensitivity 4
    - command history 4
    - data types 4
    - delimiters 4
    - help 4
    - options 3
    - output format 4
    - strings 4
  - introduction 1
  - starting 9
  - using 3, 15
- command-line session configuration
  - display for management module 97
- command-line timeout
  - set for management module 97
- commands
  - alarm 18, 22
  - alertentries 23, 27
  - boot 29
  - built-in 16
  - clear 30
  - clear management module event log 31
  - clearlog 31
  - clock 32, 35
  - common 16
  - config 36, 38
  - configuration 16
  - console 39
  - dhcpinfo 40
  - display management module event log 41
  - displaylog 41
  - dns 42
- commands (*continued*)
  - environment 44, 46
  - event log, clear for management module 31
  - event log, display for management module 41
  - examples
    - alarm 22
    - alertentries 27
    - blade server name 38
    - boot 29
    - clear 30
    - clear management module event log 31
    - clearlog 31
    - clock 35
    - config 38
    - console 39
    - DHCP settings for management module 40
    - dhcpinfo 40
    - display KVM owner 67
    - display management module event log 41
    - display media tray owner 71
    - displaylog 41
    - DNS 42
    - env 46
    - environment 46
    - environment redirect 47
    - Ethernet network settings for management module 63
    - exit 48
    - fuelg 50
    - health 53
    - help 55
    - history 57
    - identify 58
    - ifconfig 63
    - info 66
    - kvm 67
    - list 69
    - management module DHCP settings 40
    - management module DNS 42
    - management module Ethernet network settings 63
    - management module event log clear 31
    - management module event log display 41
    - management module name 38
    - management module SLP configuration 80
    - management module SMTP settings 81
    - management module SNMP settings 90
    - management module telnet configuration 97
    - management module uplink failover 101
    - mt 71
    - name for blade server 38
    - name for management module 38
    - power 74
    - reset 78
- commands (*continued*)
  - examples (*continued*)
    - Serial Over LAN 94
    - set KVM owner 67
    - set media tray owner 71
    - shutdown 79
    - slp 80
    - SLP configuration for management module 80
    - smtp 81
    - SMTP settings for management module 81
    - snmp 90
    - SNMP settings for management module 90
    - sol 94
    - syntax help 55
    - tcpmdmode 95
    - telnetcfg 97
    - update 99
    - uplink 101
    - users 110
  - exit 48
  - fuelg 49, 50
  - help 55
  - history 57
  - identify 58
  - ifconfig 59, 63
  - info 65, 66
  - kvm 67
  - LED 17
  - list 69
  - management module event log 17
  - management module failover 101
  - memory 17
  - mt 70, 71
  - power 72, 74
  - power control 17
  - power management 17
  - reset 76, 78
  - reset command 17
  - Serial Over LAN 91, 94
  - session command 17
  - shutdown 79
  - slp 80
  - smtp 81
  - snmp 82, 90
  - SOL 91, 94
  - system management command 17
  - tcpmdmode 95
  - telnet configuration 97
  - telnetcfg 97
  - update 98, 99
  - uplink 101
  - users 103, 110
- common commands 16
- common errors 114
- communicating with IBM Director 95
- communication
  - out-of-band 95
- component and reloading information 65
- component information display 65
- config 36
  - options
    - contact 37, 38
    - loc 36

- config (*continued*)
  - options (*continued*)
    - name 36
- config command 36
  - example 38
- config command errors 120
- configuration
  - view for management module 69
  - view tree for system 69
- configuration commands 16
- configuration method
  - set for channel 0 of management module 60
- configure SLP command
  - example 80
- console 39
  - create override SOL session 39
  - create SOL session 39
    - options
      - o 39
    - persistent console 39
  - console command 39
  - console command errors 120
  - console commands
    - example 39
- contact name
  - display for management module 36
  - set for management module 37, 38
- create alert recipient 24, 25
- create override SOL session 39
- create SOL session
  - persistent console 39
- create user 104, 105
- cycle power
  - blade server 29, 72
  - I/O module 72
  - switch module 72

## D

- data rate
  - set for channel 0 of management module 60
- date
  - display for management module 32
  - set for management module 32
- daylight-savings time mode
  - set for management module 34
- daylight-savings time setting
  - display for management module 32
- default IP address 10
- delete alert recipient 23
- delete user 103
- DHCP settings for management module
  - commands
    - example 40
- dhcpinfo
  - options
    - eth0 40
- dhcpinfo command errors 121
- dhcpinfo commands 40
  - example 40
- disable physical uplink failover
  - management module 101
- disable power domain quiet mode 50
- disable SOL
  - global 92

- display
  - clock settings, management module 32
  - date, management module 32
  - daylight-savings time setting, management module 32
  - GMT offset, management module 32
  - TCP command-mode session status 95
  - TCP command-mode session timeout 95
  - time, management module 32
- display (reset counter) event log
  - management module 41
- display alarms
  - alarm ID 19
  - all 18
  - complete alarm key 19
  - generator ID 18
  - generator information 19
  - power 18
- display alert properties (all recipients) 23
- display alert properties (single recipient) 23
- display alerts 53
- display all users 103
- display command-line session configuration
  - management module 97
- display component information 65
- display contact name
  - management module 36
- display DNS configuration
  - management module 42
- display Ethernet channel 0 configuration
  - management module 59
- display Ethernet channel 0 DHCP configuration
  - management module 40
- display Ethernet channel 1 configuration
  - management module 61
- display event log
  - management module 41
- display failover configuration
  - management module 101
- display firmware attributes 98
- display health status 52, 53
- display health status (tree) 52
- display KVM owner 67
- display location
  - management module 36
- display management module event log
  - commands 41
  - example 41
- display media tray owner 70
- display name
  - blade server 36
  - management module 36
- display network settings
  - I/O module 63
- display POST status
  - I/O module 74
  - switch module 74
- display power domain information
  - details 49

- display power domain information
  - overview 49
- display power state
  - blade server 72
  - I/O module 72
  - switch module 72
- display serial number
  - BladeCenter unit 36
- display single user 103
- display SLP settings
  - management module 80
- display SMTP server host name
  - management module 81
- display SMTP server IP address
  - management module 81
- display SNMP configuration
  - management module 82
- display starting IP address
  - blade servers 62
- display state
  - location LED 58
- display telnet configuration
  - management module 97
- display type/model
  - BladeCenter unit 36
- display uplink configuration
  - management module 101
- display uuid
  - BladeCenter unit 36
- displaylog 41
  - options
    - f 41
- displaylog command errors 121
- displaylog commands 41
  - example 41
- dns 42
  - options
    - i1 42
    - i2 42
    - i3 42
    - on 42
- DNS
  - enable for management module 42
- dns command errors 121
- dns commands 42
  - example 42
- DNS configuration
  - display for management module 42
- DNS first IP address
  - set for management module 42
- DNS second IP address
  - set for management module 42
- DNS third IP address
  - set for management module 42
- duplex mode
  - set for channel 0 of management module 60

## E

- enable
  - TCP command mode 95
- enable DNS
  - management module 42
- enable external management
  - I/O module 63

- enable external ports
  - I/O module 63
- enable fast POST
  - I/O module 73
- enable local KVM switching
  - globally 67
- enable local media tray switching
  - globally 70
- enable local power control
  - blade server 73
  - globally 73
- enable physical uplink failover
  - management module 101
- enable power domain quiet mode 50
- enable remote media tray switching
  - globally 70
- enable SNMP agent
  - management module (SNMPv1) 82
  - management module (SNMPv3) 82
- enable SNMP traps
  - management module 82
- enable SOL
  - global 92
- enable Wake on LAN
  - blade server 73
  - globally 72
- encryption algorithms 10
- end session 48
- ending an SOL session 14, 39
- env 44, 45
  - options
    - be 45
    - blade 45
    - blower 46
    - cpu 45
    - dtr 45
    - hsdc 45
    - mt 46
    - power 46
    - sp 45
    - switch 46
    - system (management module) 45
- env command errors 122
- env commands
  - example 46
- environment
  - blade server 45
  - BladeCenter unit 44
  - blower 46
  - BMC 45
  - high-speed expansion card 45
  - I/O module 46
  - I/O-expansion card 45
  - integrated system management processor 45
  - management module 45
  - media tray 46
  - microprocessor 45
  - power module 46
  - service processor 45
  - storage expansion unit 45
  - switch module 46
- environment commands 44
  - example 46
- errors
  - alarm command 116
  - alertentries command 117

- errors (*continued*)
  - boot command 118
  - clear command 118
  - clearlog command 118
  - clock command 119
  - command-line interface 113
  - common 114
  - config command 120
  - console command 120
  - dhcpinfo command 121
  - displaylog command 121
  - dns command 121
  - env command 122
  - exit command 122
  - fuelg command 122
  - health command 125
  - help command 126
  - history command 126
  - identify command 126
  - ifconfig command 127
  - info command 130
  - kvm command 131
  - list command 131
  - mt command 131
  - power command 132
  - reset command 132
  - shutdown command 133
  - slp command 133
  - smtp command 133
  - snmp command 134
  - sol command 135
  - tcpcmdmode command 136
  - telnetcfg command 137
  - update command 137
  - uplink command 140
  - users command 140
- Ethernet
  - configuring remote connection 13
- Ethernet channel 0 configuration
  - display for management module 59
- Ethernet channel 0 configuration method
  - set for management module 60
- Ethernet channel 0 data rate
  - set for management module 60
- Ethernet channel 0 DHCP configuration
  - display for management module 40
- Ethernet channel 0 duplex mode
  - set for management module 60
- Ethernet channel 0 gateway IP address
  - set for management module 59
- Ethernet channel 0 hostname
  - set for management module 60
- Ethernet channel 0 MAC address
  - set for management module 61
- Ethernet channel 0 MTU
  - set for management module 61
- Ethernet channel 0 static IP address
  - set for management module 59
- Ethernet channel 0 subnet mask
  - set for management module 59
- Ethernet channel 1
  - disable for management module 62
  - enable for management module 62
- Ethernet channel 1 configuration
  - display for management module 61
- Ethernet channel 1 gateway IP address
  - set for management module 61

- Ethernet channel 1 MAC address
  - set for management module 62
- Ethernet channel 1 static IP address
  - set for management module 61
- Ethernet channel 1 subnet mask
  - set for management module 62
- Ethernet network settings for management module commands
  - example 63
- event log
  - clear for management module 31
  - display (reset counter) for management module 41
  - display for management module 41
- event log, clear for management module commands 31
- event log, display for management module commands 41
- exit 48
- exit command 48
- exit command errors 122
- exit commands
  - example 48
- external management
  - enable for I/O module 63
- external ports
  - enable for I/O module 63

## F

- failover configuration
  - display for management module 101
- fast POST
  - enable for I/O module 73
- filter alert type 26
- firmware
  - display attributes 98
  - update 98
  - update (verbose) 99
- firmware requirements 1
- firmware update 98
- flash location LED 58
- fuelg 49
  - options
    - os 49
    - pm 49
    - qm 50
- fuelg command errors 122
- fuelg commands 49
  - example 50

## G

- gateway IP address
  - set for channel 0 of management module 59
  - set for channel 1 of management module 61
- getting help 145
- global
  - enable local KVM switching 67
  - enable local media tray switching 70
  - enable local power control 73
  - enable remote media tray switching 70
  - enable Wake on LAN 72



- global disable
  - SOL 92
- global enable
  - SOL 92
- GMT offset
  - display for management module 32
  - set for management module 33
- guidelines
  - case sensitivity 4
  - command history 4
  - data types 4
  - delimiters 4
  - help 4
  - options 3
  - output format 4
  - overview of 3
  - strings 4

## H

- hardware requirements 1
- hardware service and support
  - IBM reseller 146
  - IBM Services 146
  - telephone numbers 146
- health 52
  - display status 52
  - display status (tree) 52
  - display status and alerts 53
  - options
    - f 53
    - l 52
- health command 52, 53
  - example 53
- health command errors 125
- help 15, 55
- help command 55
- help command errors 126
- help commands
  - example 55
- help, getting 145
- high-speed expansion card
  - command target 45
- history 57
- history command 57
- history command errors 126
- history commands
  - example 57
- host name
  - set for channel 0 of management module 60

## I

- I/O module
  - command target 46
  - cycle power 72
  - display network settings 63
  - display POST status 74
  - display power state 72
  - enable external management 63
  - enable external ports 63
  - enable fast POST 73
  - power off 72
  - power on 72
  - reset 76

- I/O module (*continued*)
  - reset (extended diagnostics) 76
  - reset (full diagnostics) 76
  - reset (standard diagnostics) 76
  - reset configuration 30
  - set IP address 63
  - turn off 72
  - turn on 72
- I/O-expansion card
  - command target 45
- IBM Director
  - communication 95
- IBM Support Line 146
- identify 58
  - options
    - s 58
    - s, d 58
- identify command 58
- identify command errors 126
- identify commands
  - example 58
- ifconfig 62, 63
  - options
    - em, enabled 63
    - ep, enabled 63
    - eth0 59
    - eth0, c 60
    - eth0, d 60
    - eth0, g 59
    - eth0, i 59
    - eth0, l 61
    - eth0, m 61
    - eth0, n 60
    - eth0, r 60
    - eth0, s 59
    - eth1 61
    - eth1, down 62
    - eth1, g 61
    - eth1, i 61
    - eth1, l 62
    - eth1, s 62
    - eth1, up 62
    - i 62, 63
- ifconfig command errors 127
- ifconfig commands 59
  - example 63
- info 65
  - options
    - reload -fw 65
    - reload -hw 65
  - optionsall
    - reload 66
  - optionsmac
    - reload 65
  - optionswwn
    - reload 65
- info command 65
- info command errors 130
- info commands
  - example 66
- information about components and reloading components 65
- information display, component 65
- information display, power domain (detailed) 49
- information display, power domain (overview) 49

- information reload, all 66
- information reload, firmware 65
- information reload, hardware 65
- information reload, MAC addresses 65
- information reload, WWN 65
- integrated system management processor
  - command target 45
- IP address
  - display starting for blade servers 62
  - set for I/O module 63
  - set for management module 59
  - set starting for blade servers 62
- IP address, default 10
- ISMP
  - reset 76

## J

- JS20 blade server commands
  - reset (clear NVRAM) 77
  - reset (run diagnostics with boot sequence) 78
  - reset (run diagnostics) 77
  - reset (with NMI) 77

## K

- kvm 67
  - options
    - b 67
    - local 67
- KVM
  - display owner 67
  - set owner 67
- kvm command errors 131
- kvm commands 67
  - example 67

## L

- LED (location), control 58
- LED commands 17
- light location LED 58
- light location LED (BladeCenter unit)
  - time period 58
- list 69
  - options
    - l 69
- list command
  - example 69
- list command errors 131
- local KVM switching
  - enable globally 67
- local media tray switching
  - enable globally 70
- local power control
  - enable for blade server 73
  - enable globally 73
- location
  - display for management module 36
  - set for management module 36
- location LED
  - blink 58
  - display state 58
  - flash 58
  - light 58

location LED (*continued*)  
  light (BladeCenter unit)  
    time period 58  
    turn off 58  
location LED control 58

## M

MAC address  
  set for channel 0 of management module 61  
  set for channel 1 of management module 62  
manage alert recipients 23  
management module  
  cabling 8  
  clear event log 31  
  clear event log commands  
    example 31  
  command target 45  
  command-line session configuration 97  
  command-line timeout 97  
  config command 36, 38  
    example 38  
  configuring 12  
  create alert recipient 24, 25  
  create user 104, 105  
  default IP address 10  
  delete alert recipient 23  
  delete user 103  
  DHCP settings commands  
    example 40  
  dhcpinfo commands 40  
  direct connection 9  
  disable Ethernet channel 1 62  
  disable physical uplink failover 101  
  display (reset counter) event log 41  
  display alert properties (all recipients) 23  
  display alert properties (single recipient) 23  
  display all users 103  
  display clock settings 32  
  display contact name 36  
  display date 32  
  display daylight-savings time setting 32  
  display DNS configuration 42  
  display Ethernet channel 0 configuration 59  
  display Ethernet channel 0 DHCP configuration 40  
  display Ethernet channel 1 configuration 61  
  display event log 41  
  display event log commands  
    example 41  
  display GMT offset 32  
  display location 36  
  display name 36  
  display single user 103  
  display SLP settings 80  
  display SMTP server host name 81  
  display SMTP server IP address 81  
  display SNMP configuration 82  
  display time 32

management module (*continued*)  
  dns commands 42  
    example 42  
  enable DNS 42  
  enable Ethernet channel 1 62  
  enable physical uplink failover 101  
  enable SNMP agent (SNMPv1) 82  
  enable SNMP agent (SNMPv3) 82  
  enable SNMP traps 82  
  Ethernet network settings commands  
    example 63  
  failover configuration 101  
  filter alert type 26  
  IBM Director communication 95  
  ifconfig commands 59, 63  
  kvm commands 67  
  mt commands 70, 71  
  network connection 9  
  physical uplink failover delay 101  
  reset (failover) 76  
  reset (primary) 76  
  reset configuration 30  
  set alert notification method 26  
  set alert recipient email address 27  
  set alert recipient name 25  
  set alert recipient status 25  
  set alert type 26  
  set contact name 37, 38  
  set date 32  
  set daylight-savings time mode 34  
  set DNS first IP address 42  
  set DNS second IP address 42  
  set DNS third IP address 42  
  set Ethernet channel 0 configuration method 60  
  set Ethernet channel 0 data rate 60  
  set Ethernet channel 0 duplex mode 60  
  set Ethernet channel 0 gateway IP address 59  
  set Ethernet channel 0 hostname 60  
  set Ethernet channel 0 MAC address 61  
  set Ethernet channel 0 MTU 61  
  set Ethernet channel 0 static IP address 59  
  set Ethernet channel 0 subnet mask 59  
  set Ethernet channel 1 gateway IP address 61  
  set Ethernet channel 1 MAC address 62  
  set Ethernet channel 1 static IP address 61  
  set Ethernet channel 1 subnet mask 62  
  set GMT offset 33  
  set hostname for alerts 27  
  set IP address 59  
  set IP address for alerts 27  
  set location 36  
  set name 36  
  set privacy password (SNMPv3) 109  
  set server host name 81  
  set server IP address 81  
  set SLP address type 80  
  set SLP multicast address 80

management module (*continued*)  
  set SNMP community 1 first host name - get 84  
  set SNMP community 1 first host name to set 83  
  set SNMP community 1 IP address (first host) to get 84  
  set SNMP community 1 IP address (first host) to set 83  
  set SNMP community 1 IP address (second host) 84  
  set SNMP community 1 IP address (third host) 85  
  set SNMP community 1 name 82  
  set SNMP community 1 second host name 84  
  set SNMP community 1 third host name 85  
  set SNMP community 1 view type (SNMPv3) 85  
  set SNMP community 2 first host name 86  
  set SNMP community 2 IP address (first host) 86  
  set SNMP community 2 IP address (second host) 86  
  set SNMP community 2 IP address (third host) 87  
  set SNMP community 2 name 85  
  set SNMP community 2 second host name 86  
  set SNMP community 2 third host name 87  
  set SNMP community 2 view type (SNMPv3) 87  
  set SNMP community 3 first host name 88  
  set SNMP community 3 IP address (first host) 88  
  set SNMP community 3 IP address (second host) 88  
  set SNMP community 3 IP address (third host) 89  
  set SNMP community 3 name 87  
  set SNMP community 3 second host name 88  
  set SNMP community 3 third host name 89  
  set SNMP community 3 view type (SNMPv3) 89  
  set SNMP contact name 89  
  set SNMP location 90  
  set time 32  
  set user access type (SNMPv3) 110  
  set user authentication protocol (SNMPv3) 109  
  set user authority level 107, 108  
  set user context name (SNMPv3) 108  
  set user hostname (SNMPv3 traps) 110  
  set user IP address (SNMPv3 traps) 110  
  set user name 106  
  set user password 106  
  set user privacy protocol (SNMPv3) 109  
  slp command 80

- management module (*continued*)
  - example 80
  - smtp commands 81
  - SMTP settings commands
    - example 81
  - snmp commands 82, 90
  - SNMP settings commands
    - example 90
  - SSH connection 11
  - telnet configuration 97
  - telnet timeout 97
  - uplink configuration 101
  - view configuration 69
- management module (primary)
  - reset 76
- management module event log
  - commands 17
- management module failover
  - commands 101
- management module telnet configuration
  - commands
    - example 97
- management module uplink failover
  - commands
    - example 101
- management module, user accounts 103
- management-module firmware 1
- media tray
  - command target 46
  - display owner 70
  - set owner 70
- memory commands 17
- microprocessor
  - command target 45
- mt 70
  - options
    - b 70
    - local 70
    - remote 70
- mt command errors 131
- mt commands 70
  - example 71
- MTU
  - set for channel 0 of management module 61

## N

- name
  - display for blade server 36
  - display for management module 36
  - set for blade server 36
  - set for management module 36
- name (contact)
  - set for management module 37, 38
- network settings
  - display for I/O module 63
- notes, important 148
- notices 147
- notification method, set for alerts 26

## O

- online documentation 1
- out-of-band communication, IBM Director 95

- override persistent command environment 5

## P

- persistent command environment
  - override 5
- persistent command target 4
- POST status
  - display for I/O module 74
  - display for switch module 74
- power
  - options
    - cycle 72
    - cycle, c 72
    - fp 73
    - local 73
    - off 72
    - on 72
    - on, c 72
    - softoff 72
    - state 72
    - state, post 74
    - wol 72, 73
- power command errors 132
- power commands 72
  - example 74
- power control commands 17
- power domain
  - disable quiet mode 50
  - enable quiet mode 50
- power domain information display (detailed) 49
- power domain information display (overview) 49
- power domain redundancy loss policy, set 49
- power management commands 17
- power module
  - command target 46
- power off
  - blade server 72
  - I/O module 72
  - switch module 72
- power on
  - blade server 72
  - I/O module 72
  - switch module 72
- power on (to console)
  - blade server 72
- power state
  - display for blade server 72
  - display for I/O module 72
  - display for switch module 72
- primary management module 5

## Q

- quiet mode, disable 50
- quiet mode, enable 50

## R

- redirect command 15, 44
- redundancy loss policy, power domain (set) 49

- reload all information 66
- reload firmware information 65
- reload hardware information 65
- reload MAC address information 65
- reload MAC addresses information 65
- reload WNN information 65
- remote media tray switching
  - enable globally 70
- required, firmware 1
- required, hardware 1
- reset 76
  - blade server 29, 76
  - I/O module 76
  - ISMP 76
  - management module (primary) 76
  - options
    - c 76
    - clr 77
    - ddg 78
    - dg 77
    - exd 76
    - f 76
    - full 76
    - sft 77
    - std 76
    - service processor 76
    - switch module 76
- reset (clear NVRAM)
  - blade server 77
- reset (extended diagnostics)
  - I/O module 76
  - switch module 76
- reset (failover)
  - management module 76
- reset (full diagnostics)
  - I/O module 76
  - switch module 76
- reset (run diagnostics with boot sequence)
  - blade server 78
- reset (run diagnostics)
  - blade server 77
- reset (standard diagnostics)
  - I/O module 76
  - switch module 76
- reset (to console)
  - blade server 29, 76
- reset (with NMI)
  - blade server 77
- reset blade server key sequence
  - set for SOL 93
- reset command 17
- reset command errors 132
- reset commands 76
  - example 78
- reset configuration
  - I/O module 30
  - management module 30
  - switch module 30
- reset default configuration 30
- responding to thermal events 50
- retry count
  - set for SOL 92
- retry interval
  - set for SOL 91

## S

- secure command-line interface 9
- Secure Shell connection clients 10
- Secure Shell server
  - using 11
- security 9
- selecting command environment 4
- selecting command target 4
- send threshold
  - set for SOL 92
- Serial Over LAN 14
- Serial Over LAN commands 91
  - example 94
- server host name
  - set for management module 81
- server IP address
  - set for management module 81
- service processor
  - command target 45
  - reset 76
- session command 17
- set
  - date, management module 32
  - daylight-savings time mode, management module 34
  - GMT offset, management module 33
  - TCP command-mode session timeout 95
  - time, management module 32
- set accumulate timeout
  - SOL 92
- set alarm 21
- set alert notification method 26
- set alert recipient email address 27
- set alert recipient name 25
- set alert recipient status 25
- set alert type 26
- set CLI key sequence
  - SOL 93
- set command-line timeout
  - management module 97
- set contact name
  - management module 37, 38
- set DNS first IP address
  - management module 42
- set DNS second IP address
  - management module 42
- set DNS third IP address
  - management module 42
- set Ethernet channel 0 configuration method
  - management module 60
- set Ethernet channel 0 data rate
  - management module 60
- set Ethernet channel 0 duplex mode
  - management module 60
- set Ethernet channel 0 gateway IP address
  - management module 59
- set Ethernet channel 0 hostname
  - management module 60
- set Ethernet channel 0 MAC address
  - management module 61
- set Ethernet channel 0 MTU
  - management module 61
- set Ethernet channel 0 static IP address
  - management module 59
- set Ethernet channel 0 subnet mask
  - management module 59
- set Ethernet channel 1 gateway IP address
  - management module 61
- set Ethernet channel 1 MAC address
  - management module 62
- set Ethernet channel 1 static IP address
  - management module 61
- set Ethernet channel 1 subnet mask
  - management module 62
- set hostname for alerts 27
- set IP address
  - I/O module 63
  - management module 59
- set IP address for alerts 27
- set KVM owner 67
- set location
  - management module 36
- set media tray owner 70
- set name
  - blade server 36
  - management module 36
- set physical uplink failover delay
  - management module 101
- set power domain redundancy loss policy 49
- set privacy password (SNMPv3) 109
- set reset base server key sequence
  - SOL 93
- set retry count
  - SOL 92
- set retry interval
  - SOL 91
- set send threshold
  - SOL 92
- set server host name
  - management module 81
- set server IP address
  - management module 81
- set SLP address type
  - management module 80
- set SLP multicast address
  - management module 80
- set SNMP community 1 first host name
  - get management module 84
- set SNMP community 1 first host name to set
  - management module 83
- set SNMP community 1 IP address (first host) to get
  - management module 84
- set SNMP community 1 IP address (first host) to set
  - management module 83
- set SNMP community 1 IP address (second host)
  - management module 84
- set SNMP community 1 IP address (third host)
  - management module 85
- set SNMP community 1 name
  - management module 82
- set SNMP community 1 second host name
  - management module 84
- set SNMP community 1 third host name
  - management module 85
- set SNMP community 1 view type (SNMPv3)
  - management module 85
- set SNMP community 2 first host name
  - management module 86
- set SNMP community 2 IP address (first host)
  - management module 86
- set SNMP community 2 IP address (second host)
  - management module 86
- set SNMP community 2 IP address (third host)
  - management module 87
- set SNMP community 2 name
  - management module 85
- set SNMP community 2 second host name
  - management module 86
- set SNMP community 2 third host name
  - management module 87
- set SNMP community 2 view type (SNMPv3)
  - management module 87
- set SNMP community 3 first host name
  - management module 88
- set SNMP community 3 IP address (first host)
  - management module 88
- set SNMP community 3 IP address (second host)
  - management module 88
- set SNMP community 3 IP address (third host)
  - management module 89
- set SNMP community 3 name
  - management module 87
- set SNMP community 3 second host name
  - management module 88
- set SNMP community 3 third host name
  - management module 89
- set SNMP community 3 view type (SNMPv3)
  - management module 89
- set SNMP contact name
  - management module 89
- set SNMP location
  - management module 90
- set starting IP address
  - blade servers 62
- set telnet timeout
  - management module 97
- set user access type (SNMPv3) 110
- set user authentication protocol (SNMPv3) 109
- set user authority level 107, 108
- set user context name (SNMPv3) 108
- set user hostname (SNMPv3 traps) 110
- set user IP address (SNMPv3 traps) 110
- set user name 106
- set user password 106
- set user privacy protocol (SNMPv3) 109
- set VLAN ID
  - SOL 93

- shutdown
  - blade server 72, 79
  - options
    - f 79
- shutdown command errors 133
- shutdown commands 79
  - example 79
- slp 80
  - options
    - i 80
    - t 80
- SLP address type
  - set for management module 80
- slp command 80
  - example 80
- slp command errors 133
- SLP multicast address
  - set for management module 80
- SLP settings
  - display for management module 80
- smtp 81
  - options
    - s 81
- smtp command errors 133
- smtp commands 81
  - example 81
- SMTP server host name
  - display for management module 81
- SMTP server IP address
  - display for management module 81
- SMTP settings for management module
  - commands
    - example 81
- snmp 82
  - options
    - ca1 get -cli1 0.0.0.0 84
    - ca1 set -cli1 0.0.0.0 83
    - a, on 82
    - a3, on 82
    - c1 82
    - cli2 84
    - cli3 85
    - c2 85
    - c2i1 86
    - c2i2 86
    - c2i3 87
    - c3 87
    - c3i1 88
    - c3i2 88
    - c3i3 89
    - ca1 85
    - ca2 87
    - ca3 89
    - cn 89
    - l 90
    - t, on 82
- SNMP agent
  - enable for management module (SNMPv1)
    - SNMPv1 82
  - enable for management module (SNMPv3)
    - SNMPv3 82
- snmp command errors 134
- snmp commands 82
  - example 90
- SNMP community 1 first host name
  - set to get for management module 84
- SNMP community 1 first host name to set
  - set for management module 83
- SNMP community 1 IP address (first host) to get
  - set to get for management module 84
- SNMP community 1 IP address (first host) to set
  - set for management module 83
- SNMP community 1 IP address (second host)
  - set for management module 84
- SNMP community 1 IP address (third host)
  - set for management module 85
- SNMP community 1 name
  - set for management module 82
- SNMP community 1 second host name
  - set for management module 84
- SNMP community 1 third host name
  - set for management module 85
- SNMP community 1 view type
  - set for management module (SNMPv3) 85
- SNMP community 2 first host name
  - set for management module 86
- SNMP community 2 IP address (first host)
  - set for management module 86
- SNMP community 2 IP address (second host)
  - set for management module 86
- SNMP community 2 IP address (third host)
  - set for management module 87
- SNMP community 2 name
  - set for management module 85
- SNMP community 2 second host name
  - set for management module 86
- SNMP community 2 third host name
  - set for management module 87
- SNMP community 2 view type
  - set for management module (SNMPv3) 87
- SNMP community 3 first host name
  - set for management module 88
- SNMP community 3 IP address (first host)
  - set for management module 88
- SNMP community 3 IP address (second host)
  - set for management module 88
- SNMP community 3 IP address (third host)
  - set for management module 89
- SNMP community 3 name
  - set for management module 87
- SNMP community 3 second host name
  - set for management module 88
- SNMP community 3 third host name
  - set for management module 89
- SNMP community 3 view type
  - set for management module (SNMPv3) 89
- SNMP configuration
  - display for management module 82
- SNMP contact name
  - set for management module 89
- SNMP location
  - set for management module 90
- SNMP settings for management module
  - commands
    - example 90
- SNMP traps
  - disable for management module 82
  - enable for management module 82
- SNMPv3
  - community 1 view type 85
  - community 2 view type 87
  - community 3 view type 89
  - privacy password 109
  - trap receiver IP address or hostname 110
  - user access type 110
  - user authentication protocol 109
  - user context name 108
  - user privacy protocol 109
- software service and support 146
- sol 91
  - options
    - c 92
    - e 93
    - i 91
    - r 93
    - s 92
    - status 92
    - t 92
    - v 93
- SOL 14, 39
  - global disable 92
  - global enable 92
  - set accumulate timeout 92
  - set CLI key sequence 93
  - set reset blade server key sequence 93
  - set retry count 92
  - set retry interval 91
  - set send threshold 92
  - set VLAN ID 93
  - status 91
- sol command errors 135
- sol commands
  - example 94
- SOL commands 91
- SOL session
  - ending 14, 39
  - starting 14
- SSH clients 10
- SSH connection 11
- standby management modules 5
- starting a session using SSH 11
- starting a session using Telnet 10
- starting an SOL session 14
- starting command-line interface 9
- static IP address
  - set for channel 0 of management module 59

- static IP address (*continued*)
  - set for channel 1 of management module 61
- status
  - SOL 91
- storage expansion unit
  - command target 45
- subnet mask
  - set for channel 0 of management module 59
  - set for channel 1 of management module 62
- support, web site 145
- switch module
  - command target 46
  - cycle power 72
  - display POST status 74
  - display power state 72
  - power off 72
  - power on 72
  - reset 76
  - reset (extended diagnostics) 76
  - reset (full diagnostics) 76
  - reset (standard diagnostics) 76
  - reset configuration 30
  - turn off 72
  - turn on 72
- syntax help 55
- syntax help commands
  - example 55
- system
  - view configuration tree 69
- system management command 17
- system physical configuration
  - command 69

## T

- target 15, 44
- TCP command mode
  - disable 95
  - enable 95
- TCP command-mode session status
  - display 95
- TCP command-mode session timeout
  - display 95
  - set 95
- tcpcmdmode 95
  - options
    - status, on, off 95
    - t 95
- tcpcmdmode command errors 136
- tcpcmdmode commands 95
  - example 95
- telephone numbers
  - hardware service and support 146
- telnet configuration
  - display for management module 97
- telnet configuration commands 97
- Telnet connection 9, 10
- telnet timeout
  - set for management module 97
- telnetcfg 97
  - options
    - t 97
- telnetcfg command errors 137
- telnetcfg commands 97

- telnetcfg commands (*continued*)
  - example 97
- temporary command target 5
- terminate session 48
- thermal event response 50
- time
  - display for management module 32
  - set for management module 32
- trademarks 147
- turn off
  - blade server 72
  - I/O module 72
  - switch module 72
- turn off location LED 58
- turn on
  - blade server 72
  - I/O module 72
  - switch module 72
- turn on (to console)
  - blade server 72

## U

- update
  - options
    - a 98
    - i, l 98
    - i, l, v 99
- update command 98
- update command errors 137
- update commands
  - example 99
- update firmware 98
- update firmware (verbose) 99
- uplink 101
  - options
    - del 101
    - off 101
    - on 101
- uplink command errors 140
- uplink commands 101
  - example 101
- uplink configuration
  - display for management module 101
- uplink failover (physical)
  - disable for management module 101
  - enable for management module 101
- uplink failover delay (physical)
  - set for management module 101
- users 103
  - options
    - 1 through 12 103
    - a 107
    - ap 109
    - at 110
    - clear 103
    - cn 108
    - create (n, p, a, cn, ap, pp, ppw, at, i) 104
    - i 110
    - n 106
    - p 106
    - pp 109
    - ppw 109
  - users command 103
  - users command errors 140

- users commands
  - example 110
- users, create 104, 105
- users, delete 103
- users, display (all) 103
- users, display (single) 103
- users, management module 103
- users, set access type (SNMPv3) 110
- users, set authentication protocol (SNMPv3) 109
- users, set authority level 107, 108
- users, set context name (SNMPv3) 108
- users, set hostname (SNMPv3 traps) 110
- users, set IP address (SNMPv3 traps) 110
- users, set name 106
- users, set password 106
- users, set privacy password (SNMPv3) 109
- users, set privacy protocol (SNMPv3) 109
- using
  - Secure Shell server 11
- using the command-line interface 3

## V

- view command target 69
- VLAN ID
  - set for SOL 93

## W

- Wake on LAN
  - enable for blade server 73
  - enable globally 72
- web site
  - publication ordering 145
  - support 145
  - support line, telephone numbers 146
- WNN information reload 65





Part Number: 44R5372

Printed in USA

(1P) P/N: 44R5372

